




# INSTALLATION MANUAL

FOR ROTAX<sup>®</sup> ENGINE TYPE 915 i A SERIES



## **WARNING**

**Before starting with engine installation, please read the Installation Manual completely as it contains important safety relevant information.**

This Installation Manual for the ROTAX<sup>®</sup> aircraft engines should only be used as a general installation guide for the installation of ROTAX<sup>®</sup> engines into airframes. It should not be used as instruction for the installation of a ROTAX<sup>®</sup> aircraft engine in a specific type of airframe or airplane. BRP-Rotax GmbH & Co KG does not assume any warranty or liability in this context.

In no event shall the Installation Manual be used without following the specific instructions and/or requirements of the manufacture of an airframe or airplane (“Manufacturer”). For verification and/or for release of the engine installation, the respective Manufacturer must be contacted. Any modifications or adaptations to the airframe or airplane shall be carried out and/or be verified and released by the Manufacturer only.

Improper use of the Installation Manual and/or non compliance with the installation requirements of the Manufacturers can cause personal injury or property damage. BRP-Rotax GmbH & Co. KG disclaims any liability for any and all damage and/or injuries (including death) resulting from the improper use of Installation Manual and non compliance with the installation requirements of the Manufacturer.

These technical data and the information embodied therein are the property of BRP-Rotax GmbH & CO KG, Austria, acc, BGBl 1984 no. 448, and shall not, without prior written permission of BRP-Rotax GmbH & Co KG, be disclosed in whole or in part to third parties. This legend shall be included on any reproduction of these data, in whole or in part. The Manual must remain with the engine/aircraft in case of sale.

ROTAX<sup>®</sup> is a trade mark of BRP-Rotax GmbH & Co KG. In the following document the short form of BRP-Rotax GmbH & Co KG = BRP-Rotax is used.

Other product names in this documentation are used purely for ease of identification and may be trademarks of the respective company or owner.

Copyright 2019 © - all rights reserved.

Translation into other languages might be performed in the course of language localization but does not lie within ROTAX<sup>®</sup> scope of responsibility.

In any case the original text in English language and the metric units are authoritative.

**BRP-Rotax**  
**INSTALLATION MANUAL**

## **Table of Content**

<b>Chapter</b>	<b>INTRO</b> – GENERAL NOTE
<b>Chapter</b>	<b>LEP</b> – LIST OF EFFECTIVE PAGES
<b>Chapter</b>	<b>TOA</b> – TABLE OF AMENDMENTS
<b>Chapter</b>	<b>00-00-00</b> – GENERAL NOTE
<b>Chapter</b>	<b>10-10-00</b> – STORAGE AND INSTALLATION
<b>Chapter</b>	<b>24-00-00</b> – ELECTRICAL POWER
<b>Chapter</b>	<b>61-00-00</b> – PROPELLER DRIVE
<b>Chapter</b>	<b>72-00-00</b> – ENGINE
<b>Chapter</b>	<b>72-60-00</b> – AIR INTAKE SYSTEM
<b>Chapter</b>	<b>73-00-00</b> – ENGINE – FUEL AND CONTROL
<b>Chapter</b>	<b>75-00-00</b> – COOLING SYSTEM
<b>Chapter</b>	<b>76-00-00</b> – ENGINE CONTROLS
<b>Chapter</b>	<b>77-00-00</b> – ENGINE INDICATING
<b>Chapter</b>	<b>78-00-00</b> – EXHAUST SYSTEM
<b>Chapter</b>	<b>79-00-00</b> – LUBRICATION SYSTEM
<b>Chapter</b>	<b>80-00-00</b> – STARTING
<b>Chapter</b>	<b>APPENDIX</b> – OPERATIONAL AND INSTALLATION CONSIDERATIONS

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK

# BRP-Rotax INSTALLATION MANUAL

## Chapter: INTRO GENERAL NOTE

### Foreword

Before carrying out engine installation related work on the engine, read this Installation Manual carefully. The manual will provide you with basic information on correct engine installation for safe engine operation.

If any passages of the manual are not clearly understood or if you have any questions, please contact a ROTAX® authorized distributor or their independent Service Center for ROTAX® aircraft engines.

BRP-Rotax GmbH & Co KG (hereinafter "BRP-Rotax") wishes you much pleasure and satisfaction flying your aircraft powered by this ROTAX® aircraft engine.

The structure of the manual follows, whenever possible, the structure of the ATA (Air Transport Association) standards. The aim is the compatibility with the aircraft manufacturers documentation, which means they still must adapt or incorporate the documentation to their standard.

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK

**BRP-Rotax  
INSTALLATION MANUAL**

**Chapter: LEP  
LIST OF EFFECTIVE PAGES**

Each new revision to the Installation Manual will have a new List of Effective Pages.

Chapter	Page	Date
	Title page	
INTRO	1	June 01 2019
	2	June 01 2019
LEP	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
TOA	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
00-00-00	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
	10	June 01 2019
	11	June 01 2019
	12	June 01 2019
	13	June 01 2019
	14	June 01 2019
	15	June 01 2019
	16	June 01 2019
	17	June 01 2019
	18	June 01 2019

Chapter	Page	Date
	19	June 01 2019
	20	June 01 2019
10-10-00	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
24-00-00	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
	10	June 01 2019
	11	June 01 2019
	12	June 01 2019
	13	June 01 2019
	14	June 01 2019
61-00-00	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019

**BRP-Rotax**  
INSTALLATION MANUAL

Chapter	Page	Date
72-00-00	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
	10	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
72-60-00	10	June 01 2019
	11	June 01 2019
	12	June 01 2019
	13	June 01 2019
	14	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
73-00-00	10	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019

Chapter	Page	Date
75-00-00	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
	10	June 01 2019
	11	June 01 2019
	12	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
76-00-00	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
	10	June 01 2019
	11	June 01 2019
	12	June 01 2019
	13	June 01 2019
	14	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
7	June 01 2019	
8	June 01 2019	
9	June 01 2019	
10	June 01 2019	
11	June 01 2019	



**BRP-Rotax**  
INSTALLATION MANUAL

Chapter	Page	Date
77-00-00	12	June 01 2019
	13	June 01 2019
	14	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
78-00-00	8	June 01 2019
	9	June 01 2019
	10	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
79-00-00	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	1	June 01 2019
	2	June 01 2019
	3	June 01 2019
	4	June 01 2019
	5	June 01 2019
	6	June 01 2019
	7	June 01 2019
	8	June 01 2019
	9	June 01 2019
	10	June 01 2019
11	June 01 2019	
12	June 01 2019	
13	June 01 2019	

Chapter	Page	Date	
80-00-00	14	June 01 2019	
	15	June 01 2019	
	16	June 01 2019	
	1	June 01 2019	
	2	June 01 2019	
	3	June 01 2019	
	4	June 01 2019	
	5	June 01 2019	
	6	June 01 2019	
	7	June 01 2019	
	8	June 01 2019	
	APPENDIX	1	June 01 2019
		2	June 01 2019
3		June 01 2019	
4		June 01 2019	
5		June 01 2019	
6		June 01 2019	
7		June 01 2019	
8		June 01 2019	
9		June 01 2019	
10		June 01 2019	
11	June 01 2019		
12	June 01 2019		
13	June 01 2019		
14	June 01 2019		
15	June 01 2019		
16	June 01 2019		
17	June 01 2019		
18	June 01 2019		
	Index		
	Rear page		

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK

**BRP-Rotax**  
INSTALLATION MANUAL

**Chapter: TOA**  
**TABLE OF AMENDMENTS**

**Approval\***  
The technical content of this document is approved. It is issued under the authority of DOA ref. EASA.  
21J.048.  
This document is part of the ICA for product [2019].

Edition 0/Rev. 0    December 01 2017    Obsolete with Revision 1, which is a complete re-revision  
Revision 1        June 01 2019

Rev. no.	Chapter	Page	Date of change	Remark for approval	Date of approval from authorities	Date of inclusion	Signature
0	INTRO	all	December 01 2017	DOA*			
0	LEP	all	December 01 2017	DOA*			
0	TOA	all	December 01 2017	DOA*			
0	00-00-00	all	December 01 2017	DOA*			
0	10-10-00	all	December 01 2017	DOA*			
0	24-00-00	all	December 01 2017	DOA*			
0	61-00-00	all	December 01 2017	DOA*			
0	72-00-00	all	December 01 2017	DOA*			
0	72-60-00	all	December 01 2017	DOA*			
0	73-00-00	all	December 01 2017	DOA*			
0	75-00-00	all	December 01 2017	DOA*			
0	76-00-00	all	December 01 2017	DOA*			
0	77-00-00	all	December 01 2017	DOA*			
0	78-00-00	all	December 01 2017	DOA*			
0	79-00-00	all	December 01 2017	DOA*			
0	80-00-00	all	December 01 2017	DOA*			

**BRP-Rotax**  
INSTALLATION MANUAL

Rev. no.	Chapter	Page	Date of change	Remark for approval	Date of approval from authorities	Date of inclusion	Signature
1	LEP	all	June 01 2019	DOA*			
1	TOA	all	June 01 2019	DOA*			
1	00-00-00	3, 4, 5,10,15,17	June 01 2019	DOA*			
1	10-00-00	2,5	June 01 2019	DOA*			
1	24-00-00	2,3,7,8,13	June 01 2019	DOA*			
1	61-00-00	4,5,6,9	June 01 2019	DOA*			
1	72-00-00	2,4 up to 7, 9, 10	June 01 2019	DOA*			
1	72-60-00	3 up to 7	June 01 2019	DOA*			
1	73-00-00	10	June 01 2019	DOA*			
1	75-00-00	3,5,7,10,11	June 01 2019	DOA*			
1	76-00-00	9,12	June 01 2019	DOA*			
1	77-00-00	3,8	June 01 2019	DOA*			
1	78-00-00	3,4	June 01 2019	DOA*			
1	79-00-00	2,3,8,11,15	June 01 2019	DOA*			
1	APPEN-DIX	all	June 01 2019	DOA*			

# BRP-Rotax INSTALLATION MANUAL

## Summary of amendments

Summary of the relevant amendments in this context, but without any claim to completeness.

Rev. no.	Chapter	Page	Date of change	Comment
1	00-00-00	3	June 01 2019	Configuration 2 added
1		10	June 01 2019	Wiring color codes
1	24-00-00	2,13	June 01 2019	New figure
1	61-00-00	5,6	June 01 2019	New figure
1	72-00-00	9, 10	June 01 2019	Change of text
1	72-60-00	3-7	June 01 2019	Change of text, new figures
1	75-00-00	5,7,10	June 01 2019	Change of text
1	76-00-00	9,12	June 01 2019	Change of text, Update of figures
1	77-00-00	8	June 01 2019	Update of figures
1	78-00-00	3,4	June 01 2019	New figures
1	79-00-00	2,3,8,11,15	June 01 2019	Change of text, new figures
1	APPENDIX	all	June 01 2019	Appendix added

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK

**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: 00-00-00**  
**GENERAL NOTE**

**TOPICS IN THIS CHAPTER**

**General**.....2

**Type description**.....3

**Scope of supply**.....4

**Auxiliary equipment (optional)** .....5

**Abbreviations and terms** .....6

    Wiring color codes .....10

    Conversion table .....11

**Safety notice** .....12

    Safety information .....13

    Instruction .....15

**Technical documentation** .....17

**Approval of electric and electronic components (Equipment Qualification according to RTCA/DO-160)** .....19

# BRP-Rotax INSTALLATION MANUAL

## GENERAL

### **Purpose**

The purpose of this manual is to provide aircraft manufacturers with technical requirements (e.g. interface descriptions and limitations) that must be adhered to when installing this type of engine into an aircraft or certifying aircraft powered by this engine type. Furthermore it should allow independent ROTAX® Maintenance Technicians (iRMT) to install this engine into an airframe in compliance with the relevant installation and safety instructions provided by the engine manufacturer.

For detailed information related to aircraft and aircraft/engine installation, maintenance, safety or flight operation, consult the documentation provided by the aircraft manufacturer and/or its dealer.

For additional information on engines, its maintenance or parts, you can also contact your nearest ROTAX® authorized Aircraft Engine Distributor or their independent Service Center.

### **ROTAX Distributors**

For ROTAX® Authorized Distributors for aircraft engines see latest Operators Manual or the official website [www.FLYROTAX.com](http://www.FLYROTAX.com).

### **Engine serial number**

When making inquiries or ordering parts, always indicate the engine serial number. Due to continuous product improvement, engines of the same engine type might require different support and spare parts.

The engine serial number is on top of the crankcase, behind the propeller gearbox.




Figure 1.1: Engine serial number


1 Engine serial number



# BRP-Rotax INSTALLATION MANUAL

## TYPE DESCRIPTION

The type description consists of the following parts:



### Designation

Designation		Description
<b>Type</b>	<b>915</b>	4-cylinder horizontally opposed, turbocharged engine.
<b>Certification</b>	<b>iSc</b>	Certified to EASA CS-E (TC No.EASA.E.121)
	<b>iS</b>	Approved to according ASTM F2339.
<b>Configuration</b>	<b>2</b>	Propeller shaft with flange for fixed pitch propeller.
	<b>3</b>	Propeller shaft with flange for constant speed propeller and drive for hydraulic governor for constant speed propeller.
<b>Additional designation</b>	<b>A</b>	Standard version

### Options

Available options (optional equipment) for the engine type mentioned above:

	external alternator	governor	exhaust system
<b>for configuration 2</b>	YES	NO	YES
<b>for configuration 3</b>	YES	YES	YES

### NOTE

*Conversion of the version 2 to version 3 and vice versa may be accomplished by BRP-Rotax Authorized Distributors or their Service Center.*

# BRP-Rotax INSTALLATION MANUAL

## SCOPE OF SUPPLY

### Basic

- 4- stroke-, 4 cylinder horizontally opposed-, spark ignition engine, single central cam-shaft push rods —OHV (Over Head Valve)
- Liquid cooled cylinder heads
- Ram air cooled cylinders
- Dry sump forced lubrication
- Fully redundant electronic engine management system (EMS) for controlling fuel injection, ignition, etc.
- Propeller drive via gearbox with integrated torsional vibration absorber and overload clutch
- Oil tank
- Electric starter
- Turbocharged
- Electronic/pneumatic control of boost pressure
- Exhaust system

### Optional

- Preparation for hydraulic governor for constant speed propeller (configuration 3 only)
- Cooling air baffle

**BRP-Rotax**  
INSTALLATION MANUAL

**AUXILIARY EQUIPMENT (OPTIONAL)**

Any equipment not included as part of the standard engine version and thus not a fixed component of the engine is not in the volume of supply. Components especially developed and tested for this engine are readily available at BRP-Rotax.

**Auxiliary equipment certified**

The following auxiliary equipment has been developed and tested for this engine.

- See relevant Illustrated Parts Catalog

**Auxiliary equipment not certified**



The following auxiliary equipment has not been developed and tested for this engine.

- See relevant Illustrated Parts Catalog

The representation of components that are not within scope of the delivery is purely symbolic. It does not constitute the specification of the engine version and shall therefore only be seen functionally. The actual interpretation/selection of corresponding regulations is the aircraft manufacturer's responsibility.

**BRP-Rotax**  
INSTALLATION MANUAL

**ABBREVIATIONS AND TERMS**

Abbreviations	Description
*	Reference to another section
	center of gravity
	The drop symbol indicates use of sealing agents, adhesives or lubricants (only in the Illustrated Parts Catalog).
°C	Degrees Celsius (Centigrade)
°F	Degrees Fahrenheit
rpm	Revolutions per minute
A	Ampere
AAPTS	Ambient Air Pressure Temperature Sensor
AC	alternating current
AD	Airworthiness Directives
Ah	Ampere hour
A/C	Aircraft
AR	as required
assy.	assembly
ASB	Alert Service Bulletin
ACG	Austro Control GmbH
ACL	Anti Collision Light
API	American Petrol Institute
ASTM	American Society for Testing and Materials
ATA	Air Transport Association
AWG	American Wire Gauge
CAN	Controller Area Network
Coil 1–4	Ignition coils 1–4
CPS 1+2	Crankshaft Position Sensor 1+2
CSA	Constant Speed Actuator
CTS	Cooling Temperature Sensor
CW	clockwise
CCW	counter-clockwise
CGSB	Canadian General Standards Board

## BRP-Rotax INSTALLATION MANUAL

DCDI	Dual Capacitor Discharge Ignition
DC	direct current
DOA	Design Organisation Approval
DOT	Department of Transport
EASA	European Aviation Safety Agency
IM	Installation Manual
ECU	Engine Control Unit
EGT	Exhaust Gas Temperature
INTRO	Introduction
EMS	Engine Management System
EMS GND	Engine system internal ground reference which is intended to be disconnected from aircraft common ground during flight
EMC	Electromagnetic compatibility
EN	European Standard
ETFE	Ethylene Tetrafluoroethylene
FAA	Federal Aviation Administration
FAR	Federal Aviation Regulations
FOD	Foreign object damage
Fuse box	Power conditioning and distribution for the Engine Management System
hr.	hours
HIC A	Harness Interface Connector A
HIC B	Harness Interface Connector B
IAT	Indicated Air Temperature
ICA	Instructions for Continued Airworthiness
IFR	Instrument Flight Rules
IFSD	In-flight-shutdown
INJ 1–8	Injector 1–8
IPC	Illustrated Parts Catalog
ips	inch per second
iRMT	independent ROTAX Maintenance Training
ISA	International Standard Atmosphere

## BRP-Rotax INSTALLATION MANUAL

kg	Kilograms
KNOCK	Knock sensor
Lane A	System A of Engine Management System
Lane B	System B of Engine Management System
LOPC	Loss of power control
MAPS 1 & 2	Manifold Air Pressure Sensor 1 & 2
MATS 1 & 2	Manifold Air Temperature Sensor 1 & 2
MON	Motor Octane Number
MAG	Magneto Side
N	Newton
n.a.	not available
NDT	Non Destructive Testing
Nm	Newtonmeter
NVFR	Night Visual Flight Rules
OAT	Organic Acid (Additive) Technology
OHM	Overhaul Manual
OHV	Over Head Valve
OM	Operators Manual
OPS	Oil Pressure Sensor
OTS	Oil Temperature Sensor
PCD	Pitch Circle Diameters
PCV	Pressure Control Valve
PMA	Permanent magnet alternator
POA	Production Organisation Approval
PS	Power supply
PTFE	Polytetrafluoroethylene (Teflon)
PTO	Power Take Off
Rev.	Revision
ROTAX®	is a trademark of BRP-Rotax GmbH & Co KG
RON	Research Octane Number
RON 424	ROTAX® Standard 424
s.v.	still valid (only Illustrated Parts Catalog)


















**BRP-Rotax**  
INSTALLATION MANUAL

S/N	Serial Number
SAE	Society of Automotive Engineers
SEP	Single Engine Piston
SB	Service Bulletin
SI	Service Instruction
SI-PAC	Service Instruction Parts and Accessories
SPST	Single pole single throw
STP	Shield twisted pair
SL	Service Letter
SMD	Surface Mounted Devices
TBO	Time Between Overhaul
TC	Type certificate
part no.	part number
TOA	Table Of Amendments
TOC	Table of content
TPS	Throttle Position Sensor
TSN	Time Since New
TSNP	Time Since New Part
TSO	Time Since Overhaul
V	Volt
VFR	Visual Flight Rules
LEP	List of Effective Pages
MM	Maintenance Manual
MEP	Multi Engine Piston
X3	Connector on Engine Management System wiring harness which serves as an interface for power supply
XXXX	shows the serial component number

WIRING COLOR CODES

# IEC 60757

## Color codes (wiring)

black		BK
brown		BN
red		RD
orange		OG
yellow		YE
green		GN
blue		BU
violet		VT
gray		GY
white		WH
pink		PK
turquoise		TQ
Light blue		LBU
Dark blue		DBU
gold		GD
silver		SR
green-yellow		GNYE

10336

Figure 1.2



**BRP-Rotax**  
INSTALLATION MANUAL

**CONVERSION TABLE**

<b>Units of length:</b>	<b>Units of power:</b>
1 mm = 0.03937 in 1 in = 25.4 mm 1 ft = 12 in = 0.3048 m	1 kW = 1.341 hp 1 hp = 0.7457 kW 1 kW = 1.3596 PS 1 PS = 0.7355 kW
<b>Units of area:</b>	<b>Units of temperature:</b>
1 cm <sup>2</sup> = 0.155 sq. in (in <sup>2</sup> ) 1 sq. in (in <sup>2</sup> ) = 6.4516 cm <sup>2</sup>	K = °C – 273,15 °C = (°F – 32) / 1,8 °F = (°C x 1.8) +32
<b>Units of volume:</b>	<b>Units of velocity:</b>
1 cm <sup>3</sup> = 0.06102 cu in (in <sup>3</sup> ) 1 cu in (in <sup>3</sup> ) = 16.3871 cm <sup>3</sup> 1 dm <sup>3</sup> = 1 l 1 dm <sup>3</sup> = 0.21997 gal (UK) 1 gal (UK) = 4.5461 dm <sup>3</sup> 1 dm <sup>3</sup> = 0.26417 gal (US) 1 gal (US) = 3.7854 dm <sup>3</sup>	1 m/s = 3.6 km/h 1 ft/min = 0.3048 m/min = 0.00508 m/sec 1 m/s = 196.85 ft/min 1 kt = 1.852 km/h 1 km/h = 0.53996 kn
<b>Units of mass:</b>	<b>spec. fuel consumption:</b>
1 kg = 2.2046 lbs. 1 lb. = 0.45359 kg	1 g/kWh = 0.001644 lb/hph 1 lb/hph = 608.277 g/kWh
<b>Density:</b>	<b>Units of torque:</b>
1 g/cm <sup>3</sup> = 0.016018 lb/ft <sup>3</sup> 1 lb/ft <sup>3</sup> = 62.43 g/cm <sup>3</sup>	1 Nm = 0.737 ft lb = 8.848 in lb 1 ft lb = 1.356 Nm 1 in lb = 0.113 Nm
<b>Units of force:</b>	<b>Cable cross-section: Conversion table- Wire Gauge: AWG-mm<sup>2</sup></b>
1 N = 0.224809 lbf 1 lbf = 4.4482 N	AWG → mm <sup>2</sup> 4 → 21 6 → 13 8 → 8.4 10 → 5.3 12 → 3.3 14 → 2.1 16 → 1.3 18 → 0.8 20 → 0.52
<b>Units of pressure:</b>	
1 Pa = 1 N/m <sup>2</sup> 1 bar = 100 000 Pa / 1000 hPa / 100 kPa 1 bar = 14.503 lbf/in <sup>2</sup> (psi) 1 in Hg = 33.8638 hPa	

# BRP-Rotax INSTALLATION MANUAL

## **SAFETY NOTICE**

Although reading such information does not eliminate any hazards, it promotes understanding, and applying of the information will promote correct use of the engine. Always apply common workshop safety rules.

The information and descriptions of components and systems contained in this Manual are correct at the time of publication. BRP-Rotax maintains a policy of continuous improvement of its products without imposing upon itself any obligation to retrofit products previously manufactured.

### **Revisions**

BRP-Rotax reserves the right to remove, replace or discontinue any design, specification, feature or other at any time, and without incurring obligation.

### **Measurement**

Specifications are given in the SI metric system with the imperial- and US customary measurement system equivalents in parenthesis.

### **Symbols used**

This Manual uses the following symbols to emphasize particular information. This information is important and must be observed.

#### **⚠ WARNING**

**Identifies an instruction which, if not followed, may cause serious injury or even fatal injury.**

#### **⚠ CAUTION**

**Identifies an instruction which, if not followed, may cause minor or moderate injury.**

#### **ATTENTION**

**Identifies an instruction which, if not followed, may severely damage the engine or could void any warranty.**

### **NOTE**

*Indicates supplementary information which may be needed to fully complete or understand an instruction.*

#### **ENVIRONMENTAL NOTE**

**Environmental notes give you tips on environmental protection.**

A revision bar outside the page margin indicates a change to text or graphic.

# BRP-Rotax INSTALLATION MANUAL

## SAFETY INFORMATION

Use for intended  
purpose

### **⚠ WARNING**

#### **Non-compliance can result in serious injuries or death!**

The user has to assume all risks possibly arising from utilizing auxiliary equipment.

### **⚠ WARNING**

#### **Non-compliance can result in serious injuries or death!**

Never fly the aircraft equipped with this engine at locations, air speeds, altitudes or in other situations which do not allow a successful no-power landing after sudden engine stoppage.

- This engine is not suitable for aerobatics (inverted flight, etc.). Flight attitudes outside the permissible limits are not allowed
- This engine has exclusively been developed and tested for fixed wing, gyrocopter, pusher and tractor applications. In case of any other usage, the OEM is responsible for testing and the correct function of the engine
- It should be clearly understood that the choice, selection and use of this particular engine on any aircraft is at the sole discretion and responsibility of the aircraft manufacturer, assembler or owner/user
- Due to the varying designs, equipment and types of aircraft, BRP-Rotax grants no warranty on the suitability of its engines use on any particular aircraft. Further, BRP-Rotax grants no warranty on this engines suitability with any other part, component or system which may be selected by the aircraft manufacturer, assembler or user for aircraft application

### **⚠ WARNING**

#### **Non-compliance can result in serious injuries or death!**

For each use of DAY VFR, NIGHT VFR or IFR in an aircraft the applicable legal requirements and other existing regulations must be adhered to.

- In addition to observing the instructions in our Manual, general safety and accident precautions, legal regulations and regulations of any aeronautical authority must be observed
- Where differences exist between this Manual and regulations provided by any authority, the more stringent regulation shall be applied
- For continued airworthiness see Maintenance Manual Line
- Unauthorized modifications of engine or aircraft will automatically exclude any liability of the engine manufacturer for consequential damage

# BRP-Rotax

## INSTALLATION MANUAL

- Engine operation**
- The engine must always be operated according to the content of the latest Operators Manual
  - To eliminate the risk of injury or damage, ensure any loose equipment or tools are properly secured before starting the engine
  - The use of propellers and their fastenings which exceed the specified values of moment of inertia and imbalance is not allowed and releases the engine manufacturer from any liability
  - Improper engine installation, use of unsuitable piping for fuel, cooling and lubrication system and use of unsuitable wiring for electric and engine management system releases the engine manufacturer from any liability

# BRP-Rotax

## INSTALLATION MANUAL

### INSTRUCTION

Engines require instructions regarding their installation, application, use, operation, maintenance and repair.

Technical documentation and regulations are useful and necessary complementary elements for trainings, but can by no means substitute for theoretical and practical instructions.

These instructions should cover explanation of the technical context, advice for operation, maintenance, installation, use and operational safety of the engine.

#### Safety notice

In this technical Manual passages concerning safety are especially marked. Pass on safety warnings to other users!

#### Accessories

This engine must only be operated with accessories supplied, recommended and released by BRP-Rotax. Modifications are only allowed after consent of the engine manufacturer.

#### Spare parts



See Illustrated Parts Catalog, latest issue for the respective engine type.

#### ATTENTION

**Only use GENUINE ROTAX® spare parts. Spare parts must meet the requirements defined by the engine manufacturer. This can only be guaranteed when using GENUINE ROTAX® spare parts and/or accessories. Spare parts are available at ROTAX® Authorized Distributors and their independent Service Centers. Any warranty by BRP-Rotax will become void if spare parts and/ or accessories other than GENUINE ROTAX® spare parts and/or accessories are used (see latest Warranty Conditions).**

See relevant Service Letter on [www.FLYROTAX.com](http://www.FLYROTAX.com)

#### Standard tools / Special tools

#### ATTENTION

**Only use tools and appliances which are suitable for the relevant task according to the latest Manuals.**

#### State of delivery

#### ⚠ WARNING

**Engine and gearbox are delivered in “dry” conditions (without fuel, oil and coolant).**

Before putting the engine into operation it must be filled with oil and cooling liquid. Use only oil and coolant as specified.

# BRP-Rotax INSTALLATION MANUAL



See latest Operators Manual and Service Instruction SI-915 i-001 "Selection of suitable operating fluids", current issue.

# BRP-Rotax INSTALLATION MANUAL

## TECHNICAL DOCUMENTATION

These documents form the instructions ensuring continued airworthiness of ROTAX® aircraft engines.

The information contained herein is based on data and experience that are considered applicable for authorized mechanics (iRMT, see Maintenance Manual Line) under normal conditions for engine removal and installation. Concerning design of engine installation in depth knowledge of aircraft design is required.

Due to the fast technical progress and fulfillment of particular specifications of the customers it may occur that existing laws, safety prescriptions, constructional and operational regulations may not be sufficient or cannot be transferred completely to the object bought, in particular for special constructions.

### Documentation

- Installation Manual
- Operators Manual
- Maintenance Manual (Line and Heavy Maintenance)
- Overhaul Manual
- Illustrated Parts Catalog
- Alert Service Bulletin
- Service Bulletin
- Service Instruction / Service Instruction-Parts and Accessories
- Service Letter



### Status

The status of the Manuals can be determined by checking the table of amendments. The first column of this table indicates the revision status, which should be compared with the revision provided on the ROTAX®-Website: [www.FLYROTAX.com](http://www.FLYROTAX.com)  
Amendments and current versions can be downloaded free of charge.

### Replacement pages

Furthermore the Manual is constructed in such a way that single pages can be replaced instead of the complete document. The list of affected pages is given in the chapter LEP. The particular edition and revision number is given on the footer of each page.

### Reference

This Manual is only part of the technical documentation and will be supplemented by the respective Operators Manual, Maintenance Manuals and Illustrated Parts Catalog.

#### ATTENTION

**Pay attention to references to other documentation, found in various parts of this Manual.**

If not stated otherwise, any reference to a document refers to the latest edition issued by BRP-Rotax.



This symbol informs you of additional references (data sheets, Manuals, etc.) associated with the given subject.

# BRP-Rotax INSTALLATION MANUAL

## Illustrations

The illustrations in this Manual are merely sketches and show typical arrangements. They may not represent full detail or the exact shape of the parts but should outline the same or similar function. Therefore deriving dimensions or other details from illustrations is not permitted.

TYPICAL indicates a general view which may not represent exact details.

## NOTE

*The Illustrations in this Manual are stored in a graphic database system and are provided with a consecutive, irrelevant, number.*

*This number (e.g. AE 5iS001) is of no significance for the content.*

Some measurements are given in the drawings, these are manufacturing dimensions and are subject to corresponding tolerances.

## Installation drawings

Installation drawings and a DMU-model for (virtual) installation analysis are available from the ROTAX® Authorized Distributors or their independent Service Centers on special request and relevant non disclosure and copyright regulations.

The illustrations in this Manual show a possible installation variant including non certified parts.



**BRP-Rotax**  
**INSTALLATION MANUAL**

**APPROVAL OF ELECTRIC AND ELECTRONIC COMPONENTS**  
**(EQUIPMENT QUALIFICATION ACCORDING TO RTCA/DO-160)**

RTCA/DO-160 defines a series of minimum standard environmental test conditions and applicable test procedures for airborne equipment. The purpose of these tests is to provide a laboratory means of determining the performance characteristics of airborne equipment in environmental conditions representative of those which may be encountered in airborne operation of the equipment.

Electric and Electronic components (incl. wiring harness, ECU, Fuse Box, PMA, Sensors and Actuators) of the 915 i A Series are considered as part of the equipment and have been tested and qualified according to the following table:

DO-160G, Section 4 — Temperature and Altitude	Cat. C3V <sup>1</sup>
DO-160G, Section 5— Temperature Variation	Cat. B
DO-160G, Section 6— Humidity	Cat. B
DO-160G, Section 7— Operational Shocks and Crash Safety	Cat. BD
DO-160G, Section 8 — Vibration	Cat. S (L)
DO-160G, Section 9— Explosion Proofness	Test not performed
DO-160G, Section 10 — Water Proofness	Cat. S
DO-160G, Section 11 — Fluids Susceptibility	Cat. F
DO-160G, Section 12 — Sand and Dust	Cat. D
DO-160G, Section 13 — Fungus Resistance	Test not performed
DO-160G, Section 14 — Salt Spray	Cat. S
DO-160G, Section 15 — Magnetic Effect	Cat. A
DO-160G, Section 16 — Power Input	Cat. BXX
DO-160G, Section 17 — Voltage Spike	Cat. A
DO-160G, Section 18 — AF Cond. Susceptibility	Cat. Z
DO-160G, Section 19 — Induced Signal Susceptibility	Cat. ZCX
DO-160G, Section 20 — RF Susceptibility Conducted DO-160G, Section 20 — RF Susceptibility Radiated	Cat. M Cat. D
DO-160G, Section 21 — Emission RF Energy Conducted DO-160G, Section 21 — Emission RF Energy Radiated	Cat. B Cat. B
DO-160G, Section 22 — Lightning Induced Trans. Susceptibility	Cat. B3H3L3
DO-160G, Section 23 — Lightning Direct Effects	Test not performed

- 
1. Components were tested at „operating low temperature“ of - 40 °C (- 40 °F) instead of - 45 °C (- 49 °F).

**BRP-Rotax**  
INSTALLATION MANUAL

DO-160G, Section 24 — Icing	Test not performed
DO-160G, Section 25 — Electrostatic Discharge	Cat. A

**Component temperatures limits**

<b>System Limit</b>	<b>Min.</b>	<b>Max.</b>
ECU	- 40 °C (- 40 °F)	80 °C (176 °F)
EGT Sensors (electronic box)	- 40 °C (- 40 °F)	80 °C (176 °F)
Fusebox	- 40 °C (- 40 °F)	80 °C (176 °F)

**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: 10-10-00**  
**STORAGE AND INSTALLATION**

**TOPICS IN THIS CHAPTER**

**Special tools**.....3


**General**.....4

    Engine storage .....4

    Unpacking the engine .....4

    Engine handling .....7

**BRP-Rotax**  
**INSTALLATION MANUAL**



AE 5iS\_0158

Figure 2.1: 915 iS engine TYPICAL

**BRP-Rotax**  
INSTALLATION MANUAL

**SPECIAL TOOLS**

<b>Description</b>	<b>Part number</b>
Engine lift set	876040

# BRP-Rotax INSTALLATION MANUAL

## GENERAL

### ATTENTION

**Risk of consequential damage to engine and aircraft as a result of corrosion and damage. Under no circumstances is a corroded or damaged engine to be installed in an aircraft!**

## ENGINE STORAGE

The engine is preserved at BRP-Rotax thus guaranteeing proper protection against corrosion damage for at least 12 months after the date of delivery from BRP-Rotax.

This warranty is subject to the following conditions:

- The engine must be stored in the GENUINE ROTAX® packing as supplied by BRP-Rotax.
- The covers on various openings must not be removed
- The engine must be stored in a suitable place (at min. -40 °C/-40 °F and max. +80 °C/176 °F)
- The bag (blue) surrounding the engine must not be damaged or removed, as it protects the engine from corrosion and oxidation

If the engine is stored for a period longer than 12 months (or it is not stored in the GENUINE ROTAX® packing) then maintenance tasks must be carried out every 3 months as per the currently valid Maintenance Manual Line.

## UNPACKING THE ENGINE

### ATTENTION

**The attachment screws are only for transport and must not be used in the aircraft.**

### ATTENTION

**During engine installation take into account the total engine weight and ensure careful handling.**

### Unpacking the engine

When the engine is delivered, check for damage of the packaging. If the package is damaged, contact a ROTAX® Authorized Distributor or their independent Service Center for ROTAX® aircraft engines.

To unpack a new engine and for checking the state of delivery, proceed as follows:

1. Remove the wooden cover.
2. Remove the bag and protective wrapping around the engine.
3. Check that the serial number and engine type on the type plate are identical to those shown on the delivery note.

## BRP-Rotax INSTALLATION MANUAL

If the serial number or the engine type is deviating from the delivery contact a ROTAX® Authorized Distributor- or their independent Service Center for ROTAX® aircraft engines.

4. Check the engine for damage or corrosion.  
If the engine is damaged or corroded, contact a ROTAX® Authorized Distributor- or their independent Service Center for ROTAX® aircraft engines.
5. Screw off the transport bracket screws from wooden bottom of the box.
6. Remove transport brackets from engine.

### Protective coverings


ATTENTION
<p><b>Protective coverings are only for use during transport and engine installation. They must be removed completely (including sealing materials) before the engine is operated.</b></p>

All openings are protected against ingress of contamination and dampness. It is recommended to leave the protective plugs in place until installation of the specific feed line.

The protective coverings can be found at following locations:

Pos.	Installation location	Amount
1	Exhaust pipe (tail pipe)	
2	Fuel rail (outlet) / fuel pressure regulator	
3	Fuel rail (inlet)	
4	Oil inlet/outlet and oil return turbo (oil pump)	
5	Coolant inlet/outlet	
6	Throttle body socket assy.	
7	Air intake socket on turbocharger	
8	Wastegate	
9	Propeller shaft	
10	Cover plate hydraulic governor (if configuration 3)	
11	Oil return turbo (governor flange)	

# BRP-Rotax INSTALLATION MANUAL



AE 5iS\_0151

Figure 2.2: Protective covering positions

- |                                     |  |
|-------------------------------------|--|
| 1 Exhaust pipe                      | 2 Fuel (outlet) /fuel pressure regulator     |
| 3 Fuel rail (inlet)                 | 4 Oil inlet/outlet and oil return turbo      |
| 5 Coolant inlet/outlet              | 6 Throttle body socket assy.                 |
| 7 Air intake socket on turbocharger | 8 Wastegate                                  |
| 9 Propeller shaft                   | 10 Cover plate governor (if configuration 3) |



# BRP-Rotax INSTALLATION MANUAL

## ENGINE HANDLING

### ATTENTION

**Do not use the fuel lines or the wiring harness for lifting the engine!**

#### Attachment points

The engine may only be lifted on the dedicated attachment points by using the GENUINE ROTAX® engine lift set and/or a spreader bar with 35 cm (13.78 in) distance between lifting points. Make sure that lifting device does not bend the attachment lugs by relevant force distribution.




Figure 2.3: Attachment points

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK


**BRP-Rotax**  
INSTALLATION MANUAL

**Chapter: 24-00-00**  
**ELECTRICAL POWER**

**TOPICS IN THIS CHAPTER**

<b>System description .....</b>	<b>3</b>
System limitations .....	3
<b>Interface description .....</b>	<b>4</b>
Interface overview .....	4
Electrical interfaces .....	4
Mechanical interfaces .....	9
<b>Installation notes .....</b>	<b>10</b>
Installation overview .....	10
Grounding cables .....	10
Battery .....	11
Control elements .....	12
<b>Validation of installation .....</b>	<b>13</b>

**BRP-Rotax**  
INSTALLATION MANUAL



AE 51S\_0153a

Figure 3.1: Internal power supply

# BRP-Rotax INSTALLATION MANUAL

## SYSTEM DESCRIPTION

For a detailed system description refer to the latest issue of the Operators Manual.

### SYSTEM LIMITATIONS

#### ATTENTION

**Consumer cables must NOT be routed alongside the ignition cables. There is a risk of electromagnetic interference.**


#### Valid installation positions

The Fusebox must not be installed in the cockpit. Installation is only allowed in the engine compartment.

#### Component temperatures limitation

Limitations see Chapter 00-00-00 Approval of electric and electronic components.

The Regulator temperature must be measured as shown within the following figure:



AE 5S\_0003

Figure 3.2: Regulator temperature measurement area TYPICAL

1 Rectifier regulator

2 Component temperature measurement area

#### Separation of EMS and Airframe circuit

A connection between regulator plate A (EMS ground) and airframe ground should only be done during supply of the EMS System by an external power source (e.g. during engine start). Although it would have no impact on the redundancy of the EMS, the fault tolerance of the system will be degraded if the EMS ground is connected permanently with the airframe ground.

# BRP-Rotax INSTALLATION MANUAL

## INTERFACE DESCRIPTION

### INTERFACE OVERVIEW




Figure 3.3: Fusebox connections TYPICAL

- |   |  |   |  |
|---|--|---|--|
| 1 | X1 Connector (electrical interface)      | 2 | X2 Connector (electrical interface)            |
| 3 | X3 Connector (electrical interface)      | 4 | Regulator Plate A (electrical interface)       |
| 5 | Regulator Plate B (electrical interface) | 6 | Fusebox mounting points (mechanical interface) |

### ELECTRICAL INTERFACES

The seals supplied with the Fusebox must be inserted into the X1, X2 and X3 Connector (Fusebox side) to enable a good connection between plug and socket and thus avoid unnecessary vibrations and misalignment of connector pins.


#### **Fusebox –X1, X2 Connector**

The X1 and X2 ensure the power distribution to the EMS System. Both plugs must be connected with mating sockets on the (engine-) wiring harness. The connectors are not interchangeable and are marked on the wiring harness side.

#### **Fusebox–X3 Connector**

For information on the X3 Connector, see the relevant SI-PAC-012.

# BRP-Rotax INSTALLATION MANUAL



AE 5iS\_0372

Figure 3.4: X3-Connector: Fusebox side

- 1 Terminal 1
- 2 Terminal 2
- 3 Terminal 3

Terminal 1 enables the EMS to be supplied with an external power source (e.g. in case the internal power supply fails supplying the EMS). Terminal 2 enables powering the EMS during engine start (until the engine speed is high enough that the internal generator is able to supply the EMS). Terminal 3 can be used for supplying the Airframe with electrical energy after generator A has taken over powering the EMS.

Terminal	Interface Parameter	Min.	Max.	Nominal
1	Input voltage:	9 V <sup>2</sup>	14.5 V	12 V
	Input load:		230 W DC cont. 290 W DC peak	
2	Input: voltage:	9 V	14.5 V	12 V
	Input load:		230 W DC cont. 290 W DC peak	
3	Output voltage:	13.9 V	14.5 V	12 V
	Output capacity:		max. 420 W DC (at 20°) (68 °F) see section <a href="#">performance diagram</a>	

- 
- 2. This limit must also be considered when the starter motor is actuated

# BRP-Rotax INSTALLATION MANUAL

## ATTENTION

In failure conditions the output voltage can exceed the specified limits.

The following measurement is taken at an oil temperature of 135 °C (275 °F).





Figure 3.5: Characteristic curve of internal generators



# BRP-Rotax INSTALLATION MANUAL

## Fusebox Regulator A

The regulator plate A needs to be connected with the EMS Ground (ring terminals on the (engine-) wiring harness). The stud has M4 threads suitable for ring terminals according to DIN 46225 or MS25036– 149 (size #8) (tightening torque: 1.2 Nm). The ring terminals need to be evenly spread onto the three available studs.



AE 5180002

Figure 3.6: Fusebox -Regulator A

- 1 Regulator
- 3 Ground studs

- 2 Regulator plate A


### ATTENTION

**A connection between regulator plate A and airframe ground should only be done during supply of the EMS System by an external power source (e.g. during engine start).**

# BRP-Rotax INSTALLATION MANUAL

## Fusebox Regulator B

The Regulator B needs to be connected with the Airframe Ground. The stud has M6 threads suitable for ring terminals according to DIN 46225 or MS25036 (1/4" PIDG) (tightening torque: 5.9 Nm).



AE 5IS0003

Figure 3.7: Fusebox -Regulator B – TYPICAL

- 1 Regulator
- 2 Regulator plate B
- 3 Ground terminals




Figure 3.8: Fusebox – Regulator B with Amphenol connector

- 1 Connector Regulator A
- 2 Amphenol connector Regulator B

# BRP-Rotax INSTALLATION MANUAL

## MECHANICAL INTERFACES

Fusebox mounting points




Figure 3.9: Fusebox –Connections and dimensions – TYPICAL

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES

### General


The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

## INSTALLATION OVERVIEW

### Wiring diagram



AE 5iS\_0160

Figure 3.10: Wiring diagram

## GROUNDING CABLES

The wiring of the grounding cables is an essential point when conducting engine electronics. Following two circuits must be distinguished:

- Airframe circuit
- Engine management system circuit (EMS circuit)

During engine start (dynamic condition, transient), the two circuits are connected to each other.

# BRP-Rotax INSTALLATION MANUAL

When the engine is running or when the engine is turned off ( and the Fusebox is not supplied with external power), the EMS circuit works isolated from the rest of the aircraft. Therefore, the following components need to be installed decoupled from the airframe ground:

- ECU
- Regulator A (Fusebox)
- Starter relay

The engine block must be connected to the airframe using a properly sized ground strap (minimum the same cable cross section as the starter supply but at least 10 mm<sup>2</sup>), for carrying the starter current and to avoid static electricity between the engine and the airframe.

To gain full lightning strike compliance the shock mounts must be shorted-out by using ground straps (10 mm<sup>2</sup>).

## BATTERY

### ATTENTION

**The use of rechargeable batteries with lithium-ion technology should only be used in combination with a suitable battery management system. If such a battery is used, the responsibility is up to the aircraft manufacturer. The approval of the relevant aeronautical authority may be necessary. For installation of lithium-ion batteries refer e.g. to FAA AC No: 20-184**

The specification of the battery must ensure that during each operating state and also during the transition between two operation states a sufficient supply of the avionics is guaranteed (e.g. during engine start). Depending on the applicable regulations avionics need to be supplied for at least 30 minutes with energy after a failure of the primary power supply in case they are required for safe operation of the aircraft.

If the aircraft is regularly started at temperatures below - 5 °C (23 °F) (ambient- and oil/coolant temperature are below this temperature) it is recommended to provide a connection for an external power supply and a possibility for adequate engine pre-heating.

### ATTENTION

**If all consumers are active, take care not to discharge the battery deeply.**

Following battery specifications are recommended:

Interface Parameter	Min.	Max.	Nominal
Nominal Input Voltage			12 V
Internal resistance		maximal 10 mΩ at -18 °C (-0.4 °F)	

## BRP-Rotax INSTALLATION MANUAL

Interface Parameter	Min.	Max.	Nominal
Cold Cranking Ampere	350 A at -18 °C (-0.4 °F) (SAE J537)		
Capacity	16 Ah		

The usage of a battery with lower capacity may have a negative impact on the starting behavior of the engine. Additional electrical loads, which are in some cases required by law, may affect the battery performance during the starting process, (e.g. ACL (Anti Collision Light), Navigation Light, Avionics).

### CONTROL ELEMENTS

START POWER SWITCH	Requirement
Switch type	Toggle-SPST (non lockable)
Nominal voltage	28 V DC
Nominal current	20 A
Number of poles	2-pole

BATTERY BACKUP SWITCH	Requirement
Switch type	Toggle (but with mechanical interlock to prevent switch on during standard operation)
Nominal voltage	28 V DC
Nominal current	20 A
Number of poles	2-pole

# BRP-Rotax INSTALLATION MANUAL

## VALIDATION OF INSTALLATION

### General

The validation procedures described in this chapter do not claim to be complete. The correct execution and compliance with all given system limitations and interface descriptions as well as with standards and norms given by authorities must be proven by the aircraft manufacturer.

### External Power Supply


If an engine is installed in a specific aircraft type for the first time, it is required to measure the voltage on three positions:

- Battery Voltage (separate Voltmeter)
- Voltage on Electric Starter (separate Voltmeter)
- ECU Bus Voltage (displayed in BUDS Aircraft diagnostic tool)

Depending on the geographical location where the engine should be used, this measurement must be done at the lowest reachable ambient temperature. In case the measured voltages drop below 9 V especially during engine start, the installation is insufficient. In this case specification of the external power source, the execution of the wiring as well as the total consumption of all electrical loads needs to be checked.

### Separation of EMS and Airframe circuit

Proof the continuity between Fusebox Regulator A and Fusebox Regulator B in static condition (Fusebox is not supplied with power by an external power source). To determine the ECU BUS voltage at the transient moment of the engine start an oscilloscope must be used and also the total consumption of all electrical loads needs to be checked.



AE 5IS\_0155

Figure 3.11: Validation of EMS and Airframe Circuit separation

- |   |  |   |   |
|---|--|---|---|
| 1 | Multimeter                             | 2 | Rectifier regulator A (black connector) |
| 3 | Rectifier regulator B (grey connector) | 4 | Ground connections regulator A          |
| 5 | Ground connections regulator B         |   |   |

In case of continuity the installation is not sufficient and the wiring concept needs to be revised.

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK



**BRP-Rotax**  
INSTALLATION MANUAL


**Chapter: 61-00-00**  
**PROPELLER DRIVE**

**TOPICS IN THIS CHAPTER**

**System description** .....3  
    System limitations .....3

**Interface description** .....4  
    Interface overview .....4  
    Mechanical interfaces .....6  
    Hydraulic governor for constant speed propeller .....8

**BRP-Rotax**  
INSTALLATION MANUAL



AE 5iS\_0156

Figure 4.1: Propeller drive – TYPICAL

**BRP-Rotax**  
**INSTALLATION MANUAL**

**SYSTEM DESCRIPTION**

For a detailed System description refer to the latest issue of the Operators Manual.

**SYSTEM LIMITATIONS**

**Operating limits** Refer to latest issue of the Operators Manual.

<b>Moment of inertia</b>	<b>System Limit</b>	<b>Min.</b>	<b>Max.</b>
	Moment of inertia on propeller	1500 kg cm <sup>2</sup> (3.559 lb ft <sup>2</sup> )	7500 kg cm <sup>2</sup> (18.238 lb ft <sup>2</sup> )

**Out of balance** Dynamic balancing of the propeller as specified by the propeller manufacturer must be carried out.


<b>Propeller shaft</b>	<b>System Limit</b>	<b>Min.</b>	<b>Max.</b>
	Extension of the propeller shaft	-	maximal 70 mm (2.75 in.)

<b>Hydraulic governor flange/drive/oil supply</b>	<b>System Limit</b>	<b>Min.</b>	<b>Max.</b>
	Power consumption of governor	-	600 W
	Operating pressure of governor	-	10 bar (145 psi) peak pressure: 30 bar (435 psi)

**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**



AE 5iS\_0721


Figure 4.2: Interface (configuration 3)

- 1 Propeller shaft (mechanical. Interface)
- 2 Governor flange (hydraulic. Interface)
- 3 Cover plate

**NOTE**

*The cover used for delivery needs to be removed before engine operation. The cover may not be used in operational condition.*

**BRP-Rotax**  
INSTALLATION MANUAL



AE 5iS\_0720

Figure 4.3: Interface (configuration 2)

1 *Propeller shaft (mechanical. Interface)*

# BRP-Rotax INSTALLATION MANUAL

## MECHANICAL INTERFACES

### Propeller shaft flange

The propeller in tractor or pusher arrangement must be fitted on the propeller flange in accordance with applicable regulations. As required utilize one of three possible pitch circle diameters (P.C.D.) on the flange.

**ATTENTION**  
Modification of the propeller shaft is not permitted.





Figure 4.4: Propeller shaft flange

Interface Parameter	Value
Pitch circle diameter 75 mm (2.95 in.)	6x through holes 8 mm (0.31 in.)
Pitch circle diameter 80 mm (3.15 in.)	6x through holes 11.5 mm (0.45 in.)
Pitch circle diameter 101.6 mm (4 in.)	6x through holes 13mm (0.51 in.)

# BRP-Rotax INSTALLATION MANUAL

Interface Parameter	Value
Hub diameter	47 mm (1.85 in.)
Gear transmission	$i=2.54$ . Propeller shaft turns with 0.395 times engine speed.




AE 5IS\_0143a

Figure 4.5: Direction of rotation

BRP-Rotax  
INSTALLATION MANUAL

HYDRAULIC GOVERNOR FOR CONSTANT SPEED PROPELLER



AE 5IS0105

Figure 4.6: Governor flange (configuration 3 only)

- |                   |                           |
|-------------------|---------------------------|
| 1 Governor flange | 2 Pressure oil line assy. |
| 3 Oil inlet       | 4 Oil outlet              |



# BRP-Rotax INSTALLATION MANUAL

## Drive

Drive via propeller gearbox.

Position of the propeller connection on the governor flange:

x-axis [mm/in]	y-axis [mm/in]	z-axis [mm/in]
-206.3 (-8.12)	0	51.5 (2.03)

## Connection

### ATTENTION

**Obey the manufacturers instructions!**

## Technical Data

Gear ratio from crankshaft to hydraulic governor is 1.932, i.e. the propeller governor runs at 0.759 times engine speed.

<b>Mounting pad</b>	AND20010
<b>Thread size</b>	M8
<b>Thread length</b>	max. 14 mm (0.55 in)
<b>Toothing</b>	Internal spline 20/40 SMS 1834 NA 14x1,27x30x12
<b>Power input</b>	max. 600 W
<b>Operating pressure</b>	max. 30 bar (435 psi)

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK


**BRP-Rotax**  
INSTALLATION MANUAL

**Chapter: 72-00-00**  
**ENGINE**

**TOPICS IN THIS CHAPTER**

<b>System description</b> .....	<b>3</b>
System limitations .....	6
<b>Interface description</b> .....	<b>9</b>
Interface overview .....	9
Mechanical interfaces .....	9
<b>Installation notes</b> .....	<b>12</b>
Engine suspension .....	12

**BRP-Rotax**  
**INSTALLATION MANUAL**



AE 515\_0158

Figure 5.1: Engine – TYPICAL

# BRP-Rotax INSTALLATION MANUAL

## SYSTEM DESCRIPTION

For a detailed System description refer to the latest issue of the Operators Manual.





Figure 5.2: Engine side view

- |                              |  |
|------------------------------|--|
| 1 Engine number              | 2 Propeller flange                                 |
| 3 Propeller gearbox          | 4 Connection for return line, both sides mandatory |
| 5 Connection for return line | A Attachment points (for engine lifting)           |
| Z Center of gravity (Z)      | P Reference coordinate system (X, Y, Z)            |

# BRP-Rotax INSTALLATION MANUAL




AE 5S\_0161

Figure 5.3: Engine Front view

- |    |   |    |  |
|----|---|----|--|
| 6  | <i>Oil filter</i>                           | 7  | <i>Oil pump</i>                          |
| 8  | <i>Exhaust flange</i>                       | 9  | <i>Muffler assy.</i>                     |
| 10 | <i>Fuel line assy.</i>                      | 11 | <i>Crankshaft locking screw position</i> |
| 12 | <i>Connection for Turbo oil line return</i> | 13 | <i>Wastegate regulator assy.</i>         |
| 14 | <i>Wastegate rod end</i>                    |    |  |

# BRP-Rotax INSTALLATION MANUAL



AE 5IS\_0162

Figure 5.4: Top view

- |    |                                 |    |  |
|----|---------------------------------|----|--|
| 15 | Throttle valve support assy.    | 16 | Airbox                                 |
| 17 | Dual ignition coils             | 18 | Expansion tank assy.                   |
| 19 | Fuel rail (right, left)         | 20 | POP OFF valve                          |
| 21 | Inter cooler                    | 22 | Connection for fuel feed line          |
| 23 | Connection for fuel return line | A  | Attachment points (for engine lifting) |

# BRP-Rotax INSTALLATION MANUAL




Figure 5.5: Rear view

- |                            |   |
|----------------------------|---|
| 24 Ignition housing        | 25 Electric starter                     |
| 26 Water pump housing      | 27 Engine suspension frame (ring mount) |
| 28 Turbocharger assy.      | 29 Pressure control valve (PCV)         |
| 30 Fuel pressure regulator |   |

## SYSTEM LIMITATIONS

**Operating limits** Refer to latest issue of the Operators Manual.


**Installation position** The oil system, fuel system and the cooling system are unsuitable for upside-down / inverted installation of the engine.

System Limit	Min.	Max.
Static roll angle $\beta$		40°

The oil level should be in the upper half (between the “50%” and the “Max.” mark) and should never fall below the “Min.” mark. For the oil level measuring procedure refer to the latest version of the respective operators manual.



# BRP-Rotax INSTALLATION MANUAL



AE 5IS\_0164


Figure 5.6: Bank angle

Angle/force	Description
$\alpha$	Bank or rotation
F1	Gravity

## Attachment points

For mounting the engine on the engine suspension, R2, R3, L3 and L2 of attachment points must be used. Attachment bolts/screws must not protrude into engine components.

# BRP-Rotax INSTALLATION MANUAL



AE 5iS\_0165

Figure 5.7: Propeller and vertical axis

## Propeller axis

The y1-axis must be perpendicular to the longitudinal axis of the aircraft.

System Limit	Min.	Max.
Permissible deviation from perpendicular ( $\alpha$ )	- 10°	+ 10°

**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**




Figure 5.8: Attachment points

**MECHANICAL INTERFACES**

**Attachment points**

Interface Parameter	Value			
Attachment points	L2	R2	L3	R3
<b>x-axis</b> (in)	615 mm (24.21 in.)			
<b>y-axis</b> (in)	105 mm (4.13 in.)	-105 mm (-4.13 in.)	105 mm (4.13 in.)	-105 mm (-4.13 in.)
<b>z-axis</b> (in)	-277 mm (-10.9 in.)	-277 mm (-10.9 in.)	-7 mm (0.28 in.)	-7 mm (0.28 in.)

# BRP-Rotax INSTALLATION MANUAL

## ⚠ WARNING

### Non-compliance can result in serious injuries or death!

The aircraft or fuselage manufacturer must design the engine suspension so that it can safely carry the maximum occurring operational loads without exceeding the max. allowable forces and bending moments on the engine housing and attachment points. Tighten all engine suspension screws as specified by the aircraft manufacturer.

## Weight

Engine component	Weight
<b>Base engine with gearbox:</b>	74.23 kg (173.5 lb)
Cooling air baffle	0.38 kg (0.838 lb)
PCV	0.35 kg (0.771 lb)
Oil tank	1.50 kg (3.31 lb)
Intercooler	1.65 kg (3.65 lb)
ECU	1.13 kg (2.49 lb)
Fusebox	2.02 kg (4.45 lb)
Ambient sensors	0.06 kg (0.132 lb)
Wiring harness	2.50 kg (5.51 lb)
Intermediate flange with overboost valve, air hose and clamps	0.78 kg (1.72 lb)

## Centre of gravity of engine

The position information of the center of gravity does only consider the engine itself. Parts without an specific installation position in relation to the reference coordinate system are not considered.

### NOTE

*All distances are given in relation to the reference coordinate system (P).*

Axis	Center of gravity
X-axis	376 mm (14.80 in.)
Y-axis	- 15.9 mm (-0.63 in.)
Z-axis	- 115.9 mm (-4.56 in.)

**BRP-Rotax**  
INSTALLATION MANUAL

**Moments of inertia (relative to COG)**

<b>Axis</b>	<b>Moment of inertia</b>
X-axis	$2.0020282 \cdot 10^6 \text{ kg} \cdot \text{mm}^2$
Y-axis	$2.5397901 \cdot 10^6 \text{ kg} \cdot \text{mm}^2$
Z-axis	$2.9713711 \cdot 10^6 \text{ kg} \cdot \text{mm}^2$

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES

### General

The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

### ENGINE SUSPENSION

#### ATTENTION

**During engine installation take into account the total engine weight and ensure careful handling.**

The rubber mounts for neutralizing vibrations and other engine suspension components are not in the scope of delivery. Those components must be designed, selected and tested on vibration behavior during ground runs and flight testing at specified loads.

#### ATTENTION

**The engine suspension must be designed to prevent excessive engine movement and to minimise noise emission and vibration on the airframe.**

The engine suspension is determined essentially by the aircraft design. Four attachment points are provided on the engine suspension frame assy.

The engine will be supplied with a well tried and certified suspension frame for attachment on the fireproof bulkhead. The exhaust system and the turbo charger are supported on this frame, too. The installation into the aircraft is as generally practised by captive rubber mounts which ensure also to reduce vibrations and sound transmission from engine to aircraft frame.

# BRP-Rotax INSTALLATION MANUAL

## ⚠ WARNING

The hex. screws M10x60 on the attachment points R2 and L2 are only used for transport securing but must never be utilized for engine suspension. See interface overview. Therefore, use the ROTAX engine suspension frame and the 4 stated attachment points R2, L2, R3, L3.




Figure 5.9: Damping element engine suspension

Standard aircraft industry damping elements (e.g. Lord) are suitable and need to be chosen according to the aircraft specific design requirements. Check with the relevant equipment manufacturer.

The vibration and acoustic insulation factor depends on the airframe.

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK



**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: 72-60-00**  
**AIR INTAKE SYSTEM**


**TOPICS IN THIS CHAPTER**

**System description** ..... **3**  
    System limitations ..... 3

**Interface description** ..... **5**  
    Interface overview ..... 5  
    Mechanical interfaces ..... 6  
    Pneumatic interfaces ..... 7  
    Electrical interfaces ..... 9

**Installation notes** ..... **10**  
    Installation overview ..... 10

**BRP-Rotax**  
INSTALLATION MANUAL



AE 51S\_0148b

Figure 6.1: Air intake system

# BRP-Rotax INSTALLATION MANUAL

## SYSTEM DESCRIPTION

For a detailed System description refer to the latest issue of the Operators Manual.

### SYSTEM LIMITATIONS

#### Air intake

Following requirements may be used:

System Limit	Min.	Max.
Flow rate	400 kg/h	
Pressure loss (between ambient pressure and altitude pressure 975 mbar / 14.14 psi at ISA conditions)		10 mbar (0.14 psi)

Icing in the area of the air intake needs to be avoided. The prevention of icing lies within the aircraft manufacturer's responsibility.

#### Airbox reference pressure

The reference pressure of the fuel system is the airbox pressure.

#### Air intake ducting

The air intake ducting must not be changed in any case (connection between Intercooler and overboost valve, between Turbocharger and Intercooler, between Overboost valve and throttle).

System Limit	Min.	Max.
Intake pressure loss (Engine Speed: 5500 ±50 rpm; Airflow: 360-366 kg/min)		85 mbar (1.23 psi)
Intake pressure loss (Engine Speed: 5800 ±50 rpm; Airflow: 384-396 kg/min)		90 mbar (1.30 psi)

#### PCV ducting

All pneumatic connections leading from and to the Pressure Control Valve (PCV) may not be changed. Changes in length and diameter of the connections will have a significant effect on the wastegate control. Depending on the installation heat protection must be provided.

System Limit	Min.	Max.
Bending radius on tube centerline	60 mm	

#### Valid installation positions

The intercooler as well as the PCV must be installed vibration-decoupled from the engine.

#### Compressor housing

The turbo compressor housing must not be rotated. The wastegate functionality can be affected.

# BRP-Rotax INSTALLATION MANUAL

## Throttle lever

Adjust Bowden cable such that throttle valve can be fully opened and closed. Use Bowden cable with minimized friction so that the return spring on the throttle valve can open the throttle valve completely.

### NOTE

*It is not recommended to install a throttle limiter. With the installation of a throttle limiter, the engine can not reach its nominal power.*

### **⚠ WARNING**

#### **Non-compliance can result in serious injuries or death!**

With throttle lever not connected the throttle valve will remain fully open. The starting position of the throttle valve is therefore full throttle! Therefore never start the engine without connecting the throttle lever first.

### **⚠ WARNING**

#### **Non-compliance can result in serious injuries or death!**


The cable actuations being used must not be affected at all by vibrations emanating from the engine or the airframe.

BRP-Rotax  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**

**Interface  
overview**



AE 5IS\_0148a

Figure 6.2: Air intake: Interface overview and components

- |   |  |   |   |
|---|--|---|---|
| 1 | <i>Turbocharger inlet (pneumatic Interface)</i>            | 2 | <i>Air intake hose (POP OFF valve to throttle body)</i> |
| 3 | <i>Turbocharger</i>  | 4 | <i>Intercooler</i>                                      |
| 5 | <i>POP OFF valve</i>                                       | 6 | <i>Throttle body (mechanical interface)</i>             |
| 7 | <i>Pressure control valve (PCV) (electrical interface)</i> | 8 | <i>Wastegate (boost pressure valve)</i>                 |

# BRP-Rotax INSTALLATION MANUAL

## MECHANICAL INTERFACES

**Pressure control valve (PCV)**

Interface Parameter	Min.	Max.
Tightening torque	—	1 Nm (9 in. lb)

**Pressure control valve (PCV)**




Figure 6.3: PCV: Connection and dimensions

**Throttle body**

Interface Parameter	Min.	Max.
Tightening torque	4 Nm (35 in. lb) (suitable for flexible cable), 1.5 mm (0.06 in.) steel rope or single-strand wire	—
Cable travel	65 mm (2.56 in.)	—
Actuating force	7.5 N (1.69 lbs.)	20 N (4.5 lbs)
Max. permissible actuating force	—	20 N (4.5 lbs)

**Connection:** Set screw M6x12 mm

# BRP-Rotax INSTALLATION MANUAL

## Intercooler




Figure 6.4: Intercooler: Connection and dimensions

To attach the intercooler within the airframe design four suitable fixation points are available and M6 screws must be used.

**ATTENTION**

**Make sure proper dampening of the 4 fixation points and assure stressfree installation on these 4 fixation points.**

## PNEUMATIC INTERFACES

### Airfilter connection

See figure Connection on turbocharger

Interface Parameter	Min.	Max.
Slip-on length	30 mm (1.18 in.)	-

# BRP-Rotax INSTALLATION MANUAL

## NOTE

*Use only filter elements which will not tend to restrict the flow when in contact with water.*

### Turbocharger to intercooler

#### Connection on turbocharger:

Interface Parameter	Min.	Max.
Slip-on length	30 mm (1.18 in.)	-




Figure 6.5: Connection on turbocharger



# BRP-Rotax INSTALLATION MANUAL


## Connection on intercooler:

Interface Parameter	Min.	Max.
Slip-on length	32 mm (1.26 in.)	-

See [Figure 6.3: Intercooler: Connection and dimensions](#)

## Intercooler to POP OFF valve

Interface Parameter	Min.	Max.
Slip-on length	18 mm (0.71 in.)	



AE 5IS\_0374

Figure 6.6: POP OFF valve

**Connection on throttle body:** Install the delivered hose (scope of supply) to the correct side of the POP OFF valve, recheck if it fits.

## ELECTRICAL INTERFACES

### PCV sockets

The appropriate connectors on the wiring harness as well as the corresponding sockets on the PCV are color coded.  
To avoid inappropriate behavior of the wastegate the correct linkage needs to be ensured.

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES

### General

The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

### INSTALLATION OVERVIEW

#### Pneumatic diagram




Figure 6.7: Pneumatic diagram

#### Connection between compressor outlet and intercooler

Temperature-resistant hoses must be used.


**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: 73-00-00**  
**ENGINE – FUEL AND CONTROL**

**TOPICS IN THIS CHAPTER**

<b>System Description .....</b>	<b>3</b>
System limitations .....	3
<b>Interface description .....</b>	<b>4</b>
Interface overview .....	4
Hydraulic interfaces .....	5
Electrical interfaces .....	5
Mechanical interfaces .....	6
<b>Installation notes .....</b>	<b>7</b>
Installation overview .....	8
Fuel lines .....	9
Inlet line .....	9
Return line .....	9
Bypass line .....	9
Coarse filter .....	10
Water trap, gascolator .....	10
Fine filter .....	10
Fuel pump .....	11
Fuel pressure sensor .....	11
Fuel pressure regulator .....	11
Fuel tank .....	11
Fuel shut off valve .....	12

**BRP-Rotax**  
INSTALLATION MANUAL



AE 5iS\_0171

Figure 7.1: Fuel System

**BRP-Rotax**  
INSTALLATION MANUAL

**SYSTEM DESCRIPTION**

For a detailed System description refer to the latest issue of the Operators Manual.


**SYSTEM LIMITATIONS**

**Operating limits** Refer to latest issue of the Operators Manual.

**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**



AE 5IS\_0172

Figure 7.2: Fuel System: Interface overview and components

- |   |  |   |  |
|---|--|---|--|
| 1 | <i>Fuel rail 2/4 outlet line (hydraulic Interface)</i> | 2 | <i>Fuel rail 1/3 feed line (hydraulic Interface)</i> |
| 3 | <i>Fuel rail</i>                                       | 4 | <i>Fuel line assy.</i>                               |
| 5 | <i>Injection valves</i>                                | 6 | <i>Fuel pump connectors (electrical interface)</i>   |
| 7 | <i>Banjo bolt</i>                                      |   |  |

# BRP-Rotax INSTALLATION MANUAL

## HYDRAULIC INTERFACES

### Fuel inlet

Interface Parameter	Min.	Max.
Fuel pressure (relative to MAP)	2.9 bar (42 psi)	3.1 bar (45 psi)
Acceptable Fuel pressure exceedance (max. 3 sec.)	2.5 bar (36 psi)	3.5 bar (51 psi)
<b>NOTE</b> <i>Fuel pressure exceedance only allowed after power setting change</i>		
Fuel pressure oscillation (min. sample rate 20 kHz)	-	1.0 bar (14.5 psi), peak-to-peak
Fuel flow	56 l/h (14.8 gal/h)	120 l/h (31.7 gal/h)
Fuel quality	EN 228	-

### Filter quality

#### NOTE

*Nominal rating 5 µm, minimum 82 % capture efficiency according to ISO 19438 (edition 11/2003), dirt particles > 35 µm are not permissible.*

#### ATTENTION

**Independent from the ambient conditions (e.g. fuel pressure and temperature) and independent from the used fuel the design of the fuel system must prevent vapour lock conditions. Vapour lock may result in engine stoppage.**

**Connection:** M14x1.5 or AN-6 (9/16-18 UNF).

### Fuel outlet

Interface Parameter	Min.	Max.
Fuel pressure (relative to Fuel Tank pressure)	-	0.5 bar (7.3 psi)

**Connection:** M14x1.5 or AN-6 (9/16-18 UNF).

## ELECTRICAL INTERFACES

### Fuel pump connectors

Interface Parameter	Min.	Max.	Nominal
Output Voltage (V)	12 V	14.5 V	13.8 V
Output Current (A)	-	5 A	-

# BRP-Rotax INSTALLATION MANUAL

## MECHANICAL INTERFACES

### Banjo bolt adapter

Standard banjo bolt can be replaced by an optional Sensor adapter for connectivity directly on the fuel inlet of the fuel pressure regulator.

Interface Parameter	Min.	Max.
Tightening torque	23 Nm (17 ft. lb)	27 Nm (20 ft.lb)
Component mass (adapter with sensor)	-	80 g

**Connection:** M12 x 1.5



**BRP-Rotax**  
INSTALLATION MANUAL

**INSTALLATION NOTES**

**General**



The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION OVERVIEW



AE 5IS\_0173

Figure 1.3: Fuel system

- |                           |                            |
|---------------------------|----------------------------|
| 1 Fuel tank               | 2 Fuel pump 1              |
| 3 Fuel pump 2             | 4 Fine filter              |
| 5 Fuel pressure regulator | 6 Coarse filter/water trap |

# BRP-Rotax INSTALLATION MANUAL

## FUEL LINES

To prevent problems with vapour lock, all the fuel lines should be insulated against heat in the engine compartment. It is recommended to route the fuel lines in an appropriate distance from hot engine components and avoid sharp bends.

For a better heat dissipation it is recommended to use fuel lines made of metal whenever practicable (except for flex hoses to/ from engine).

Fuel lines should be installed by using suitable screw clamps or by ferrules.

Non drainable low points in feed, return and vent lines should be avoided. Any low points should allow for drainage of water and other contaminants.

### **⚠ WARNING**

**Non-compliance can result in serious injuries or death!**

At the low points, accumulations of water can freeze and cut of the fuel flow.

## INLET LINE

The inlet line should have an inner diameter of at least 7.5 mm (0.3 in). (AN-6 or 3/8").

### **ATTENTION**

Fuel lines smaller than this diameter may have a significant impact on the proper functionality of this engine.

## RETURN LINE

The return line should have a inner diameter of at least 7.5 mm (0.3 in). (AN-6 or 3/8").

### **ATTENTION**

Fuel lines smaller than this diameter may have a significant impact on the proper functionality of this engine.

Vapour locks in the return line should be efficiently vented out of the fuel system to the atmosphere. Adequate fuel tank venting system design is imperative. Large vent lines with (most) direct routing avoiding low points are desired.

## BYPASS LINE

To allow venting of the fuel system after a potential inclusion of air, there could be installed a restricted bypass line between the inlet (pressure side of the fuel pump module) and the return line. In this bypass line a restricted jet should be installed so that there is an ideal balance between short venting time and minimum fuel flow rate. The positioning and dimensioning of the jet is up to the aircraft manufacturer.

If no bypass line is installed, the pressure release in the fuel lines is very slow. This should be noted accordingly in the manuals of the aircraft manufacturer (fuel lines are possibly under full operating pressure even after engine stop).

# BRP-Rotax INSTALLATION MANUAL

## NOTE

*The switching between several fuel tanks at power loss due to fuel shortage should be given within a defined period of time and without falling below the minimum performance limit and must be ensured by the aircraft manufacturer. Refer to the latest requirements such as FAR or EASA.*

## COARSE FILTER

The coarse filter should be installed at an easily accessible position to allow a periodic inspection.

Following fuel filter could be used to ensure that the engine is supplied with fuel of an adequate quality:

Interface Parameter	Min.	Max.
Filter mesh size	50 micron (0.0019 in.)	70 micron (0.0027 in.)
Filter surface (total)	64.4 cm <sup>2</sup> (10 in <sup>2</sup> )	-
Passing area	18.4 cm <sup>2</sup> (2.85 in <sup>2</sup> )	-

The filter should be installed in the supply line between the tank and the fuel pumps and should be of sufficient capacity to prevent complete blockage between maintenance intervals.

### ATTENTION

An installation without coarse filter may have a significant impact on the proper functionality of this engine.

## WATER TRAP, GASCOLATOR

A suitable water trap must be installed. Certification according to the latest regulations, such as FAR or EASA, must be conducted by the aircraft or fuselage manufacturer.

## FINE FILTER

The fine filter should be installed at an easy accessible position to allow a periodic inspection. To ensure that the engine is supplied with fuel of an adequate quality, a fine filter with following specifications should be installed between the fuel pumps (module) and the injection rail (Cylinder 1/3):

Interface Parameter	Min.	Max.
Filter mesh size	8 micron	12 micron
Fuel flow rate	90 l/h (23.8 gal/h)	-
Differential pressure		0.02 bar (0.29 psi)

# BRP-Rotax INSTALLATION MANUAL

## ATTENTION

An installation without fine filter may have a significant impact on the proper functionality of this engine.

## FUEL PUMP

For reducing the risk of vapor lock, the fuel pump should be placed in a well-ventilated area. A recommended installation position would be near the fuel tank in order to ensure a safe fuel supply.

## FUEL PRESSURE SENSOR

The operating limit of the fuel pressure should be observed at the inlet of the fuel pressure regulator.

An additional fuel pressure sensor could be placed before the fine filter, so the filter load can be checked. An increase of fuel pressure over the allowed limit could mean that the fine filter is becoming contaminated. The fine filter should be checked and replaced if necessary.

## FUEL PRESSURE REGULATOR

Fuel pressure regulators have very precise tolerances and are generally reliable. Mostly pressure fluctuations are not caused by the pressure regulator, they might be found in other sections (filter clogged, pulsation of lines, kinks in the hoses etc.) of the fuel system.

## FUEL TANK

In case of supply problems of the fuel pump, the fuel tank should be emptied and filled with AVGAS. If the problem does not occur at the next test (with AVGAS), then this is a sign of formation of vapour locks when using MOGAS (or auto fuel).

Following points may have a positive impact on the proper functionality of this engine:

- Single tank (large volume of fuel in the tank, just a few fuel lines)
- Catch tanks in the wing tanks. This provides the fuel supply in every flight situation/ position
- Header tank (the following reference values should be considered):

Interface Parameter	Specification
Venting line	The venting line from header tank to wing tank should generally be on an incline to avoid trapping bubbles. The venting line must have an inner diameter of at least 12 mm (0.50 in).
Feed lines	Fuel feed lines from the wing tanks to the header tank should be on a steady decline.

# **BRP-Rotax**

## **INSTALLATION MANUAL**

Following points may have a negative impact on the proper functionality of the engine:

- A header tank design that enables the re-entry of vapour bubbles in the suction line
- Multi tank system without catch-, header tank

### **FUEL SHUT OFF VALVE**

The fuel shut off valve position on the pressure side of the fuel system (after the fuel pump module) can have an unfavorable impact on the installation of the 915 i.

**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: 75-00-00**  
**COOLING SYSTEM**

**TOPICS IN THIS CHAPTER**


**System Description .....3**  
    System limitations .....3

**Interface description .....4**  
    Interface overview .....4  
    Hydraulic interfaces .....5  
    Air Cooling interfaces .....7

**Installation notes .....9**  
    Installation overview .....9  
    Water inlet elbow .....9  
    Expansion tank .....10  
    Coolant hoses .....10  
    Coolant .....11

**Validation of installation .....12**

**BRP-Rotax**  
**INSTALLATION MANUAL**



AE5IS\_0174

Figure 8.1: Cooling System



# BRP-Rotax INSTALLATION MANUAL

## SYSTEM DESCRIPTION

For a detailed System description refer to the latest issue of the Operators Manual.

### SYSTEM LIMITATIONS

**Operating limits** Refer to latest issue of the Operators Manual.

#### **⚠ WARNING**

##### **Non-compliance can result in serious injuries or death!**

The cooling system must be designed so that operating temperatures will not exceed the maximum values.

**Coolant types** It is important that the coolant circuit is designed so that the coolant does not reach boiling point under any conditions. If the temperature exceeds the boiling point, the engine can quickly overheat due loss of coolant.

The boiling point of the coolant is mainly influenced by:

- the type of coolant
- mixture ration (percentage water rate)
- the system pressure (opening pressure of radiator cap)

For permissible coolant types see SI-915i-001, latest issue.

**System pressure**

System Limit	Min.	Max.
Coolant system pressure	–	1.2 bar (18 psi)

**Hose connect-  
ing expansion  
tank to over-  
flow bottle**

System Limit	Min.	Max.
Able to withstand heat and vacuum without collapsing-able	125 °C (257 °F)	–

A soft walled hose is not suitable as it can collapse and cause cooling system failure.

**Expansion tank**

To ensure proper operation of the cooling system, the expansion tank with pressure cap in the main operating systems must be installed on the highest point of the cooling circuit.

**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**




Figure 8.2: Cooling System – Interfaces


- |   |   |   |   |
|---|---|---|---|
| 1 | Coolant hose                                    | 2 | Water pump housing                      |
| 3 | Expansion tank                                  | 4 | Radiator cap                            |
| 5 | Expansion tank connection (hydraulic Interface) | 6 | Water inlet elbow (hydraulic Interface) |
| 7 | Water outlet (hydraulic Interface)              | 8 | Coolant temperature sensor              |
| 9 | Cooling air baffle                              |   |   |

# BRP-Rotax INSTALLATION MANUAL

## HYDRAULIC INTERFACES

### Water inlet elbow

Interface Parameter	Min.	Max.
Cooling system pressure (relative)	1.6 bar (23 psi)	-
Cooling water temperature	- 20 °C (- 4 °F)	125 °C (257 °F)
Cooling water flow (at 5800 rpm)	70 l/min (18.49 USgal/min)	-
Slip on length	19 mm (0.75 in)	



AE 5IS\_0375

Figure 8.3: Water inlet elbow

**Connection:** Outer diameter 27 mm (1.07 in).

### Water outlet


Interface Parameter	Min.	Max.
Cooling system pressure (relative)	1.6 bar (23 psi)	-
Cooling water temperature	- 20 °C (- 4 °F)	130 °C (266 °F)
Cooling water flow (at 5800 rpm)	70 l/min (18.49 USgal/min)	-

# BRP-Rotax INSTALLATION MANUAL

**Connection:** Inner diameter 25 mm (0.98 in).

**Expansion tank connection**

Interface Parameter	Min.	Max.
Slip on length	18 mm	



AE 5iS\_0376

Figure 8.4: Expansion tank connection

# BRP-Rotax INSTALLATION MANUAL

## AIR COOLING INTERFACES

### Cooling air baffle




Figure 8.5: Cooling air baffle position


Position	x-axis	y-axis	z-axis
P1	- 142 mm (- 5.59 in.)	- 101 mm (- 3.98 in.)	- 106 mm (- 4.17 in.)

### Cooling air baffle

Following recommendations should assist the aircraft or fuselage manufacturer in selecting suitable cooling air ducts:

Specification	Description
Cooling capacity	The cooling air baffle must be designed so, that it transfers thermal energy of approx. 6 kW (5.7 BTU/s) at take-off performance.
Cross section of air baffle	Cross section of the air baffle min. 100 cm <sup>2</sup> (15.50 in <sup>2</sup> ).
Material	Glass fibre reinforced plastic or heat and fire resistant material.
Attachment options	Formlocking on engine block and mounting above the cylinder and the crankcase.

# BRP-Rotax INSTALLATION MANUAL



AE 5IS\_0269

Figure 8.6: Cooling air baffle for tractor

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES

### General

The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

### INSTALLATION OVERVIEW




Figure 8.7: Cooling system schematic


- |   |                 |   |              |
|---|-----------------|---|--------------|
| 1 | Expansion tank  | 2 | Pressure cap |
| 3 | Radiator        | 4 | Water pump   |
| 5 | Overflow bottle | 6 | Vent         |

### WATER INLET ELBOW

#### ATTENTION

The hoses should be fixed with appropriate clips to prevent loss e.g. with spring type hose clips, such as those used for the coolant hoses between the water pump and cylinder.

# BRP-Rotax INSTALLATION MANUAL



AE 5iS\_0377

Figure 8.8: Water inlet elbow

1 Water pump housing

2 Water inlet elbow

Use two M6x20 Allen screws lock washers to attach the water inlet elbow. Tighten screws to 10 Nm (90 in lb.)

## ATTENTION

The total slip-on length of the water inlet elbow and expansion tank should be used.

## EXPANSION TANK

The aircraft manufacturer should give the possibility to the pilots to check the coolant level in the expansion tank. It is also necessary to inform the pilots about the daily inspection of the coolant level in the aircraft manufacturers Operators Manual.

To allow this inspection, e.g. a flap or panel on the cowling or a warning instrument in the cockpit for low coolant level should be foreseen.

## COOLANT HOSES

### NOTE


*For proper operation keep hoses as short as possible.*



## BRP-Rotax INSTALLATION MANUAL

Aluminium tubes with an inner diameter of 25 mm (0.98 in) can be used instead of longer hoses. These should have a bulge (1) in order to prevent coolant hoses working loose. Note as well that this will double the number of hose clamps required. The material of the hoses must be resistant against glycol, coolant and ozone.

Interface Parameter	Min.	Max.
Temperature resistance	125 °C (257 °F)	
Pressure durability	5 bar (72 psi)	
Inner diameter	25 mm (1")	
Bending radius	175 mm (6.89 in)	



09158




Figure 8.9: Aluminium tube

1 bead

### Hoses

Hoses exposed to direct heat radiation from exhaust system must be suitably protected with e.g. heat resistant protection tubes.

The hose between the overflow bottle and the expansion tank should be as short as possible and have a resistance to collapsing under temperature and vacuum.

### COOLANT

#### ATTENTION

**Use only coolant as recommended in the current Operators Manual.**

# BRP-Rotax INSTALLATION MANUAL

## VALIDATION OF INSTALLATION

### General

The validation procedures described in this chapter do not claim to be complete. The correct execution and compliance with all given system limitations and interface descriptions as well as with standards and norms given by authorities must be proven by the aircraft manufacturer.

### Coolant temperature

The maximum coolant temperature must be determined in order to check the efficiency of the cooling system.




Figure 8.10: Coolant temperature sensor

1 Coolant temperature sensor

The coolant temperature is measured using a temperature sensor (1), which is installed on cylinder 4.

### ATTENTION

**It is possible to record a false measurement when measuring fluid temperatures. If fluid volume is lost and sensor is not fully submerged in the liquid, the indicating instrument could incorrectly display a lower temperature, by measuring the air temperature instead of the coolant temperature.**

### Cylinder wall temperature

Max. permitted cylinder wall temperature on hottest cylinder is 200 °C (392 °F). See the following figure.

### NOTE

*If this temperature is exceeded, appropriate measures (e.g. cooling air ducts, modifications to cowling, etc.) must be taken to bring it within limits again.*

# BRP-Rotax INSTALLATION MANUAL




Figure 8.11: Measuring point

## Pressure test

To ensure the System has no leakage, remove the pressure cap from the expansion tank. Then attach the pressure tester and pump the system until the pressure manometer shows 1.2 bar (18 psi). After min. 1 minute, there should be still 1.2 bar (18 psi) pressure in the system.

- Check the efficiency of the coolant radiator and its proper sealing between cowling and radiator.
- Check the proper flow between expansion tank and overflow bottle.
- Ensure that no ram is induced onto the overflow bottle vent line.
- Check efficiency of air duct and proper air flow through the duct and around cylinders.
- Consider cold (winter) and hot (summer) conditions in ground and flight testing.
- Check proper dampening of the water radiator and stressfree installation and proper sealing.

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK


**BRP-Rotax**  
INSTALLATION MANUAL

**Chapter: 76-00-00**  
**ENGINE CONTROLS**

**TOPICS IN THIS CHAPTER**

<b>Special tools</b> .....	<b>3</b>
<b>System description</b> .....	<b>4</b>
System limitations .....	4
<b>Interface description</b> .....	<b>5</b>
Interface overview .....	5
Electrical interfaces .....	5
Mechanical interfaces .....	10
<b>Installation notes</b> .....	<b>12</b>
Installation overview .....	12
LANE Select Switches .....	13
Fuel pump switches .....	14
Start Switch .....	14

**BRP-Rotax**  
INSTALLATION MANUAL



AE 5iS\_0147

Figure 9.1: Engine management system (EMS)

**BRP-Rotax**  
INSTALLATION MANUAL

**SPECIAL TOOLS**

<b>Description</b>	<b>Part number</b>
Crimping pliers MOLEX 64016-0035/63811-4400	n.a.
Disassembly tool MOLEX 63813-1500	n.a.

# BRP-Rotax INSTALLATION MANUAL

## **SYSTEM DESCRIPTION**

For a detailed System description refer to the latest issue of the Operators Manual.

### **SYSTEM LIMITATIONS**

**Operating limits** Refer to latest issue of the Operators Manual.

**Valid installation positions** The ECU may be installed either in the engine compartment or in the cockpit. To prevent the ingress of liquids (moisture), the ECU must be mounted in a way that the connectors are facing downward.

The two Ambient Air Pressure and Temperature Sensors (AAPTS) are all-in-one sensors for engine ambient temperature and engine ambient pressure. In cowled engine installations they have to be mounted in the engine compartment in a ram air free area and close to the air inlet. The sensors must measure the correct air inlet temperature and the air pressure right before the air filter. The AAPTS sensors must not be mounted in the air intake system between the air filter and turbocharger inlet. The AAPTS must be mounted isolated from vibrations (e.g. caused by the engine).

The casing of the ECU must not be connected to the airframe ground. The rubber vibration damping (insulation material) must not be removed. If the rubber dampers were removed, the engine ground and the aircraft ground would be short-circuited.

**Component temperatures limitation** Limitation see Chapter 00-00-00 Approval of electric and electronic components.

**Connections** When connecting the wiring harness with the ECU take into account the labeling on the wiring harness and the ECU. Although the connectors are mechanically coded (i.e. wiring harness connector A1 can only be connected to ECU A1 socket), excessive force or incorrect positioning can result in bent pins and the ECU would then need to be replaced. Unplug the ECU connector from the wiring harness only if absolutely necessary. Connector plugs (ECU) are suitable for up to 20 plug-in operations. The number of plugging operations must be entered into the logbook. If this limit has been exceeded the ECU needs to be replaced.

**Wiring harness** The wiring harness must NOT be shortened or modified. Do not bend, kink, pinch or otherwise improperly stress the wiring harness. The bending radius of the wiring harness must not be less than 50 mm (1.97 in). To avoid excessive tension on the ECU connectors, a strain relief must be installed in a distance of ~ 100 mm (3.94 in) from the ECU.

#### **ATTENTION**


**Do not bend, kink, pinch or otherwise improperly stress the wiring harness. Use proper routing, clamping and strain relief on wiring harnesses.**



**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**



AE 5IS\_0184


Figure 9.2: Engine Management System (EMS)– Interfaces

- |    |   |    |   |
|----|---|----|---|
| 1  | <i>Harness Interface Connector A (HIC A) (electrical Interface)</i> | 2  | <i>Harness Interface Connector B (HIC B) (electrical Interface)</i> |
| 3  | <i>X1 Connector (electrical Interface)</i>                          | 4  | <i>X2 Connector (electrical Interface)</i>                          |
| 5  | <i>Regulator A (electrical Interface)</i>                           | 6  | <i>ECU (electrical, mechanical Interface)</i>                       |
| 7  | <i>AAPTS (electrical, mechanical Interface)</i>                     | 8  | <i>Wiring harness</i>   |
| 9  | <i>Starter relay connectors (electrical Interface)</i>              | 10 | <i>Fuel pump connectors (electrical Interfaces)</i>                 |
| 11 | <i>Wiring harness grounding</i>                                     |    |   |

**ELECTRICAL INTERFACES**

**Harness interface connector A** The HIC A connector allows powering ECU Lane A and Fuel Pump A. interfaces to Indication elements are described in Chapter 77-00-00.

# BRP-Rotax INSTALLATION MANUAL



AE 5IS\_0186

Figure 9.3: HIC A Connector

In case the EMS is powered by an external power source or by one of the internal generators:

- A connection between Terminal 1 and Terminal 7 will power ECU Lane A
- A connection between Terminal 3 and Terminal 9 will power Fuel pump 1





Figure 9.4: HIC A connector –Engine controls

## BRP-Rotax INSTALLATION MANUAL

Terminal (Supply)		Terminal (Ground)		Interface Parameter	Min.	Max.	Nominal
1	LANE_SEL_SW_A_1	7	LANE_SEL_SW_A_2	Nominal Voltage			12 V
				Nominal Current			7.5 A
3	SIG_FUEL_PUMP_1	9	GND_FUEL_PUMP_1	Nominal Voltage			12 V
				Nominal Current			10 A

### Harness Interface Connector B



AE 5IS\_0187

Figure 9.5: HIC B connector

In case the EMS is powered by an external power source or by one of the internal generators:

- A connection between Terminal 1 and Terminal 9 will power ECU Lane B
- A connection between Terminal 3 and Terminal 11 will power Fuel Pump 2
- A connection between Terminal 4 and Terminal 12 will actuate the Starter Relay

# BRP-Rotax INSTALLATION MANUAL




Figure 9.6: HIC B Connector – Engine controls

Terminal (Supply)		Terminal (Ground)		Interface Parameter	Min.	Max.	Nominal
1	LANE_SEL_SW_B_1	9	LANE_SEL_SW_B_2	Nominal Voltage			12 V
				Nominal Current		7.5 A	
3	SIG_FUEL_PUMP_2	11	GND_FUEL_PUMP_2	Nominal Voltage			12 V
				Nominal Current		10 A	
12	SUPP_START_SWITCH	4	CONN_STARTER_REL_SW	Nominal Voltage			12 V
				Nominal Current		5 A	

The HIC B connector allows powering ECU Lane B. Interfaces to indication elements are described in Chapter 77-00-00.

**X1, X2 Connector** [See Chapter 24-00-00 section Interface Description.](#)

**Regulator A** [See Chapter 24-00-00 section 24-00-00 section Interface Description.](#)

**Starter Relay** [See Chapter 80-00-00 section Interface Description](#)

# BRP-Rotax INSTALLATION MANUAL

## Wiring harness grounding

The grounding cable must be attached to Fusebox Regulator A. [See Chapter 24-00-00 section Fusebox Regulator A](#)


## Fuel pump

[See Chapter 73-00-00 section Interface Description](#)

# BRP-Rotax INSTALLATION MANUAL

## MECHANICAL INTERFACES

Engine Control  
Unit (ECU)



AE 5IS\_0190


Figure 9.7: ECU –mounting points

- |                       |                       |
|-----------------------|-----------------------|
| 1 Connector socket A1 | 2 Connector socket A2 |
| 3 Connector socket B  | 4 Rubber sleeve       |

# BRP-Rotax INSTALLATION MANUAL

## Sensors

### Ambient Air Pressure and Temperature Sensors (AAPT 1, 2)



AE 5IS\_0017

Figure 9.8: AAPT – mounting points

Maximum diameter of screw in the interior of the mounting hole: 6 mm (0.24 in.). Only mount sensor with a washer ( $\varnothing$  10 mm (0.39 in.) or with an adequate screw head diameter. The maximum permissible pressure at the mounting flange may not exceed 20 N/mm<sup>2</sup> (0.0029 psi).

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES


### General

The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

### INSTALLATION OVERVIEW




AE 5IS\_0191

Figure 9.9: Harness Interface Connector A-Schematic

Part	Function
1	Harness Interface Connector A
2	Lane Select Switch A (-S4)



# BRP-Rotax INSTALLATION MANUAL



AE 5IS\_0192

Figure 9.10: Harness Interface Connector B-Schematic

Part	Function
4	Harness Interface Connector B
5	Lane Select Switch B (-S5)
7	Start Switch (-S6)

## LANE SELECT SWITCHES

### Lane Select Switch A (-S4)

Interface Parameter	Value
Switch type	Toggle (normally open)
Nominal voltage	28 V
Nominal current	7.5 A
Number of poles	1-pole

### Lane Select Switch B (-S5)

Interface Parameter	Value
Switch type	Toggle (normally open)
Nominal voltage	28 V

**BRP-Rotax**  
INSTALLATION MANUAL

Interface Parameter	Value
Nominal current	7.5 A
Number of poles	1-pole

### FUEL PUMP SWITCHES

#### Fuel pump Switch 1 (-S7)

Interface Parameter	Value
Switch type	Toggle (normally open)
Nominal voltage	28 V
Nominal current	10 A
Number of poles	1-pole

#### Fuel Pump Switch 2 (-S7)

Interface Parameter	Value
Switch type	Toggle (normally open)
Nominal voltage	28 V
Nominal current	10 A
Number of poles	1-pole

### START SWITCH

#### Start Switch (-S6)

Interface Parameter	Value
Switch type	Button (normally open, non-locking)
Nominal voltage	28 V
Nominal current	5 A
Number of poles	1-pole

**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: 77-00-00**  
**ENGINE INDICATING**


**TOPICS IN THIS CHAPTER**

**System description** ..... **3**  
    System limitations ..... 3

**Interface description** ..... **4**  
    Interface overview ..... 4  
    Electrical interfaces ..... 4

**Installation notes** ..... **8**  
    Installation overview ..... 8  
    Warning lamps ..... 10  
    CAN interfaces ..... 10

**BRP-Rotax**  
INSTALLATION MANUAL



AE 5iS\_0147

Figure 10.1: Engine indication

# BRP-Rotax INSTALLATION MANUAL

## SYSTEM DESCRIPTION

The complete system is volume of supply and is certified together with the engine. For a detailed system description refer to latest issue of the Operators Manual.

## SYSTEM LIMITATIONS

**Maintenance CAN** The Maintenance CAN must only be used in combination with a B.U.D.S. Aircraft USB-to-CAN converter and *B.U.D.S. Aircraft Software*. It is not possible to use the Maintenance CAN for other displaying or data logging purposes.

**CAN wiring** For the Display- and the Maintenance CAN twisted and shielded cables (3 pins: CAN\_H, CAN\_L, CAN\_GND) must be used for the CAN-connections to ensure a high electromagnetic compatibility in data transmission.

**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**





Figure 10.2: Engine Management System (EMS) – Interfaces

- 1 *Harness Interface Connector A (HIC A)*
- 2 *Harness Interface Connector B (HIC B)*
- 3 *Electromagnetic shielding of CAN Bus*

**ELECTRICAL INTERFACES**

**Harness Interface Connector A** The HIC Connector A is equipped with a Maintenance CAN interface, a Display CAN interface and terminals which can be used to actuate a warning lamp indicating the current status of the ECU Lane A. Interfaces to control elements are described in Chapter 76-00-00.

# BRP-Rotax INSTALLATION MANUAL



AE 5IS\_0186

Figure 10.3: HIC A Connector

### Warning Lamp

Terminal (Supply)	Terminal (Ground)	Interface Parameter	Min.	Max.	Nominal
2	8	SUPP_WARN_LAMP_A / WARN_LAMP_A			12 V
			Nominal voltage		
		Nominal current		120 mA	

### CAN Interfaces

Terminal	Specification
4	Display CAN Lane A
5	
6	
10	Maintenance CAN Lane A
11	
12	


**Connector:** HIC Connector A (included in the engines scope of delivery).

The HIC Connectors must be mounted according to the procedure prescribed in Chapter 76-00-00.

The Display CAN is based on the CAN Aerospace protocol. For detailed interface description contact an authorized ROTAX® Distributor or its independent Service Center.

# BRP-Rotax INSTALLATION MANUAL

**Harness Interface Connector B** The HIC Connector B is equipped with a Maintenance CAN interface, a Display CAN interface and terminals which can be used to actuate a warning lamp indicating the current status of the ECU Lane B. Interfaces to control elements are described in Chapter 76-00-00.



AE 5iS\_0187

Figure 10.4: HIC B connector

### Warning Lamp

Terminal (Supply)	Terminal (Ground)	Interface Parameter	Min.	Max.	Nominal
2	SUPP_WARN_LAMP_B	10	WARN_LAMP_B	Nominal voltage	12 V
				Nominal current	120 mA

### CAN Interfaces

Terminal	Specification
6	Display CAN Lane B
7	
8	
14	Maintenance CAN Lane B
15	
16	

Terminal (Supply)	Terminal (Ground)	Interface Parameter	Min.	Max.	Nominal
2	SUPP_WARN_LAMP_B	10	WARN_LAMP_B	Nominal voltage	12 V
				Nominal current	120 mA



# BRP-Rotax INSTALLATION MANUAL

**Connector:** HIC Connector B (included in the engine's scope of delivery).  
The HIC Connectors must be mounted according to the procedure prescribed in Chapter 76-00-00.  
The Display CAN is based on the CAN Aerospace protocol. For detailed interface description contact an authorized ROTAX® Distributor or its independent Service Center.

## **Electromagnetic shielding of CAN Bus**

The electromagnetic CAN Bus shielding ring terminals need to be connected with the Airframe Ground.

**Connector:** Ring Terminal M6

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES

### General

The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

### INSTALLATION OVERVIEW




Figure 10.5: Harness Interface Connector A-Schematic

Part	Function
1	Harness Interface Connector A
2	Warning Lamp A (-H1)
3	Warning Lamp A (LED) (-H1 V2)

# BRP-Rotax INSTALLATION MANUAL

Part	Function
4	Resistor 1.5 kΩ (-R6)
5	Resistor 1 kΩ (-R7)
6	Display CAN A
7	Maintenance CAN A




Figure 10.6: Harness Interface Connector B-Schematic

Part	Function
8	Harness Interface Connector B
9	Warning Lamp B (-H2)
10	Warning Lamp B (LED) (-H2 V2)
11	Resistor 1.5 kΩ (-R8)
12	Resistor 1 kΩ (-R9)
13	Display CAN B
14	Maintenance CAN B

# BRP-Rotax INSTALLATION MANUAL

## WARNING LAMPS

<b>Warning Lamp A, B (-H1, -H2)</b>	<b>Interface Parameter</b>	<b>Value</b>
	Nominal voltage	12
	Nominal current	max. 120 mA

Instead of common lamps also LED lamps (-H1 V2, -H2 V2) can be used. In this case a appropriate pre-resistor must be conducted serial to the LED. An additional resistor parallel to the LED prevents the ECU from detecting an open circuit at this warning lamp.

## CAN INTERFACES

**Display CAN** Two independent Display CAN interfaces are provided for displaying or recording engine data. When displaying engine data, it must be ensured that data of both CAN interfaces is used, providing truly redundant data indication or data indication of suitable reliability, consistent with the safety objective of the final application. The proof of consistency with the safety objective of the final application is the responsibility of the installer.

**Maintenance CAN** To be able to connect the Maintenance CAN A and B with the B.U.D.S Aircraft USB-to-CAN converter the Maintenance CAN A and B should be connected with two separate Sub-D DE9 (9-pin) sockets. It is highly recommended to conduct those connectors due to the fact that the B.U.D.S. Aircraft is a central element when it comes to diagnosis and maintenance of this engine.

<b>CAN Type</b>	<b>Description</b>	<b>HIC Pin</b>	<b>Sub-D DE9 Pin</b>
Maintenance CAN A	CAN_LOW_2_A	11 (HIC A)	2
	CAN_GND_2_A	10 (HIC A)	3
	CAN_HIGH_2_A	12 (HIC A)	7
Maintenance CAN B	CAN_LOW_2_B	15 (HIC B)	2
	CAN_GND_2_B	14 (HIC B)	3
	CAN_HIGH_2_B	16 (HIC B)	7

It is recommended not to connect maintenance and diagnostic interfaces Lane A and Lane B together.


**BRP-Rotax**  
INSTALLATION MANUAL

**Chapter: 78-00-00**  
**EXHAUST SYSTEM**

**TOPICS IN THIS CHAPTER**

**System description** .....3  
    System limitations .....3  
**Interface description** .....4  
    Interface overview .....4  
    Mechanical interfaces .....5

**BRP-Rotax**  
INSTALLATION MANUAL



AE 5iS\_0193

Figure 11.1: Exhaust system

# BRP-Rotax INSTALLATION MANUAL

## **SYSTEM DESCRIPTION**

The complete system is volume of supply and is certified together with the engine. For a detailed system description refer to latest issue of the Operators Manual.

### **SYSTEM LIMITATIONS**

**Operating limits** Refer to latest issue of the Operators Manual.

**Modifications** Modifications of the system by the OEM (e.g. cut the exhaust) may be done, if following requirements are met:


- All exhaust parts added by the OEMs are decoupled (weight and vibration) from the exhaust provided
- Exhaust back pressure must not exceed following limits:

<b>System Limit</b>	<b>Min.</b>	<b>Max.</b>
Exhaust back pressure (ambient pressure: 1000 mbar (14.50 psi))	155 mbar (2.24 psi)	180 mbar (2.61 psi)
Exhaust back pressure (ambient pressure: 900 mbar (13.05 psi))	175 mbar (2.53 psi)	205 mbar (2.97 psi)
Exhaust back pressure (ambient pressure: 800 mbar (11.60 psi))	195 mbar (2.82 psi)	230 mbar (3.33 psi)
Exhaust back pressure (ambient pressure: 700 mbar (10.15 psi))	215 mbar (3.11 psi)	255 mbar (3.69 psi)

**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**



AE 51S\_0193a

Figure 11.2: Exhaust interfaces

- |                          |                     |
|--------------------------|---------------------|
| 1 Exhaust muffler assy.  | 2 Exhaust pipe      |
| 3 Exhaust manifold assy. | 4 Exhaust tail pipe |



# BRP-Rotax INSTALLATION MANUAL

## MECHANICAL INTERFACES

### Exhaust tail pipe




Figure 11.3: Exhaust tail pipe position

Interface Parameter	Value		
Tail pipe bending position (P1)	<b>x-axis:</b> 491 mm (19.33 in.)	<b>y-axis:</b> 396 mm (15.59 in.)	<b>z-axis:</b> 208 mm (8.19 in.)
Tail pipe diameter	54 mm (2.13 in.)		
Tail pipe material	1.4845 (X8CrNi25-21)		

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK



**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: 79-00-00**  
**LUBRICATION SYSTEM**

**TOPICS IN THIS CHAPTER**

<b>System description</b> .....	<b>3</b>
System limitations .....	3
<b>Interface description</b> .....	<b>5</b>
Interface overview .....	5
Oil tank dimensions .....	5
Oil tank interfaces .....	7
Oil pump .....	8
<b>Installation notes</b> .....	<b>11</b>
Installation overview .....	11
Oil lines .....	11
<b>Filling and purging of the oil system</b> .....	<b>13</b>
<b>Validation of installation</b> .....	<b>16</b>
Crankcase pressure measurement .....	16

**BRP-Rotax**  
INSTALLATION MANUAL



Configuration 2



AE 5iS\_0195

Figure 12.1: Lubrication system

# BRP-Rotax INSTALLATION MANUAL

## SYSTEM DESCRIPTION

For a detailed System description refer to the latest issue of the Operators Manual.

### SYSTEM LIMITATIONS

**Operating limits** Refer to latest issue of the Operators Manual.

#### **⚠ WARNING**

##### **Non-compliance can result in serious injuries or death!**

The lubrication system must be designed such that the permissible operating temperatures and maximum values are not exceeded.

### Pressure limits

Following measurements must be exceeded when operating the engine at full throttle:

System Limit	Min.	Max.
Crankcase pressure relative to ambient pressure at full load = 5800 rpm (Oil temperature 90 °C (194 °F))		Ambient pressure 400 mbar (5.80 psi)
Pressure loss in suction line. (p_ambient – p_oil pump inlet)	-	350 mbar (5 psi) between 70 - 90°C (158-194 °F) oil temperature




Figure 12.2

1 Oil pressure measurement point

# BRP-Rotax INSTALLATION MANUAL

## Installation positions

### Oil tank

System Limit	Min.	Max.
Angular deviation	- 10°	+ 10°
Tank position in relation to engine	- 40 mm (- 1.57 in.)	360 mm (14.17 in.)

### ⚠ WARNING

#### Non-compliance can result in serious injuries or death!

If the oil tank is located higher, oil might trickle through bearing clearances into the crankcase during longer periods of engine stop. If fitted too low it might damage the oil circuit.




Figure 12.3: Oil tank installation position

The oil tank must be installed on a low-vibration position and not on the engine directly. The oil tank cover and the oil drain screw must be easily accessible.

**BRP-Rotax**  
INSTALLATION MANUAL

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**





Figure 12.4: Lubrication system interfaces

- |  |  |
|--|--|
| 1 Oil pump inlet (hydraulic interface)                   | 2 Oil return outlet (hydraulic interface)        |
| 3 Oil return outlet (turbocharger) (hydraulic interface) | 4 Oil tank in- and outlets (hydraulic interface) |
| 5 Oil filter (hydraulic interface)                       |  |

**OIL TANK DIMENSIONS**

**Oil tank**            The oil tank must be mounted by using appropriate clamps.

# BRP-Rotax INSTALLATION MANUAL



AE 5IS\_0200 a

Figure 12.5: Oil tank dimensions


- |   |                  |   |                     |   |                   |
|---|------------------|---|---------------------|---|-------------------|
| 1 | Oil tank         | 2 | Oil dipstick        | 3 | Oil bayonet cap   |
| 4 | Hex. screw M12x2 | 5 | Gasket ring C 12x18 | 6 | Profile clamp 163 |
| 7 | Oil tank cover   |   |                     |   |                   |



# BRP-Rotax INSTALLATION MANUAL

## OIL TANK INTERFACES

Oil tank inlet and outlet



AE 5IS0199

Figure 12.6: Oil tank interfaces

- |                  |                                  |
|------------------|----------------------------------|
| 1 Oil tank inlet | 2 Oil tank outlet                |
| 3 Vent fitting   | 4 Oil tank inlet (turbo charger) |

### NOTE

The oil tank cover is also marked: *IN* — oil tank inlet, *OUT* — oil tank outlet.

### ATTENTION

**Both oil tank inlets must be connected with the oil return outlets.**

2x Oil tank inlet

Interface Parameter	Value
Screw socket	3/4–16 UNF
Tightening torque	25 Nm (18 ft. lb)

Oil tank outlet

Interface Parameter	Value
Screw socket	3/4–16 UNF
Tightening torque	25 Nm (18 ft. lb)

# BRP-Rotax INSTALLATION MANUAL

Vent fitting

Interface Parameter	Value
Outside diameter	8 mm (0.31 in.)
Slip-on length	15 mm (0.59 in.)

## **⚠ WARNING**

**In any case the vent fitting must ensure a release of pressure from the oil tank at any time. Otherwise oil could emerge into the turbo housing which conveys through the exhaust. Formation of smoke is possible.**

Oil tank inlet  
(turbo charger)

Interface Parameter	Value
Screw socket	M10 x 1
Tightening torque	15 Nm (133 in. lb)

## OIL PUMP

Oil pump inlet

The oil pump inlet must be connected directly with the oil tank outlet.

Interface Parameter	Value
Screw socket	3/4-16 UNF
Tightening torque	25 Nm (18 ft. lb)


Oil return outlet

The oil return outlet must be connected directly with the oil tank inlet.

# BRP-Rotax INSTALLATION MANUAL

## ATTENTION

**Both oil return outlets need to be used. Only the oil return lines on magneto side must be used. The hoses must have approx. the same length.**



AE 5IS\_0198

Figure 12.7: Oil return outlets

*1 Oil return outlet*


Interface Parameter	Value
Screw socket	3/4–16 UNF
Tightening torque	25 Nm (18 ft. lb)

**Oil return outlet (turbocharger)**

The oil return outlet (turbocharger) must be connected directly with the oil tank inlet (turbocharger).

Interface Parameter	Value
Screw socket	M10 x 1
Tightening torque	15 Nm (133 in. lb)

**BRP-Rotax**  
INSTALLATION MANUAL



AE 5iS\_0378

Figure 12.8: Oil return outlet (turbocharger)

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES

### General

The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

### INSTALLATION OVERVIEW




Figure 12.9: Lubrication system overview

1 Engine circuit

2 Turbocharger return line

### OIL LINES

At negative pressure of -500 mbar (-7.25 psi) and a oil temperature of 140 °C (284 °F) the oil lines must not collapse.


A minimum inner diameter of at least 10 mm (0.39 in.) should be used.

# BRP-Rotax INSTALLATION MANUAL

## Oil tank venting line

Following points should be considered when installing the oil tank venting line:

- Route the line without kinks and avoid sharp bends
- Route the venting line in a continuous decline. Otherwise a drain bore at the lowest point should be foreseen to drain any condensate.



AE 516\_0177

Figure 12.10: Bypass opening

1 Bypass opening

2 Cowling

## NOTE

*Water is a by-product of the combustion of fuel. Most of this water will dissipate from the combustion chamber with the exhaust gases. A small amount will reach the crankcase and must be disposed of through a venting line.*

*The venting line must be protected from any kind of ice formation for condensation by using e.g. isolation protection or a routing in a hose with hot air flow. Additionally a bypass opening should be foreseen before the cowling outlet.*

# BRP-Rotax

## INSTALLATION MANUAL

### **FILLING AND PURGING OF THE OIL SYSTEM**

**Introduction** Ensure that oil lines are connected correctly and secured. Also ensure that the oil cooler (if fitted) is in the suction line between the oil tank and the oil pump, see following figure. Verify that the oil tank is filled up to the maximum level (to the top of the flat portion of the dipstick). The capacity of the oil system without oil cooler and connection lines is approx. 3l (0.66 gal.). Additional oil (up to 0.5 litres (0.13 gal)) may be added to the tank for the purpose of this procedure.

**Instruction** The following work procedures must be carried out for purging the oil system:

1. Disconnect oil return lines (2) from the oil tank.
2. Place the free end of the return lines into a suitable container (4) below the engine.
3. Plug open connections on oil tank with suitable air tight cap.
4. Remove the spark plug connections.
5. For easier rotation of engine remove one spark plug from each cylinder.

#### **NOTE**

Prevent any foreign objects entering the spark plug hole.

6. Using a compressed air line, pressurize the oil tank through its vent fitting (6) (on the neck of the tank). Adjust the compressor outlet regulator so that the air line pressure is between 0.4 bar (5.8 psi) and 1 bar (14.5 psi). Do not exceed 1 bar (14.5 psi).

#### **NOTE**

The oil tank bayonet cap is not pressure-tight, some air can escape.

7. Turn the engine by hand in direction of normal rotation until the first pressure indication appears on the oil pressure gauge. Normally this will take approx. 20 turns. Depending on installation it may take up to 60 turns.

#### **NOTE**

Do not use the starter for this purpose. Fit propeller and use it to turn the engine by hand.

#### **NOTE**

The oil tank may empty and as a result introduce air into the oil system. Pay attention to the oil level and fill tank as required.

8. Stop the pressurization.
9. Open the cap for the oil return line on the oil tank and reconnect the engine oil return line to the tank. Ensure that the suction oil line and oil return line is connected to proper fittings on the oil tank. Note: If the oil lines from engine to oil tank are incorrectly connected, severe engine damage may result.
10. Re-fit the spark plugs. Restore aircraft to original operating condition.
11. Residual oil may have accumulated in the crankcase. Return it to the oil tank by following the oil level check procedure in the relevant Operators Manual.

**BRP-Rotax**  
INSTALLATION MANUAL

12. Fill the oil in the tank up to the full mark on the dipstick.
13. Carefully check all lubrication system connections, lines and clamps for leaks and tightness.

**ENVIRONMENTAL NOTE**

**Protect the environment! Do not spill oil and pay attention for adequate disposal.**



# BRP-Rotax INSTALLATION MANUAL




Figure 12.11: Setup for purging the oil system

- |                   |                                    |
|-------------------|------------------------------------|
| 1 Suction line    | 2 Oil return line                  |
| 3 Free end        | 4 Tank                             |
| 5 Oil return line | 6 Vent fitting                     |
| 7 Plug (2x)       | 8 Temporary connection for purging |

# BRP-Rotax INSTALLATION MANUAL

## VALIDATION OF INSTALLATION

### General

The validation procedures described in this chapter do not claim to be complete. The correct execution and compliance with all given system limitations and interface descriptions as well as with standards and norms given by authorities must be proven by the aircraft manufacturer.

### CRANKCASE PRESSURE MEASUREMENT

1. Remove magnetic plug or crankshaft locking screw.
2. Attach pressure sensor (pressure gauge with liquid damping). The thread for the magnetic plug must be M12x1,5 (metric). The thread for the crankshaft lock pin hole must be M8.
3. Start the engine according the Operators Manual and read the crankcase pressure value at full throttle.
4. Compare the read out value with the limitations for the crankcase pressure specified in the section "System Limitations" of this chapter.  
If the readings exceed the pressure limits, then the flow resistance in the oil return line from oil sump to oil line is too high in the current engine installation (contamination, restrictions of cross-section etc.) This condition is unsafe and must be rectified immediately.
5. Re-install magnetic plug or screw into crankshaft locking pin hole. When reinstalling the screw always use a new gasket.

**BRP-Rotax**  
INSTALLATION MANUAL

**Chapter: 80-00-00**  
**STARTING**

**TOPICS IN THIS CHAPTER**


**System description** ..... **3**  
    System limitations ..... 3

**Interface description** ..... **4**  
    Interface overview ..... 4  
    Electrical interfaces ..... 4

**Installation notes** ..... **5**  
    Installation overview ..... 5  
    Wiring ..... 5

**Validation of installation** ..... **7**

**BRP-Rotax**  
INSTALLATION MANUAL



AE 515\_0203

Figure 13.1: Starting

**BRP-Rotax**  
INSTALLATION MANUAL

**SYSTEM DESCRIPTION**

For a detailed System description refer to the latest issue of the Operators Manual.

**SYSTEM LIMITATIONS**

**Operating limits** Refer to latest issue of the Operators Manual.

**Ambient temperatures**

System Limit	Min.	Max.
Electric Starter	- 40 °C (- 40 °F)	80 °C (176 °F)


**Thermal durability** Suitable for short starting periods only. Activate starter for max. 10 seconds (without interruption), followed by a cooling period of 2 minutes.

**Aircraft ground** The engine block must be connected to the aircraft using a properly sized line (minimum the same cable cross section as starter supply), to provide the required starter current and to avoid static electricity between the engine and the aircraft.

**BRP-Rotax**  
**INSTALLATION MANUAL**

**INTERFACE DESCRIPTION**

**INTERFACE OVERVIEW**



AE 516\_0036

Figure 13.2: Starter interfaces

1 Positive terminal

2 Negative terminal

**ELECTRICAL INTERFACES**

**Positive terminal**

Interface Parameter	Min.	Max.	Nominal
Input voltage:			12 V
Input load:* * for resistance of starter circuit R <sub>smax</sub> = <20 mOhm	20 A	350 A <sup>3</sup>	

The terminal must be conducted as M5 screw connection suitable for cable lug according to DIN 46225.

Tightening torque: Min. 3 Nm (27 in.lb) Max. 5 Nm (44 in.lb).

**Negative terminal** The engine block must be connected to the airframe using a properly sized ground strap (minimum the same cable cross section as the starter supply), for carrying the starter current and to avoid static electricity between the engine and the airframe.

3. When starter engine is locked

# BRP-Rotax INSTALLATION MANUAL

## INSTALLATION NOTES

### General

The representation of components in this chapter which are not within scope of the delivery is only symbolic. The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

The final design, the selection and specification of parts according to the respective applicable regulations, the consideration of the system limitations and interface description as well as the comprehension of the operating limits in every operational state is in the responsibility of the aircraft manufacturer.

The aircraft manufacturer has to make sure that the operating limits given in the Operators Manual can be supervised by the pilot. The execution of the installation must allow the operation of the engine according to the Operators Manual.

### INSTALLATION OVERVIEW




Figure 13.3: Engine starting circuit

1 Starter relay

2 Wiring

### WIRING

The engine block must be connected to the airframe using a properly sized ground strap for carrying the starter current and to avoid static electricity between the engine and the airframe.

The minimum cable cross-section for the line from the battery to the starter relay and from there to the electric starter and for the ground line (start system) depends on the cable length "l" (= Sum of the supply line and ground line of the electric starter) and has to be calculated according to the following table.

## BRP-Rotax INSTALLATION MANUAL

I [m]	I [ft]	A <sub>min.</sub> [mm <sup>2</sup> ]	A <sub>min.</sub> [in <sup>2</sup> ]	A <sub>max.</sub> [mm <sup>2</sup> ]	A <sub>max.</sub> [in <sup>2</sup> ]	AWG <sub>min.</sub>
<4	<13	20.408	0.031	25	0.039	4
4<I<4.5	13<I<14.8	22.959	0.036	35	0.054	3
4.5<I<5	14.8<I<16.4	25.51	0.04	35	0.054	3
5<I<5.5	16.4<I<18	28.061	0.043	35	0.054	2
5.5<I<6	18<I<19.7	30.612	0.047	35	0.054	2
6<I<6.5	19.7<I<21.3	33.163	0.051	35	0.054	2
6.5<I<7	21.3<I<23	35.714	0.055	50	0.078	1
7<I<7.5	23<I<24.6	38.265	0.059	50	0.078	1
7.5<I<8	24.6<I<26.2	40.816	0.063	50	0.078	1
8<I<8.5	26.2<I<27.9	43.367	0.067	70	0.109	0
8.5<I<9	27.9<I<29.5	45.918	0.071	70	0.109	0
9<I<9.5	29.5<I<31.2	48.469	0.075	70	0.109	0
9.5<I<10	31.2<I<32.8	51.02	0.079	70	0.109	0

The internal resistance of the battery and the resistance of the electrical system (wires, contact points, relay contacts) largely determine the performance of the starting system. Therefore, the total loop resistance ( $R_{Smax}$ ) may not exceed 0.015 Ω.

$$R_{Smax} = \sum R = R_{iBatt} + R_{C \text{ Starter relay}} + R_L + R_{Other}$$

Symbol	Description
$R_{iBatt}$	Inner resistance of battery
$R_{C \text{ Starter Relay}}$	Contact resistance starter relay
$R_L$	Line resistance
$R_{Other}$	Any other resistor (e.g. Master relay, contact resistance...)



**BRP-Rotax**  
INSTALLATION MANUAL

**VALIDATION OF INSTALLATION**

**General**

The validation procedures described in this chapter do not claim to be complete. The correct execution and compliance with all given system limitations and interface descriptions as well as with standards and norms given by authorities must be proven by the aircraft manufacturer.

**Check starting**

- Check of starting at cold weather condition. Starter interface must be executed.

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK

**BRP-Rotax**  
**INSTALLATION MANUAL**

**Chapter: APPENDIX**  
**OPERATIONAL AND INSTALLATION CONSIDERATIONS**

**TOPICS IN THIS CHAPTER**

**Scope .....2**

**Fuel pumps and power supplies .....3**

**Engine starting, Start power switching system and Starting system .....4**

**Lane select switching system – Ignition switching .....5**

**Failure behavior and Warning annunciation to the pilot .....6**

**Simplified EMS Matrix 915 i A Series .....7**

**Hypothesis on warning lamp execution in the aircraft .....15**

**System availability and reliability .....16**

**Electrical bonding .....17**

# BRP-Rotax INSTALLATION MANUAL

## SCOPE

The current version of the Operators Manual provides information on pilot action in the case of abnormal engine operation (see Chapter 4, section 4.1: Engine failures in flight). The current information (table) provides a very conservative position which might not allow to tap the full potential of the engine's operational ability if referring to this table only. For this reason, an additional section in written form is provided in the Installation Manual, explaining engine behavior in very simple form, with the intention to allow the installer tailoring evaluation of system behavior and failure severity classification and thus pilot action for a specific aircraft installation.

Prediction of pilot action is not possible to the engine system designer entirely, since this may vary with actual conditions arising from installation in a specific aircraft (SEP, MEP, Aircraft Type, Operational Conditions, etc.). It therefore might seem appropriate to provide a more detailed description of the engine system behavior in the case of failures, rather than providing a given pilot reaction, not knowing about the aircraft installation in every detail.

With upcoming installation projects based on different aircraft certification specifications it is now found that the current documentation should be refined and or changed to better meet the demands of installers.

This written document should furthermore provide a better understanding for interpretation and implementation of the following topics:

- Fuel pumps and power supplies
- Engine starting, start power switching system and Starting system
- Lane select switching system – Ignition switching
- Failure behavior and warning annunciation to the pilot
- Failure consideration beyond Installation Interfaces
- Hypothesis on warning lamp execution in the aircraft
- System availability and reliability
- Electrical bonding

# BRP-Rotax INSTALLATION MANUAL

## **FUEL PUMPS AND POWER SUPPLIES**

The 915 i A Series provides the possibility to supply fuel pumps from the engine electric supply system. It provides a connector for connection of two electric fuel pumps (not engine type design) and furthermore the possibility to actuate these fuel pumps via the HIC (Harness Interface connector). At the HIC position two fuel pump switching systems (not engine type design) are required to provide the fuel pump ON/OFF function. From engine system perspective these fuel pump switching systems are required to allow a real check of the functional performance of each pump, meaning completely switching off the opposite fuel pump, while the current engaged fuel pump must supply the engine stand alone.

The 915 i A Series power supply system comprises two separate permanent magnet alternators (engine internal, on a single stator but completely physically separated), two independent Voltage regulators, including voltage smoothing capacitors, etc. This forms two **independent power supply** sources which are each able to power the Engine Management System (EMS) entirely. These power supply systems produce power once the engine is turning, each completely independent and completely galvanic separated from the aircraft power supply (when Start power OFF and backup battery OFF). For this reason, there is no dependence and interaction between engine power supply and aircraft power supply at all. The two power supply systems are not specifically dedicated to the two fuel pumps. They are rather dedicated to the entire EMS, meaning power supply system Generator A is supplying the entire EMS including both fuel pumps in common operation mode. In the case of a faulty power supply system Generator A the power supply system Generator B is automatically engaged and supplying the EMS including both fuel pumps. This means not only a backup pump receives an independent power supply but rather each control system including each fuel pump has a redundant independent power supply.

Engagement of the backup power supply system Generator B is done by the Engine Control Unit (ECU) in the case of over voltage and under voltage. If the voltage of power supply system Generator A decreases significantly or at all, the control transition of the power supplies is additionally done per mechanical means (relays drop out). These mechanism allow engagement of backup power supply under every probable circumstance.

If power supply system Generator B is used to supply the aircraft electrical system (possible in common operation mode) it must be noted that in case of failure this power supply system B is disconnected from the aircraft to serve as the backup to the EMS.

The ECU does not control and monitor the fuel pumps. The EMS provides the possibility to supply and control the fuel pumps.

The aspect “**directly driven fuel pump**” as required in various aircraft certification specifications is interpreted as follows:

- The fuel pump is directly driven in an electrical manner, as it is supplied by a power supply system which is directly driven from the crankshaft, self-supplying the system as long as the engine is rotating (as it would be the case on a typical mechanical system).
- From a human factor perspective it is desired, that a main pump may not be switched off inadvertently. This aspect must be resolved per the arrangement of the fuel pump switching system on aircraft level. The arrangement may be such, that the main pump is always ON during flight, while switching OFF is just feasible for fuel pump checking purpose during preflight checks. Prevention of inadvertent operation of switching action is common practice with ignition systems.

**BRP-Rotax**  
INSTALLATION MANUAL

**ENGINE STARTING, START POWER SWITCHING SYSTEM AND  
STARTING SYSTEM**

The 915 i A Series engines requires provision of electric power supply for EMS startup (startup power to ECU, sensors, etc.). This is done by a start power switching system (not engine type design), which provides power to the EMS via the Fuse box interface (X3, EMS GND).

The 915 i A Series provides the possibility to supply a starter relay (not engine type design) from the EMS and to actuate the starter relay via the HIC. This arrangement can form a part of a complete starting system with interfaces at the starter, starter relay connector and HIC connector of the engine wiring harness.

When the engine is started the engine internal power supply system Generator B is supplying the EMS. At a certain engine speed , and after a certain amount of stable operating time, the ECU commands power supply system A to take over. power supply system Generator A remains engaged except in the case of failures. This procedure ensures that both power supply systems are checked prior to flight. It is therefore important that a start power switching system releases power prior to commanding power supply system A. This is important so as not to compromise the check of power supply system Generator B.

**BRP-Rotax**  
**INSTALLATION MANUAL**

**LANE SELECT SWITCHING SYSTEM – IGNITION SWITCHING**

Certification Specifications might call out specific requirements for ignition systems, whereas this seems to be sometimes driven by classical configurations where the only engine related piece of electronics is represented by the ignition system itself.

The 915 i A Series engine features a complete electronic system including redundant controllers, ignition, injection, power supply, turbo actuation, etc. The ignition system is not to be segregated from the entire system and therefore a classical magneto check needs to be extended to all functions an EECS performs. With the 915 i A Series engines each individual lane (including controller, sensors, actuators) needs to be checked prior to flight, ensuring a full functional check of a system, other than just checking for availability of the ignition system only. This is done by providing a Lane select switching system (not engine type design) to each HIC of the engine system. Ignition switching needs to be interpreted as part of the Lane select switching system which should be in line with the intent of certification specifications.

The two Lane select switching systems are switchable independently (redundant HIC) and just foreseen for engine related functions including ignition. Appropriate separation from other aircraft electrical circuits is required as it might also be defined by aircraft certification specifications. Inadvertent operation of an ignition system needs to be implemented per the design of the Lane select switching system on aircraft level.

# BRP-Rotax INSTALLATION MANUAL

## **FAILURE BEHAVIOR AND WARNING ANNUNCIATION TO THE PILOT**

Prediction of pilot action in the case of engine failure is not possible to the engine system designer entirely, since this may vary with actual conditions arising from installation in a specific aircraft (SRE, MRE, type of aircraft, Operational conditions, etc.). It seems more appropriate to provide a detailed description of the engine system behavior in the case of failures to empower the installer to derive pilot action related to the current installation situation. It must be noted that the information provided in the following section is an extract of supposable failure scenarios with the intention to just indicate information relevant to the installer.

The EMS comprises redundant controllers (ECU) which facilitate different system modes. These system modes are Auto\_AB which is the common operation mode and Auto\_A, Auto\_B, Only\_A, Only\_B, which are alternate system modes. The alternate system modes are engaged either during pre-flight checks or during presence of faults/failures. It is important to understand that each mode is capable providing full control over the engine, respectively providing full power/thrust from the engine. The control modes just differ in efficiency of engine operation.

The ECU distinguishes between fault and failures, whereas a fault prescribes a scenario of low severity, not causing system mode change. A failure leads to a system mode change. The presence of a fault is indicated by a flashing warning lamp. The presence of a failure is indicated by warning lamp which is permanent on. Each individual Lane is equipped with a warning lamp.

The system is equipped with a redundant Display CAN interface for annunciation of a broad range of engine data additionally.



**BRP-Rotax**  
INSTALLATION MANUAL

**SIMPLIFIED EMS MATRIX 915 I A SERIES**

<b>Item (Failure/Fault)</b>	<b>System</b>	<b>Affect-ed Lane</b>	<b>Warn-ing Lamp A</b>	<b>Warning Lamp B</b>	<b>System Mode</b>	<b>Engine effect</b>
Crankshaft Position Sensor (CPS)	Sensor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection
Crankshaft Position Sensor (CPS)	Sensor	B	OFF	ON	Auto_A	No change of engine power; single ignition and single injection
Manifold Air Pressure Sensor (MAPS)	Sensor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection
Manifold Air Pressure Sensor (MAPS)	Sensor	B	OFF	ON	Auto_A	No change of engine power; double ignition and single injection
Manifold Air Temperature Sensor (MATS)	Sensor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection
Manifold Air Temperature Sensor (MATS)	Sensor	B	OFF	ON	Auto_A	No change of engine power; double ignition and single injection
Throttle Position	Sensor	A	flashing	OFF	Auto_AB	No change of engine power; double ignition and single injection
Throttle Position (in range failure)	Sensor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection
Ambient Air Pressure Sensor (AAPS)	Sensor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection
Ambient Air Pressure and Temperature Sensor (AAPTS)	Sensor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection

**BRP-Rotax**  
INSTALLATION MANUAL

Item (Failure/ Fault)	System	Affect- ed Lane	Warn- ing Lamp A	Warning Lamp B	System Mode	Engine effect
Ambient Air Temperature	Sensor	A	flashing	OFF	Auto_AB	No change of engine power; double ignition and single injection
Coolant Temperature Sensor (CTS)	Sensor	A	flashing	OFF	Auto_AB	No change of engine power; double ignition and single injection
EGT (1-4)	Sensor	A	flashing	OFF	Auto_AB	No change of engine power; double ignition and single injection
Knock	Sensor	A	flashing	OFF	Auto_AB	No change of engine power; double ignition and single injection
Display CAN A	Annun- ciation	A	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection
Display CAN B	Annun- ciation	B	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection
Maintenance CAN Lane A	Data Bus	A	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection
Maintenance CAN Lane B	Data Bus	B	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection
Coil 1/3	Actua- tor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection
Coil 2/4	Actua- tor	B	OFF	ON	Auto_A	No change of engine power; single ignition and single injection; Double ignition control mode intended in Auto_A but one ignition failed, therefore single ignition in effect
Injector 1/2/ 3/4 (INJ)	Actua- tor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection

**BRP-Rotax**  
INSTALLATION MANUAL

Item (Failure/Fault)	System	Affect- ed Lane	Warn- ing Lamp A	Warning Lamp B	System Mode	Engine effect
Injector 5/6/ 7/8 (INJ)	Actua- tor	B	OFF	ON	Auto_A	No change of engine power; double ignition and single injection
Warning Lamp (WL)	Annun- ciation	A	OFF	OFF	Auto_AB	No change of engine power; double ignition and single in- jection; Check immediately with display or during next en- gine start (Warning lamp check)
Warning Lamp (WL)	Annun- ciation	B	OFF	OFF	Auto_AB	No change of engine power; double ignition and single in- jection; Check immediately with display or during next en- gine start (Warning lamp check)
Oil Tempera- ture Sensor (OTS)	Sensor	B	OFF	flashing	Auto_AB	No change of engine power; double ignition and single injection
Oil Pressure Sensor (OPS)	Sensor	B	OFF	flashing	Auto_AB	No change of engine power; double ignition and single injection
Loss of EMS Ground Port	Power Supply	A	ON	OFF *(ON)	Only_B	No change of engine power; single ignition and single injection *) if system electric fuel pump supply is used the following applies: No change of engine power; single ignition and sin- gle injection if both fuel pumps are ON (Take-off/Landing procedure)
Loss of EMS Ground Port	Power Supply	B	OFF	ON	Only_A	No change of engine power; single ignition and single injection
Power Sup- ply ECU Lane A	Power Supply	A	ON	OFF	Only_B	No change of engine power; single ignition and single injection
Power Sup- ply ECU Lane B	Power Supply	B	OFF	ON	Only_A	No change of engine power; single ignition and single injection

**BRP-Rotax**  
INSTALLATION MANUAL

Item (Failure/Fault)	System	Affect-ed Lane	Warn-ing Lamp A	Warning Lamp B	System Mode	Engine effect
Generator Selector	Power Supply	-	flashing	flashing	Auto_AB	No change of engine power; double ignition and single injection; Automatic switch from Generator A to Generator B, no charging of aircraft battery if Generator B is the only charging source
Generator A	Power Supply	-	flashing	flashing	Auto_AB	No change of engine power; double ignition and single injection; ECU performs automatic change to Generator B; in addition check via display and/or current gauge; no charging of aircraft battery if Generator B is the only charging source
Generator B	Power Supply	-	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection; no charging of aircraft battery if Generator B is the only charging source. Additional description: In common operation both ECU Lanes monitor the active power supply system, in this case System A (Generator A). Important: ECU does not recognize power supply system B failure in this common operating state. Check is done during next engine start. Immediate check can be done with Ampere/Voltage indication in aircraft.
Rectifier regulator A	Power Supply	-	flashing	flashing	Auto_AB	No change of engine power; double ignition and single injection; ECU performs automatic change to Generator B; in addition check via display and/or current gauge; no charging of aircraft battery if Generator B is the only charging source

**BRP-Rotax**  
INSTALLATION MANUAL

Item (Failure/Fault)	System	Affect-ed Lane	Warn-ing Lamp A	Warning Lamp B	System Mode	Engine effect
Rectifier regulator B	Power Supply	-	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection; no charging of aircraft battery if Generator B is the only charging source. See additional description "Generator B".
Specific Failures within Fusebox (Capacitors, Fuses, Relays...) leading to Generator change (to Generator B)	Power Supply	-	flashing	flashing	Auto_AB	No change of engine power; double ignition and single injection; ECU performs automatic change to Generator B; in addition check via display and/or current gauge; no charging of aircraft battery if Generator B is the only charging source
Specific Failures within Fusebox (Capacitors, Fuses, Relays...) leading to loss of electric power supply system Generator B	Power Supply	-	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection; no charging of aircraft battery if Generator B is the only charging source. See additional description "Generator B".
Boost Pressure Sensor (BPS)	Sensor	A	ON	OFF	Auto_B	No change of engine power; single ignition and single injection
Boost Pressure Sensor (BPS)	Sensor	B	OFF	ON	Auto_A	No change of engine power; double ignition and single injection
Ambient Air Pressure Sensor (AAPS)	Sensor	B	OFF	ON	Auto_A	No change of engine power; double ignition and single injection
Pressure Control Valve (PCV)	Actuator	A	ON	OFF *(ON)	Auto_B	No change of engine power; single ignition and single injection; *) 915 iSc A provides electric power supply to PCV and

**BRP-Rotax**  
INSTALLATION MANUAL

Item (Failure/ Fault)	System	Affect- ed Lane	Warn- ing Lamp A	Warning Lamp B	System Mode	Engine effect
						main fuel pump from same fuse box output. If system electric fuel pump supply is used and power supply to PCV/Main fuel pump fails the following applies: No change of engine power; single ignition and single ignition if both fuel pumps are ON (Take-off / Landing procedure) IFSD in cruising if only one fuel pump (Main) is ON >>Normal Emergency Procedure (Engine Re-Start) >> Both WL are activated because of engine stall. WL activation is irrelevant because engine and annunciation stops immediately.
Pressure Control Valve (PCV)	Actua- tor	B	OFF	ON	Auto_A	No change of engine power; double ignition and single injection
Overboost Pressure Control Valve (OBV)	Actua- tor	A	flashing	OFF	Auto_AB	No change of engine power; double ignition and double injection
Lane Select Switch A	Power Supply	A	ON	OFF	Only_B	No change of engine power; single ignition and single injection
Lane Select Switch B	Power Supply	B	OFF	ON	Only_A	No change of engine power; single ignition and single injection
Fuel pump 1 (Main)	Fuel system	-	OFF * (ON)	OFF *(ON)	Auto_AB	No change of engine power; single ignition and single ignition if both fuel pumps are ON (Take-off / Landing procedure) IFSD in cruising if only one fuel pump (Main) is ON >>Normal Emergency Procedure (Engine Re-Start) >> Both WL are activated because of engine stall. WL activation is irrelevant because engine and annunciation

**BRP-Rotax**  
INSTALLATION MANUAL

Item (Failure/ Fault)	System	Affect- ed Lane	Warn- ing Lamp A	Warning Lamp B	System Mode	Engine effect
						stops immediately. See also dependence of electric power supply associated with PCV.
Fuel pump 2 (Aux)	Fuel system	-	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection; Check during next engine start
Fuel pump 1 switching system (Main)	Fuel system	-	OFF * (ON)	OFF *(ON)	Auto_AB	No change of engine power; single ignition and single ignition if both fuel pumps are ON (Take-off / Landing procedure) IFSD in cruising if only one fuel pump (Main) is ON >>Normal Emergency Procedure (Engine Re-Start) >> Both WL are activated because of engine stall. WL activation is irrelevant because engine and annunciation stops immediately. See also dependence of electric power supply associated with PCV.
Fuel pump 2 switching system (Aux)	Fuel system	-	OFF	OFF	Auto_AB	No change of engine power; double ignition and single injection; Check during next engine start
Start switching system	Starting system	-	OFF *(flashing)	OFF	Auto_AB	1) If failure occurs during engine run: No change of engine power; double ignition and double injection. *) 915 iSc A provides electric power supply to OBV and starting system from the same fuse box output. If system electric starting supply is used and power supply to OBV / Starting system fails the following applies: additional to 1) OBV fault and WL A flashing
Starter Relay	Starting system	-	OFF	OFF	Auto_AB	No change of engine power; double ignition and double injection; no effect on EMS / ECU; Failure detection at next

**BRP-Rotax**  
INSTALLATION MANUAL

Item (Failure/Fault)	System	Affect-ed Lane	Warn-ing Lamp A	Warning Lamp B	System Mode	Engine effect
						engine start, Engine (Re-) Start not possible.
Start Power Switching System	Power up system	-	OFF	OFF	Auto_AB	No change of engine power (unless windmilling); double ignition and double injection; no effect on EMS / ECU
Battery Back-up Switching System	Backup PS	-	OFF	OFF	Auto_AB	No change of engine power; double ignition and double injection; no effect on EMS / ECU



# BRP-Rotax INSTALLATION MANUAL

## **HYPOTHESIS ON WARNING LAMP EXECUTION IN THE AIRCRAFT**

Aircraft Certification Specifications and related guidance call out for lamp indication colors RED in the case of a warning, YELLOW/AMBER in the case of a caution, GREEN in the case of safe operation. Whereas RED calls out for immediate crew action and YELLOW/AMBER indicates degraded conditions without immediate crew action.

For the 915 i A Series the warning lamp color is not mandated in the engine Installation Manual.

As shown in the extract of supposable failure scenarios (see previous sections), the EMS provides an automatic reaction in the case of faults/failures, still producing sufficient power/thrust in a relevant critical flight phase. The transition to an alternate mode does not implicate manual pilot action. The warning annunciation through the warning lamps indicates the state of an individual Lane. Based on these facts the meaning of warning Lamp indication is to be associated with YELLOW/AMBER entirely. The differentiation between flashing and permanent ON can be ignored in a straight forward approach in terms of ease of interpretation.

The indication of a flashing lamp allows for additional differentiation of the failure severity if desired. A warning lamp that is “just flashing” does not lead to a system mode change. This means even in the case of an additional failure the system provides an alternate system mode.

If flashing lamps are not acceptable the flashing must be filtered at the installers discretion.

If the approach described in the previous section is not found to be acceptable (use just YELLOW/AMBER) the warning lamp signals from the ECU will need to be converted at the installers discretion.

# BRP-Rotax INSTALLATION MANUAL

## **SYSTEM AVAILABILITY AND RELIABILITY**

In the course of development and certification, the 915 i A Series has been assessed in terms of safety and reliability. The system is essentially single fault tolerant with respect to LOPC/LOTC. This means there's an existing (small) number of single faults which can lead to LOPC/LOTC. However, these failure modes in combination with other existing failure modes are in line with the reliability targets on engine level, which is associated with the term "essentially single fault tolerant".

Following systems are beyond the scope of the engine EMS (not Engine Type Design) but are relevant interface considerations in the course of the engine FTA. Therefore probability rates have been budgeted and are provided here within for installation guidance. These budgeted rates represent conservative reliability numbers and should be well achievable.

**For 915 i A Series , assuming that electrical/electronic fuel pumps are used and powered from the engine EMS:**

FTA Top Event "LOPC – Loss of Power Control"

- "Battery Backup Fault": The budgeted LOPC FTA probability rate is 1E-4 (failure mode description: no or insufficient backup power supply)
- "Lane Select Switching System Fault": The budgeted LOPC FTA probability rate for a single lane select switching system is 1E-4 (failure mode description: no or insufficient power supply through lane select switching system). Two independent lane select switching systems are required
- "Electrical/electronic fuel pump switching system Fault" is 1E-4 (failure mode description: no or insufficient power supply to fuel pump through switching system). Two independent fuel pump switching systems are required

FTA Top Event "ISDE – Inability to shutdown engine"

- "Fuel Shut Off Valve": The budgeted ISDE FTA probability rate is 1E-4 (failure mode description: fuel shut off valve permanent on/open)
- "Electrical/electronic fuel pump switching system fault": The budgeted ISDE FTA probability rate of a single electrical/electronic fuel pump switching system is 1E-4 (failure mode description: fuel pump switching system fails to open). Two independent fuel pump switching systems are required
- "Lane Select switching system fault": The budgeted ISDE FTA probability rate of a single lane select switching system is 1E-4 (failure mode description: lane select switching system fails to open). Two independent lane select switching systems are required

**BRP-Rotax**  
INSTALLATION MANUAL

**ELECTRICAL BONDING**

The engine's frame/body is connected to the airframe and there is no floating potential all the time.

The EMS GND is electrically isolated during flight. The engine system is not susceptible to, nor a source of electrostatic discharge. The EMS is most likely located aircraft internally and charging activity is expected to be low (static charge increases with air velocity and friction effect). The electrical system provides a finite working resistance (MOhm range) which is electrically dissipative in terms of electrostatic charge. Charging effect is therefore expected to be low if any.

**BRP-Rotax**  
INSTALLATION MANUAL

INTENTIONALLY LEFT  
BLANK

# BRP-Rotax INSTALLATION MANUAL

## Index

### A

Abbreviations.....	6
Air cooling interfaces .....	7
Approval of electric and electronic components .....	19
Auxiliary equipment.....	5

### B

Battery .....	11
Bypass line.....	9

### C

CAN interfaces.....	10
Coarse filter .....	10
Components .....	8
constant speed propeller.....	8
Control elements.....	12
Conversion table.....	11
Coolant .....	11
Coolant hoses.....	10
Coolant, Boiling point.....	11
Crankcase pressure measurement.....	16

### E

Electrical bonding.....	17
Electrical interfaces .....	4, 9, 5, 4
Engine starting, Start power switching system and Starting system .....	4
Engine suspension.....	12
Engine, Handling.....	4
Engine, Preservation .....	4
Engine, Storage .....	4
Engine, Unpacking .....	4
Exhaust tail pipe.....	5
Expansion tank .....	10

### F

Failure behavior and Warning annunciation to the pilot.....	6
Filling and purging the oil system .....	13
Fine filter .....	10
Fuel interfaces .....	5
Fuel lines.....	9

Fuel pressure regulator.....	11
Fuel pressure sensor.....	11
Fuel pump .....	11
Fuel pump Switch.....	14
Fuel pumps and power supplies .....	3
Fuel shut off valve .....	12
Fuel system, overview .....	8
Fuel tank .....	11

### G

Gascolator.....	10
General.....	2
Grounding cables.....	10

### H

Handling the engine .....	7
Hypothesis on warning lamp execution in the aircraft .....	15

### I

Inlet line.....	9
Installation notes .....	10, 7, 11
Installation overview .....	10, 9, 12, 8, 11, 5
Instruction .....	15
Interface description .....	4, 9, 5, 4
Interface overview .....	4, 5, 4, 5

### L

Lane Select Switch.....	13
Lane select switching system – Ignition switching .....	5
List of effective pages .....	1

### M

Mechanical interfaces.....	9, 6, 9, 6, 10, 5
----------------------------	-------------------

### O

Oil lines .....	11
Oil pressure sensor .....	1
Oil pump.....	8
Oil tank.....	7

**BRP-Rotax**  
**INSTALLATION MANUAL**

Operational and Installation Considerations .....	1	System Description .....	3
		System limitations .....	3, 6, 3, 4, 3
		System Limitations .....	3
<b>P</b>			
Pneumatic interfaces .....	7		
Positive terminal .....	4		
Propeller governor, hydraulic .....	8		
<b>R</b>			
Return line .....	9		
RTCA/DO-160 .....	19		
<b>S</b>			
Safety .....	12		
Safety information .....	13		
Scope .....	2		
Scope of supply .....	4		
Simplified EMS Matrix 915 i Series .....	7		
Start button .....	14		
System availability and reliability .....	16		
System description .....	3, 4		
		<b>T</b>	
		Table of amendments .....	1
		Technical documentation .....	17
		Terms .....	6
		Type description .....	3
		<b>V</b>	
		Validation of installation .....	13, 12, 16, 7
		<b>W</b>	
		Warning lamp .....	10
		Water inlet elbow .....	9
		Water inlet, Water outlet .....	5
		Water trap .....	10
		Wiring .....	5
		Wiring color codes .....	10





\_\_\_\_\_

Engine serial no.

\_\_\_\_\_

Type of aircraft

\_\_\_\_\_

Aircraft registration no.

ROTAX® authorized distributor

