

# OPERATORS MANUAL

FOR ROTAX ENGINE TYPE 915 i A / C24 SERIES



51515

REF NO.: OM-915 i A / C24 | PART NO.: 898851

### 

Before starting the engine, read the Operators Manual, as it contains important safety relevant information. Failure to do so may result in personal injuries including death. Consult the original eq uipment manufactur-ers handbook for additional instructions!

These technical data and the information embodied therein are the property of BRP-Rotax GmbH & CO KG, Austria, acc, BGBI 1984 no. 448, and shall not, without prior written permission of BRP-Rotax GmbH & Co KG, be disclosed in whole or in part to third parties. This legend shall be included on any reproduction of these data, in whole or in part. The Manual must remain with the engine/aircraft in case of sale.

 $ROTAX_{\odot}$  is a trade mark of BRP-Rotax GmbH & Co KG. In the following document the short form of BRP-Rotax GmbH & Co KG = BRP-Rotax is used. Other product names in this documentation are used purely for ease of identification and may be trademarks of the respective company or owner.

Copyright 2021 © - all rights reserved.

Translation into other languages might be performed in the course of language localization but does not lie within ROTAX® scope of responsibility. In any case the original text in English language and the metric units are authoritative.

# **Table of Content**

Chapter	INTRO – Introduction
Chapter	LEP – LIST OF EFFECTIVE PAGES
Chapter	<b>TOA</b> – Table of amendments
Chapter	1 – General note
Chapter	2 – Operating instructions
Chapter	3 – Standard operation
Chapter	4 – Abnormal operation
Chapter	5 – Performance and Fuel consumption
Chapter	7 – System Description
Chapter	8 – Preservation and storage
Chapter	9 – Supplement
Chapter	<b>10</b> – Proper disposal

#### INTENTIONALLY LEFT BLANK

# **INTRO)** Introduction

#### Topics in this chapter

Foreword	BRP-Rotax GmbH & Co KG (hereinafter "BRP-Rotax") provides "Instructions for Continued Airworthiness", which are based on the design, tests and certification of the engine and its components. These instructions apply only to engines and components supplied by BRP-Rotax.
	Before operating the engine, read this Operators Manual carefully. If any passages of the Manual are not clearly understood or in case of any questions, please contact our ROTAX® Authorized Distributors or their independent Service Centers.
	This Operators Manual contains important information about safe operation of the engine together with descriptions of the systems, technical data, operating media and the operational limits of the engine.
	The specified information and procedures apply only to the engine and not to specific applications in particular aircraft. The aircraft manufacturers Operators Manual is therefore definitive in terms of the operation of the engine, as it contains all of the aircraft-specific instructions
	BRP-Rotax wishes you much pleasure and satisfaction flying your aircraft powered by this ROTAX® aircraft engine.
Document structure	The structure of the Manual follows whenever it is possible the structure of the "GAMA Specification #1 for Pilot's Operating Handbook".

#### INTENTIONALLY LEFT BLANK

# LEP) LIST OF EFFECTIVE PAGES

Each new revision to the Operators Manual will have a new List of Effective Pages.

cover page         4         July 01 2021           INTRO         1         July 01 2021         5         July 01 2021           2         July 01 2021         6         July 01 2021           2         July 01 2021         7         July 01 2021           1         July 01 2021         8         July 01 2021           2         July 01 2021         9         July 01 2021           1         July 01 2021         10         July 01 2021           1         July 01 2021         1         July 01 2021           1         July 01 2021         3         1         July 01 2021           1         July 01 2021         3         July 01 2021         2         July 01 2021           1         July 01 2021         3         July 01 2021         3         July 01 2021           3         July 01 2021         4         July 01 2021         4         July 01 2021           4         July 01 2021         5         July 01 2021         5         July 01 2021           4         July 01 2021         8         July 01 2021         7         July 01 2021           5         July 01 2021         8         July 01 2021         9         J	Chapter	Page	Date	Chapter	Page	Date
Judge         5         July 01 2021           INTRO         1         July 01 2021         6         July 01 2021           2         July 01 2021         7         July 01 2021           2         July 01 2021         8         July 01 2021           2         July 01 2021         8         July 01 2021           1         July 01 2021         9         July 01 2021           1         July 01 2021         10         July 01 2021           1         July 01 2021         3         July 01 2021           1         July 01 2021         3         July 01 2021           1         July 01 2021         3         July 01 2021           2         July 01 2021         3         July 01 2021           3         July 01 2021         3         July 01 2021           4         July 01 2021         5         July 01 2021           5         July 01 2021         6         July 01 2021           6         July 01 2021         8         July 01 2021           9         July 01 2021         9         July 01 2021           9         July 01 2021         10         July 01 2021           10         July 01 2021 <td></td> <td>cover</td> <td></td> <td></td> <td>4</td> <td>July 01 2021</td>		cover			4	July 01 2021
INTRO         1         July 01 2021         6         July 01 2021           2         July 01 2021         7         July 01 2021           2         July 01 2021         8         July 01 2021           2         July 01 2021         9         July 01 2021           10         July 01 2021         10         July 01 2021           1         July 01 2021         10         July 01 2021           1         July 01 2021         3         1         July 01 2021           1         July 01 2021         3         July 01 2021         3         July 01 2021           3         July 01 2021         3         July 01 2021         4         July 01 2021           3         July 01 2021         5         July 01 2021         5         July 01 2021           6         July 01 2021         6         July 01 2021         6         July 01 2021           7         July 01 2021         8         July 01 2021         9         July 01 2021           9         July 01 2021         10         July 01 2021         10         July 01 2021           10         July 01 2021         10         July 01 2021         10         July 01 2021	INTER	page			5	July 01 2021
2         July 01 2021         7         July 01 2021           1         July 01 2021         8         July 01 2021           2         July 01 2021         9         July 01 2021           1         July 01 2021         10         July 01 2021           2         July 01 2021         10         July 01 2021           1         July 01 2021         2         July 01 2021           1         July 01 2021         2         July 01 2021           3         July 01 2021         3         July 01 2021           3         July 01 2021         3         July 01 2021           3         July 01 2021         4         July 01 2021           4         July 01 2021         5         July 01 2021           6         July 01 2021         6         July 01 2021           7         July 01 2021         8         July 01 2021           8         July 01 2021         8         July 01 2021           9         July 01 2021         10         July 01 2021           10         July 01 2021         10         July 01 2021           11         July 01 2021         11         July 01 2021           11         July 01	INTRO	1	July 01 2021		6	July 01 2021
LEP       1       July 01 2021       8       July 01 2021         2       July 01 2021       9       July 01 2021         1       July 01 2021       10       July 01 2021         2       July 01 2021       1       July 01 2021         1       July 01 2021       3       1       July 01 2021         1       July 01 2021       3       July 01 2021       3       July 01 2021         3       July 01 2021       3       July 01 2021       3       July 01 2021         4       July 01 2021       5       July 01 2021       5       July 01 2021         5       July 01 2021       6       July 01 2021       6       July 01 2021         6       July 01 2021       7       July 01 2021       8       July 01 2021         7       July 01 2021       8       July 01 2021       8       July 01 2021         9       July 01 2021       9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021       11       July 01 2021         11       July 01 2021       12       July 01 2021       12       July 01 2021		2	July 01 2021		7	July 01 2021
2       July 01 2021       9       July 01 2021         1       July 01 2021       10       July 01 2021         2       July 01 2021       1       July 01 2021         1       July 01 2021       2       July 01 2021         2       July 01 2021       2       July 01 2021         3       July 01 2021       3       July 01 2021         3       July 01 2021       4       July 01 2021         4       July 01 2021       5       July 01 2021         5       July 01 2021       6       July 01 2021         6       July 01 2021       7       July 01 2021         7       July 01 2021       8       July 01 2021         9       July 01 2021       9       July 01 2021         10       July 01 2021       10       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         11       July 01 2021       11       July 01 2021         11       July 01 2021       12       July 01 2021	LEP	1	July 01 2021		8	July 01 2021
TOA       1       July 01 2021       10       July 01 2021         2       July 01 2021       3       1       July 01 2021         1       1       July 01 2021       2       July 01 2021         2       July 01 2021       3       July 01 2021         2       July 01 2021       3       July 01 2021         3       July 01 2021       4       July 01 2021         4       July 01 2021       5       July 01 2021         5       July 01 2021       6       July 01 2021         6       July 01 2021       7       July 01 2021         7       July 01 2021       8       July 01 2021         8       July 01 2021       8       July 01 2021         9       July 01 2021       10       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         11       July 01 2021       12       July 01 2021		2	July 01 2021		9	July 01 2021
2       July 01 2021       3       1       July 01 2021         1       July 01 2021       2       July 01 2021         2       July 01 2021       3       July 01 2021         3       July 01 2021       3       July 01 2021         4       July 01 2021       4       July 01 2021         5       July 01 2021       5       July 01 2021         6       July 01 2021       6       July 01 2021         7       July 01 2021       7       July 01 2021         7       July 01 2021       8       July 01 2021         8       July 01 2021       9       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       12       July 01 2021	ΤΟΑ	1	July 01 2021		10	July 01 2021
1       1       July 01 2021       2       July 01 2021         2       July 01 2021       3       July 01 2021         3       July 01 2021       4       July 01 2021         4       July 01 2021       5       July 01 2021         5       July 01 2021       6       July 01 2021         6       July 01 2021       6       July 01 2021         7       July 01 2021       7       July 01 2021         8       July 01 2021       8       July 01 2021         9       July 01 2021       9       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       12       July 01 2021		2	July 01 2021	3	1	July 01 2021
2       July 01 2021       3       July 01 2021         3       July 01 2021       4       July 01 2021         4       July 01 2021       5       July 01 2021         5       July 01 2021       6       July 01 2021         6       July 01 2021       7       July 01 2021         7       July 01 2021       8       July 01 2021         8       July 01 2021       8       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       12       July 01 2021	1	1	July 01 2021		2	July 01 2021
3       July 01 2021       4       July 01 2021         4       July 01 2021       5       July 01 2021         5       July 01 2021       6       July 01 2021         6       July 01 2021       7       July 01 2021         7       July 01 2021       8       July 01 2021         8       July 01 2021       9       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       12       July 01 2021		2	July 01 2021		3	July 01 2021
4       July 01 2021       5       July 01 2021         5       July 01 2021       6       July 01 2021         6       July 01 2021       7       July 01 2021         7       July 01 2021       8       July 01 2021         8       July 01 2021       9       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       12       July 01 2021		3	July 01 2021		4	July 01 2021
5       July 01 2021       6       July 01 2021         6       July 01 2021       6       July 01 2021         7       July 01 2021       8       July 01 2021         8       July 01 2021       9       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       July 01 2021       July 01 2021		4	July 01 2021		5	luly 01 2021
6       July 01 2021       7       July 01 2021         7       July 01 2021       7       July 01 2021         8       July 01 2021       8       July 01 2021         9       July 01 2021       9       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       July 01 2021		5	July 01 2021		6	July 01 2021
7       July 01 2021       8       July 01 2021         8       July 01 2021       9       July 01 2021         9       July 01 2021       10       July 01 2021         10       July 01 2021       10       July 01 2021         11       July 01 2021       11       July 01 2021         12       July 01 2021       July 01 2021		6	July 01 2021		7	July 01 2021
8     July 01 2021     9     July 01 2021       9     July 01 2021     10     July 01 2021       10     July 01 2021     11     July 01 2021       11     July 01 2021     12     July 01 2021       12     July 01 2021     12		7	July 01 2021		7	July 01 2021
9     July 01 2021     10     July 01 2021       10     July 01 2021     10     July 01 2021       11     July 01 2021     11     July 01 2021       12     July 01 2021     12		8	July 01 2021		0	July 01 2021
10     July 01 2021     10     July 01 2021       11     July 01 2021     11     July 01 2021       12     July 01 2021     12		9	July 01 2021		9	July 01 2021
11         July 01 2021         11         July 01 2021           12         July 01 2021         12         July 01 2021		10	July 01 2021		10	July 01 2021
12 July 01 2021		11	July 01 2021		11	July 01 2021
		12	July 01 2021		12	July 01 2021
13 July 01 2021		13	July 01 2021		13	July 01 2021
14 July 01 2021		14	July 01 2021		14	July 01 2021
15 July 01 2021		15 July 01 2021			15	July 01 2021
16 July 01 2021		16	July 01 2021		16	July 01 2021
17 July 01 2021	2	1	July 01 2021		17	July 01 2021
2 July 01 2021	~	2	luly 01 2021		18	July 01 2021
3 luly 01 2021		2	July 01 2021		19	July 01 2021

Chapter	Page	Date	Chapter	Page	Date
	20	July 01 2021		8	July 01 2021
	21	July 01 2021		9	July 01 2021
	22	July 01 2021		10	July 01 2021
	23	July 01 2021		11	July 01 2021
	24	July 01 2021		12	July 01 2021
4	1	July 01 2021		13	July 01 2021
	2	July 01 2021		14	July 01 2021
	3	July 01 2021		15	July 01 2021
	4	July 01 2021		16	July 01 2021
	5	July 01 2021		17	July 01 2021
	6	July 01 2021		18	July 01 2021
	7	July 01 2021		19	July 01 2021
	8	July 01 2021		20	July 01 2021
	9	July 01 2021		21	July 01 2021
	10	July 01 2021		22	July 01 2021
5	1	July 01 2021	8	1	July 01 2021
	2	July 01 2021		2	July 01 2021
	3	July 01 2021		3	July 01 2021
	4	July 01 2021		4	July 01 2021
7	1	July 01 2021	9	1	July 01 2021
	2	July 01 2021		2	July 01 2021
	3	July 01 2021	10	1	July 01 2021
	4	July 01 2021		2	July 01 2021
	5	July 01 2021		Index	
	6	July 01 2021		rear page	
	7	July 01 2021	L	P-32	

# TOA) Table of amendments

Approval\* at of this document is approved under the author

The technical content of this document is approved under the authority of the DOA ref. EASA.21J.048.

Revision 1 June 01 2019

Revision 2 Dec. 01 2020

Obsolete with Revision 3, which is a complete re-revision

Revision 3 July 01 2021

rev. no.	chapter	page	date of change	remark for appro- val	date of appro- val from authori- ties	date of inclu- sion	signa- ture
0	INTRO	all	Dec. 01 2017	DOA*			
0	LEP	all	Dec. 01 2017	DOA*			
0	ТОА	all	Dec. 01 2017	DOA*			
0	1 up to 10	all	Dec. 01 2017	DOA*			

rev. no.	chap- ter	page	date of change	remark for appro- val	date of appro- val from au- thori- ties	date of inclu- sion	signa- ture
1	LEP	all	June 01 2019	DOA*			
1	ΤΟΑ	all	June 01 2019	DOA*			
1	1	1–14	June 01 2019	DOA*			
1	3	3–13, 3–16 up to 3–20	June 01 2019 June 01 2019	DOA* DOA*			
1	4	4–3, 4–4	June 01 2019 June 01 2019	DOA* DOA*			
1	5	5–2	June 01 2019	DOA*			

rev. no.	chap- ter	page	date of change	remark for appro- val	date of appro- val from au- thori- ties	date of inclu- sion	signa- ture
1	7	7–2, 7–3, 7–8 7–17	June 01 2019 June 01 2019 June 01 2019 June 01 2019	DOA* DOA* DOA* DOA*			
1	8	8–1	June 01 2019	DOA*			

rev. no.	chap- ter	page	date of change	remark for appro- val	date of appro- val from au- thori- ties	date of inclu- sion	signa- ture
2	LEP	all	Dec. 01 2020	DOA*			
2	ΤΟΑ	all	Dec. 01 2020	DOA*			
2	1	1–15	Dec. 01 2020	DOA*			
2	2	2–3 2–4	Dec. 01 2020 Dec. 01 2020	DOA* DOA*			
2	3	3–3 3–5 3–6 3–9 3-14	Dec. 01 2020 Dec. 01 2020 Dec. 01 2020 Dec. 01 2020 Dec. 01 2020 Dec. 01 2020	DOA* DOA* DOA* DOA* DOA*			
2 2	4 9	4–6 9–2	Dec. 01 2020 Dec. 01.2020	DOA* DOA*			

rev. no.	chap- ter	page	date of change	re- mark for appro- val	date of appro- val from au- thori- ties	date of inclu- sion	signa- ture
3	LEP	all	July 01 2021	DOA*			
3	ΤΟΑ	all	July 01 2021	DOA*			
3	1	1–15	July 01 2021	DOA*			

rev. no.	chap- ter	page	date of change	re- mark for appro- val	date of appro- val from au- thori- ties	date of inclu- sion	signa- ture
3	2	2–3, 5	July 01 2021	DOA*			
3	3	3–6 up	July 01 2021	DOA*			
3		to 3–10	July 01 2021	DOA*			
3	4	all	July 01 2021	DOA*			
3	7	7–4,	July 01 2021	DOA*			
3		7–11	July 01 2021	DOA*			
3		7–14	July 01 2021	DOA*			
3	8	8–2	July 01 2021	DOA*			

#### Summary of amendments

Summary of the relevant amendments in this context, but without any claim to completeness.

rev no.	chap- ter	page	date of change	comments
1 1 1 1	1 3 4 5	1–14 3–18 4–3 5–2	June 01 2019 June 01 2019 June 01 2019 June 01 2019	New configuration 2 Fuel pump check: Text correction New: EMS Warning lamps Performance data and fuel consumption: Text correction
1	7	7–3 7–8 7–17	June 01 2019 June 01 2019 June 01 2019	New figure New figure New text

rev no.	chap- ter	page	date of change	comments
2	1	1–15	Dec. 01 2020	Text change
2	2	2–3	Dec. 01 2020	Text change
2		2–4	Dec. 01 2020	Text change
2	3	3–3	Dec. 01 2020	New figure
2		3–5	Dec. 01 2020	Text change
2		3–6	Dec. 01 2020	Text change
2		3–9	Dec. 01 2020	New diagram
2		3–14	Dec. 01 2020	Text change
2	4	4–6	Dec. 01.2020	Text change
2	9	9–2	Dec. 01 2020	New form

rev no.	chap- ter	page	date of change	comments
3 3 3 3 3 3 3 3 3	1 2 3 4 7	15 3, 4,6 6 up to 23 4–7 9 4,12,13 16	July 01 2021 July 01 2021	New additional designation of engine type (C24) New text Text change Text change Text change New figure Text change, New figure

# 1) General note

#### Topics in this chapter

1.1 General	2
1.2 Abbreviations and terms (depending on respective engine type)	3
1.3 Safety	8
1.4 Safety information	10
1.5 Technical documentation	13
1.6 Type description	15

# 1.1) General

Purpose

The purpose of this Operators Manual is to familiarize the aircraft manufacturers installing this aircraft engine with operating instructions and safety information.

This document is not intended for use by end customers (private aircraft owners, flight schools...) for operating the engine. Due to various executions of engine installations, only the aircraft manufacturer is able to provide end customers with operation and safety information tailored for a specific aircraft.

Nevertheless, all provided information in this Operators Manual (such as operating limits, safety information, operation instructions...) must be adhered to. The aircraft manufacturer is obliged to forward this information to the end customer in an appropriate way (e.g. within the aircraft specific Operators Manual).

For detailed information related to aircraft and aircraft/engine installation, maintenance, safety or flight operation, consult the documentation provided by the aircraft manufacturer and/or its dealer.

For additional information on engines, their maintenance or parts, you can also contact your nearest ROTAX® authorized aircraft engines distributor or their independent Service Center.

Engine serial<br/>numberWhen making inquiries or ordering parts, always indicate the<br/>engine serial number. Due to continuous product improvement,<br/>engines of the same engine type might require different support<br/>and spare parts.

The engine serial number is located on top of the crankcase, behind the propeller gearbox.



Figure 1: Pos. 1: Engine serial number

# **1.2)** Abbreviations and terms (depending on respective engine type)

Abbrevia- tions	Description	
*	Reference to another section	
•	center of gravity	
٥	The drop symbol indicates use of sealing agents, ad- hesives or lubricants (only in the Maintenance Man- ual Heavy)	
°C	Degrees Celsius (Centigrade)	
°F	Degrees Fahrenheit	
rpm	Revolutions per minute	
А	Ampere	
AAPTS	Ambient Air Pressure Temperature Sensor	
AC	alternating current	
AD	Airworthiness Directives	
Ah	Ampere hour	
A/C	Aircraft	
AC-DC	EMS Modul voltage converter	
AR	as required	
assy.	assembly	
ASB	Alert Service Bulletin	
ACG	Austro Control GmbH	
ACL	Anti Collision Light	
API	American Petrol Institute	
ASTM	American Society for Testing and Materials	
ATA	Air Transport Association	
AWG	American Wire Gauge	
CAN	Controller Area Network	
CCS	Camshaft position sensor	
Coil 1–4	Ignition coils 1–4	
CPS 1+2	Crankshaft Position Sensor 1+2	

Abbrevia- tions	Description	
CSA	Constant Speed Actuator	
CTS	Cooling Temperature Sensor	
CW	clockwise	
CCW	counter-clockwise	
CGSB	Canadian General Standards Board	
DCDI	Dual Capacitor Discharge Ignition	
DC	direct current	
DOA	Design Organisation Approval	
DOT	Department of Transport	
EASA	European Aviation Safety Agency	
IM	Installation Manual	
ECU	Engine Control Unit	
EGT	Exhaust Gas Temperature	
INTRO	Introduction	
EMS	Engine Management System	
EMS GND	Engine system internal ground reference which is in- tended to be disconnected from aircraft common ground during flight	
EMC	Electromagnetic compatibility	
EN	European Standard	
ETFE	Ethylene Tetrafluoroethylene	
FAA	Federal Aviation Administration	
FAR	Federal Aviation Regulations	
FOD	Foreign object damage	
Fuse box	Power conditioning and distribution for the Engine Management System	
hr.	hours	
HIC A	Harness Interface Connector A	
HIC B	Harness Interface Connector B	
IAT	Indicated Air Temperature	
ICA	Instructions for Continued Airworthiness	

Abbrevia- tions	Description		
IFR	Instrument Flight Rules		
IFSD	In-flight-shutdown		
INJ 1–8	Injector 1–8		
IPC	Illustrated Parts Catalog		
ips	inch per second		
iRMT	independent ROTAX Maintenance Technician		
ISA	International Standard Atmosphere		
kg	Kilograms		
KNOCK	Knock sensor		
Lane A	System A of Engine Management System		
Lane B	System B of Engine Management System		
LOPC	Loss of power control		
MAPS 1 & 2	Manifold Air Pressure Sensor 1 & 2		
MATS 1 & 2	Manifold Air Temperature Sensor 1 & 2		
MON	Motor Octane Number		
MAG	Magneto Side		
Ν	Newton		
n.a.	not available		
NDT	Non Destructive Testing		
Nm	Newtonmeter		
NVFR	Night Visual Flight Rules		
OAT	Outside Air Temperature		
ОНМ	Overhaul Manual		
OHV	Over Head Valve		
OM	Operators Manual		
OPS	Oil Pressure Sensor		
OTS	Oil Temperature Sensor		
PCD	Pitch Circle Diameters		
PCV	Pressure Control Valve		

Abbrevia- tions	Description	
PMA	Permanent magnet alternator	
POA	Production Organisation Approval	
PS	Power supply	
PTFE	Polytetrafluoroethylene (Teflon)	
PTO	Power Take Off	
Rev.	Revision	
ROTAX®	is a trademark of BRP-Rotax GmbH & Co KG	
RON	Research Octane Number	
RON 424	ROTAX® Standard 424	
s.v.	still valid (only Illustrated Parts Catalog)	
S/N	Serial Number	
SAE	Society of Automotive Engineers	
SEP	Single Engine Piston	
SB	Service Bulletin	
SI	Service Instruction	
SI-PAC	Service Instruction Parts and Accessories	
SPST	Single pole single throw	
STP	Shielded twisted pair wire	
SL	Service Letter	
SMD	Surface Mounted Devices	
ТВО	Time Between Overhaul	
тс	Type certificate	
part no.	part number	
ΤΟΑ	Table Of Amendments	
TOC	Table Of Contents	
TPS	Throttle Position Sensor	
TSN	Time Since New	
TSNP	Time Since New Part	
TSO	Time Since Overhaul	
V	Volt	

Abbrevia- tions	Description
VFR	Visual Flight Rules
LEP	List of Effective Pages
MM	Maintenance Manual
MEP	Multi Engine Piston
Х3	Connector on Engine Management System wiring harness which serves as an interface for power supply
XXXX	shows the component serial number

# 1.3) Safety

	Although reading such information does not eliminate any haz- ards, it promotes understanding, and applying the information will promote correct use of the engine. Always apply common workshop safety rules.
	The information and descriptions of components and systems contained in this Manual are correct at the time of publication. BRP-Rotax maintains a policy of continuous improvement of its products without imposing upon itself any obligation to retrofit products previously manufactured.
Revisions	BRP-Rotax reserves the right to remove, replace or discontinue any design, specification, feature or other at any time, and with- out incurring obligation.
Measurement	Specifications are given in the SI metric system with the imperi- al and US customary measurement system equivalents in parenthesis.
Symbols used	This Manual uses the following symbols to emphasize particular information. This information is important and must be observed.

**▲ WARNING** 

Identifies an instruction which, if not followed, may cause serious injury or even fatal injury.

#### 

Identifies an instruction which, if not followed, may cause minor or moderate injury.

#### ATTENTION

Identifies an instruction which, if not followed, may severely damage the engine or could void any warranty.

#### NOTE

Indicates supplementary information which may be needed to fully complete or understand an instruction.

#### ENVIRONMENTAL NOTE

Environmental notes give you tips on environmental protection.

A revision bar outside the page margin indicates a change to text or graphic.

# 1.4) Safety information

Use for intended purpose

#### 

Non-compliance can result in serious injuries or death! Never fly the aircraft equipped with this engine at locations, air speeds, altitudes or in other situations which do not allow a successful no-power landing after sudden engine stoppage.

- This engine is not suitable for acrobatics (inverted flight, etc.). Flight attitudes outside the permissible limits are not allowed.
- This engine has exclusively been developed and tested for gyrocopter, pusher and tractor applications. In case of any other usage, the OEM is responsible for testing and the correct function of the engine.
- It should be clearly understood that the choice, selection and use of this particular engine on any aircraft is at the sole discretion and responsibility of the aircraft manufacturer, assembler and owner/user.
- Due to the varying designs, equipment and types of aircraft, BRP-Rotax grants no warranty on the suitability of its engine's use on any particular aircraft. Further, BRP-Rotax grants no warranty on this engine's suitability with any other part, components or system which may be selected by the aircraft manufacturer, assembler or user for aircraft application.

#### A WARNING

Non-compliance can result in serious injuries or death! For each use of DAY VFR, NIGHT VFR or IFR in an aircraft the applicable legal requirements and other existing regulations must be adhered to.

- Certain areas, altitudes and conditions present greater risk than others. The engine may require humidity or dust/sand preventative equipment, or additional maintenance may be required.
- You should be aware that any engine may seize or stall at any time. This could lead to a crash landing and possible severe injury or death. For this reason, we recommend strict compliance with the maintenance and operation and any additional information which may be given to you by your dealer.

Training	• Whether you are a qualified pilot or a novice, complete knowl- edge of the aircraft, its controls and operation is mandatory before a solo flight. Flying any type of aircraft involves a cer- tain amount of risk. Be informed and prepared for any situa- tion or hazard associated with flying.
	• A recognized training program and continued education for piloting an aircraft is absolutely necessary for all aircraft pi- lots. Make sure you also obtain as much information as possi- ble about your aircraft, its maintenance and operation from your dealer.
	• Engine-specific training courses are provided by the author- ized distributors according to manufacturer specifications (iRMT).
Regulations	<ul> <li>Respect all legal requirements or local rules pertaining to flight operation in your flying area. Only fly when and where conditions, topography, and airspeeds are safest.</li> </ul>
	<ul> <li>Consult your aircraft dealer or manufacturer and obtain the necessary information, especially before flying in new areas.</li> </ul>
Instrumentation	<ul> <li>Select and use proper aircraft instrumentation. This instrumentation is not included in the ROTAX® engine package.</li> <li>Verification to the latest regulations such as FAR or EASA has to be conducted by the aircraft manufacturer.</li> </ul>
Engine log book	<ul> <li>Keep an engine log book and respect engine and aircraft maintenance schedules. Keep the engine in top operating condition at all times. Do not operate any aircraft which is not properly maintained or has engine operating irregularities which have not been corrected.</li> </ul>
Maintenance (iRMT)	• Since special training, tools and equipment are required, en- gine servicing shall only be performed by an authorized ROTAX® aircraft engine distributor or their independent serv- ice center. BRP-Rotax requires that any service or mainte- nance work be carried out and verified by a technician that has a current iRMT rating.
	• When the engine will not be operated for a longer period pro- tect the engine and fuel system from contamination and envi- ronmental exposure.
Engine operation	<ul> <li>Never operate the engine without sufficient quantities of oper- ating fluids (oil, coolant, fuel).</li> </ul>
	Never exceed the maximum permitted operational limits.
	<ul> <li>In the interest of safety, the aircraft must not be left unat- tended while the engine is running.</li> </ul>

- To eliminate the risk of injury or damage, ensure any loose equipment or tools are properly secured before starting the engine.
- Allow the engine to cool at idle for several minutes before turning off the engine.

**Governor** • This engine may be equipped with a governor. The safety warning accompanying the governor must be given to the owner/operator of the aircraft into which the governor is installed.

### 1.5) Technical documentation

	These documents form the instructions ensuring continued air- worthiness of ROTAX® aircraft engines. The information contained herein is based on data and experi- ence that are considered applicable for authorized mechanics (iRMT, see Maintenance Manual Line) under normal conditions. Due to the fast technical progress and fulfillment of particular specifications of the customers it may occur that existing laws, safety prescriptions, constructional and operational regulations may not be sufficient or cannot be transferred completely to the object bought, in particular for special constructions.
Documentation	
	Installation Manual
	Operators Manual
	<ul> <li>Maintenance Manual (Line and Heavy Maintenance)</li> </ul>
	Overhaul Manual
	Illustrated Parts Catalog
	Alert Service Bulletins
	Service Bulletins
	Service Instructions
	Service Instruction–Parts and Accessories
	Service Letters
Status	The status of Manuals can be determined by checking the table of amendments. The first column of this table indicates the revi- sion status which should be compared with the revision pro- vided on the ROTAX®-Website: www.FLYROTAX.com Amendments and current versions can be downloaded free of change.
Replacement pages	Furthermore the Manual is constructed in such a way that single pages can be replaced instead of the complete document. The list of effective pages is given in the chapter LEP. The particular edition and revision number is given on the footer of each page.
Reference	Any reference to a document refers to the latest edition issued by BRP-Rotax if not stated otherwise.



This symbol informs you of additional references (data sheets, Manuals, etc.) associated with the given subject.

Illustrations

The illustrations in this Manual are merely sketches and show typical arrangements. They may not represent full detail or the exact shape of the parts but should outline the same or similar function. Therefore deriving dimensions or other details from illustrations is not permitted.

TYPICAL indicates a general view which may not represent exact details..

#### NOTE

The Illustrations in this Manual are stored in a graphic data base system and are provided with a consecutive irrelevant number.

This number (e.g. AE 5iS001) is of no significance for the content.

# 1.6) Type description

The type description consists of the following parts:



#### Designation

Designation		Description
Туре	915	4-cylinder horizontally opposed, turbo- charged engine.
Certification	iSc	Certified to EASA CS-E (TC No.EASA. E.121)
	iS	Approved to according ASTM F2339.
Configuration	2	Propeller shaft with flange for fixed pitch propeller.
	3	Propeller shaft with flange for constant speed propeller and drive for hydraulic governor for constant speed propeller.
Additional	Α	Standard version
designation	C24	24 Volt Board Net Supply Version

#### INTENTIONALLY LEFT BLANK

# 2) Operating instructions

#### Topics in this chapter

2.1 Operating limits	2
2.2 Operating media-Coolant	7
2.3 Operating media-Fuel	7
2.4 Operating media-Lubricants	8

Introduction	The operating limits for certified engines are also given in the type certificate for the relevant engine type. This chapter of the Operators Manual contains the operating limits that must be observed and adhered to while operating
	limits that must be observed and adhered to while operating this type of engine.

# 2.1) Operating limits

#### General

#### ATTENTION

Monitor Operating limits. Limits must not be exceeded. If one or more operating limits are exceeded, the engine must be operated so that the values fall back into the allowed range. Carry out instructions for abnormal operation

performance is measured under following boundary conditions:

- Standard engine (without governor). Without auxiliary equipment (e.g. external alternator)
- Installation in accordance with installation guidelines (e.g. intake and exhaust system). See latest Installation Manual
- ISA Condition(International Standard Atmosphere)

#### Engine speed

Parameter	Min.	Max.
Engine speed at idle	1800 rpm	_
Engine speed	_	5800 rpm (max. 5 minutes)

#### Performance

The engine performance is approximately proportional to the airflow value and can be calculated as follows: Observed Power [kW] ~-6.3264+0.0169\*Airflow [g/min]

Parameter	Min.	Max.
Take-off Performance (engine speed: 5800 rpm)	-	104 kW
Continuous Perform- ance (engine speed: 5500 rpm)	_	99 kW (without governor)
Critical Altitude (MAT: max. 50 °C (120 °F))	_	15000 ft

#### NOTE

The max. Continuous performance is available up to the critical altitude.

Parameter	Min.	Max.
Operating Altitude	-	23000 ft

The engine performance is approximately proportional to the air flow value.

The air flow information is available on the Display CAN Bus.

Acceleration

Limit of engine operation at zero gravity and in **negative "g"** condition.

Parameter	Min.	Max.
Acceleration	_	-0.5 g (max. 5 seconds)

#### Static roll angle

The dry sump lubrication system warrants lubrication in every flight situation

Parameter	Min.	Max.
Static roll angle ß	_	40°

Manifold temperature

915 Type A

Parameter	Min.	Max.
Manifold temperature	-	50 °C (122 °F)

Manifold temperature

#### 915 Type C24

Parameter	Min.	Max.
Manifold temperature (Note*)	_	50 °C (122 °F)
Extended Manifold temperature (Note**)	> 50 °C (122 °F)	80 °C (176 °F)

Note\* rated power performance is provided Note\*\* reduced power performance as provided in section "Extended Manifold Temperature Range – Power Performance Impact"

# Extended Manifold temperature range

#### 915 Type C24

#### Power Performance Impact

Power Performance	Continuous Performance	Take-Off Performance
Resulting Power reduction	- 1 kW	- 2.7 kW

#### Manifold pressure

Parameter	Min.	Max.
Manifold pressure	60 hPa (1.77 in. HG)	1730 hPa (51 in. HG)

#### NOTE

Target pressure at a temperature from 25 °C (77 °F) to 35 °C (95 °F): 5800 rpm 1520 mbar 5500 rpm 1450 mbar 1730 mbar is the "not to exceed" value which is needed by the boost pressure control in special situations (e.g. 75 °C (167 ° F)).

#### **Boost pressure**

Parameter	Min.	Max.
Boost pressure	ambient pressure	1730 hPa (51 in. HG)

#### **Oil pressure**

Parameter	
Normal operating range above 3500 rpm	2.0 to 5.0 bar (29 – 72.5 psi)
Minimum below 3500 rpm	0.8 bar (11.6 psi)
At cold start and warming up period (maximum)	7.0 bar (101.5 psi)

#### **Oil temperature**

Parameter	Min.	Max.
Engine start	-20 °C (-4 °F)	-
Take-off	50 °C (122 °F)	_
Normal operation	50 °C (122 °F)	130 °C (266 °F)

#### ATTENTION

Operating the engine below (90 to 110 °C / 194 to 230 °F) may lead to formation of condensation water in the lubrication system. To evaporate possibly accumulated condensation water, at least once a day 100 °C (212 °F) oil temperature must be reached.

# Coolant temperature

Parameter	Min.	Max.
Coolant temperature at ground idle, start procedure and warm up	-20 °C (-4 °F)	_
Coolant temperature at normal operation	_	120 °C (248 °F)

# Exhaust gas temperature.

Parameter	Min.	Max.
Exhaust gas temperature.	-	950 °C (1742 °F)

EGT-Split

EGT- Split is the difference between the actual highest EGT value of the actual lowest EGT value.

Parameter	Min.	Max.
EGT-Split at > 3 Liter/hour (Fuel consumption).	_	200 °C (392 °F)
EGT-Split at < 3 Liter/hour (Fuel consumption).	_	500 °C (932 °F)

#### Ambient temperature

Parameter	Min.	Max.
Ambient temperature at ground idle, start procedure and warm up.	-	50 °C (122 °F)
Ambient temperature at normal operation	- 40 °C (- 40 °F)	50 °C (122 °F)

#### Fuel pressure

Parameter	Min.	Max.
Fuel pressure at fuel rail	2.9 bar (42 psi)	3.2 bar (46 psi)
Acceptable Fuel pressure exceedance (max. 3 sec.)	2.5 bar (36 psi)	3.5 bar (51 psi)

### NOTE

Fuel pressure exceedance only allowed after power setting change.

# 2.2) Operating media-Coolant

	ATTENTION	
	Obey the latest edition of Service Instruction SI-915 i-001, for the selection of the correct operating media.	
Conventional coolant	Conventional coolant mixed with water has the advantage of a higher specific thermal capacity than waterless coolant.	
Application	When correctly applied, there is sufficient protection against va- por bubble formation, freezing or thickening of the coolant with- in the operating limits. Use the coolant specified in the manufacturers documentation.	
Mixture		

ATTENTION

Obey the operating media manufacturer's instructions!

### 2.3) Operating media-Fuel

#### ATTENTION

Obey the latest edition of Service Instruction SI-915 i-001, for the selection of the correct fuel.

#### ATTENTION

Use only fuel suitable for the respective climatic zone.

#### NOTE

Risk of vapour formation if using winter fuel for summer operation.

Antiknock properties

Fuels with following specification can be used:

	Usage/Description
Anti knock properties	915 iSc/iS
	Min. RON 95

#### NOTE

For fuels according to ASTM D4814 specifications following AKI (Anti Knock Index) value has to be observed: min. AKI 91.

	Usage/Description
MOGAS	915 iSc/iS
European standard	EN 228 super EN 228 super plus

AVGAS

AVGAS 100LL places greater stress on the valve seats due to its high lead content and forms increased deposits in the combustion chamber and lead sediments in the oil system.

	Usage/Description
AVGAS	915 iSc/iS
Aviation Standard	AVGAS 100 LL (ASTM D910)

### 2.4) Operating media-Lubricants

	ATTENTION
	<b>Obey the manufacturer's instructions about the lubricants.</b> If the engine is mainly run on AVGAS more frequent oil changes will be required. See Service Information SI-915 i-001, latest edition.
type	For the selection of suitable lubricants refer to the additional in- formation in the Service Information SI-915 i-001, latest edition.
consumption	Max. 0.06 l/h (0.13 liq pt/h)
specification	<ul> <li>Use only oil with RON 424 classification</li> </ul>
	NOTE
	The ROTAX® Norm 424 (RON 424) is a BRP-Rotax internal standard, which is only available on special request via the ROTAX® authorized distributor and will not be disclosed to third parties without prior consent.
	<ul> <li>Due to the high stresses in the reduction gears, oils with gear additives such as high performance motor cycle oils are required.</li> </ul>
	<ul> <li>Because of the incorporated overload clutch, oils with friction modifier additives are unsuitable as this could result in clutch slippage during normal operation.</li> </ul>
	<ul> <li>Heavy duty 4-stroke motor cycle oils meet all the require- ments. These oils are normally not mineral oils but semi- or full synthetic oils.</li> </ul>
	<ul> <li>Oils primarily for Diesel engines have insufficient high tem- perature properties and additives which favour clutch slipping, and are generally unsuitable.</li> </ul>
-------------------------	--
Oil viscosity	Use of multi-grade oils is recommended.
	NOTE
	Multi-viscosity grade oils are less sensitive to temperature var- iations than single grade oils. They are suitable for use throughout the seasons, ensure rapid lubrication of all engine components at cold start and get less fluid at higher temperatures.
Table of lubrication	Since the temperature range of neighboring SAE grades over- lap, there is no need for change of oil viscosity at short duration

of ambient temperature fluctuations.

climatic conditions	°¢	$\cap$	÷ ا	ı	nu	lti-	gr	ad	e c	oils	5
	40-		100								
tropical	<b>3</b> 0-		- <b>8</b> 0	0	0						
	<b>2</b> 0-		-60	0W-5	0W-4	50	40				
	10-			SAE 2	SAE 2	15W-	15W-	1-40	/-30	_	
temperate	temperate		- <b>4</b> 0	,		SAE	SAE	E 10V	E 10V	5W-50	5W-40
	0-							SA	SA	SAE	SAE (
	10-		-20								
arctic	20-		-0								
	20-										
	<b>3</b> 0-		20								

Figure 1: Temperature range

AE 2\_0064

#### INTENTIONALLY LEFT BLANK

# 3) Standard operation

### Topics in this chapter

3.1 Daily checks	2
3.2 Pre-flight checks	5
3.3 Engine start	6
3.4 After engine start	12
3.5 Engine run-up	13
3.6 Engine shut-off	22

Introduction To warrant reliability and efficiency of the engine, meet and carefully observe all the operating and maintenance instructions.

The following description of procedures depends on the respective type of installation in the aircraft and shall therefore only be seen functionally.

### NOTE

The control elements mentioned in this chapter are only symbolic and should support the understanding of the procedures. The execution of control elements is in the responsibility of the aircraft manufacturer.

# 3.1) Daily checks

Safety

To warrant reliability and efficiency of the engine, meet and carefully observe all the operating and maintenance instructions.

**▲ WARNING** 

Risk of burns and scalds! Hot engine parts! Conduct checks on cold engine only!

#### A WARNING

Non-compliance can result in serious injuries or death! When performing checks which do not require ignition make sure that the ECU is turned off and the aircraft is secured to prevent unwanted engine starts.

#### ATTENTION

If established abnormalities (e.g. excessive resistance of the engine, noise etc.) inspection in accordance with the relevant Maintenance Manual is necessary. Do not release the engine into service before rectification.

**Coolant level** 

#### ATTENTION

Operating media must be observed.

Inappropriate coolant quantity can lead to serious engine damage.

The specifications given in Chapter 2.2 must be adhered to when refilling coolant.

Step	Procedure
1	Verify coolant level in the <b>expansion tank</b> , replenish as required up to top. The max. coolant level must be flush with the bottom of the filler neck.
2	Verify coolant level in the <b>overflow bottle</b> , replenish as required. The coolant level must be between max. and min. mark.

#### ENVIRONMENTAL NOTE

#### Protect the environment!

Do not harm the environment by spilling coolant. Dispose coolant in an environmentally friendly manner.



AE 5iS 0070a



- 1 Radiator cap
- 2 Expansion tank



1 Overflow bottle 2 Coolant

#### Check of mechanical/electronic components.

# Mech./electronic components

Step	Procedure
1	Turn propeller slowly by hand in direction of engine rota- tion several times and observe engine for odd noises or excessive resistance and normal compression.
2	Verify free movement of throttle valve and the complete range.
3	Inspect for damages, leakage and general condition of exhaust system and turbocharger.
4	Visual inspection for mechanical and thermal damages of sensor, actuators and the wiring harness.
5	Visual inspection for mechanical and thermal damages of pressure control valve, fusebox and ECU.

# 3.2) Pre-flight checks

### Safety

Risk of burns and scalds! Hot engine parts! Conduct checks on cold engine only!	!

#### Operating media

Step	Procedure
1	Check for any oil-, coolant- and fuel leaks. If leaks are evident, rectify and repair them before next flight.

#### Oil level

#### ATTENTION

#### **Operating media must be observed.** Inappropriate oil quantity can lead to serious engine damage.

The specifications given in Chapter 2.4 must be adhered to when refilling oil.

Step	Procedure
1	Prior to oil level check, turn the propeller several times by hand in direction of engine rotation to pump all the oil from the engine to the oil tank.
2	This process is completed when air flows back to the oil tank. This air flow can be perceived as a murmur (gur-gling) when the oil tank cover of the oil tank is removed.
3	Pull out the oil dipstick.
4	The oil level in the oil tank should be between the two marks (max./min.) on the oil dipstick, but must never fall below the min. mark. During standard engine operation, the oil level should be mid-way between the max. and min. marks, as at higher oil level (over servicing), oil will escape via the venting passage. Difference between max and min mark = 0.60 I (1.268 liq pt).
5	Replenish oil as required.

Step	Procedure
6	Check oil level - Marks on the oil dipstick.
7	Fit the oil dipstick and tighten the oil tank cover by hand.

#### ENVIRONMENTAL NOTE

#### Protect the environment.

Do not harm the environment by spilling oil. Dispose of oil in an environmentally friendly manner.

# 3.3) Engine start

#### A WARNING

**Non-compliance can result in serious injuries or death!** Do not start the engine if any person is near the engine.

#### **Engine start**

Maintenance CAN Bus (A/B) must not be used during flight. B. U.D.S. aircraft USB-to-CAN converter must be disconnected.

Step	Step Description	Procedure
1	Engine Pre-heating (if necessary)	-
	Example (Symbolic)	_
2	Activate Fuel pumps	HIC A: A connection between Terminal 3 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal E and F, will power Fuel pump 1. HIC B: A connection between Terminal 3 and Terminal 11 at 915 i Type A, or at 915 i Type C24 AC-DC Convert- er Terminal X4.C and X4.D, will power Fuel pump 2.
	Example (Symbolic)	Fuel pump 1: <b>ON</b> Fuel pump 2: <b>ON</b>

#### ATTENTION

Only switch on one fuel pump when starting the engine. Switching on both fuel pumps can lead to a bad start behavior.

Step	Step Description	Procedure
3	Activate ECU	HIC A: A connection between Terminal 1 and Terminal 7 at 915 i Type A, or at 915 i Type C24 Terminal N and P, will power ECU Lane A. HIC B: A connection between Terminal 1 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal N and P, will power ECU Lane B.
	Example (Symbolic)	Lane select Switch A: <b>ON</b> Lane select Switch B: <b>ON</b>
4	Temporarily supply engine with external power supply	X3: A connection between Ter- minal 2 and Terminal 3 at 915 i Type A, or at 915 i Type C24 AC-DC Convert- er Terminal X2.C, and between airframe ground and EMS ground will activate Start Power. The temporary power supply must be maintained during steps 4, 5, 6.
	Example (Symbolic)	Start Power Switch: HOLD
5	Check if Warning In- dicators illuminate and extinguish after around 3 seconds.	HIC A: 12 V voltage drop be- tween Terminal 2 and Terminal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D for 3 seconds. HIC B: 12 V voltage drop be- tween Terminal 2 and Terminal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D for 3 seconds.
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check
6	Set Throttle Valve	Set linearized throttle position according to diagram section 3.3 Fig. Throttle position.
	Example (Symbolic)	Set Throttle.

Step	Step Description	Procedure
7	Check Caution lamp state 915 i Type C24	AC-DC converter: 24 V pro- vided to Terminal X2.C Caution Lamp: 14 V Output (EMS): <b>OFF</b> Caution Lamp: 28 V Output (AC): <b>ON</b> Caution Lamp: Start/Backup Power: <b>ON</b>
	Example (Symbolic)	Start Power Switch: HOLD

#### ATTENTION

Activate starter for maximum of 10 consecutive seconds only, followed by a cooling period of 2 minutes.

Step	Step Description	Procedure
8	Start Engine	HIC B: A connection between Terminal 4 and Terminal 12 at 915 i Type A, or at 915 i Type C24 Terminal G and H, actuates the starter. The connection must persist until the engine speed exceeds 1500 rpm.
	Example (Symbolic)	Start Power Switch: HOLD
9	Reduce Throttle Valve as required	Set linearized throttle position so that the engine runs on idle.
	Example (Symbolic)	Reduce Throttle.

### ATTENTION

Increasing engine speed is only permitted at steady oil pressure readings above 3 bar (43.5 psi).

Step	Step Description	Procedure
10	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected perform Lane and Igni- tion Check. See abnormal oper- ation if the voltage drop still persists. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected perform a Lane and Ignition Check. See abnormal operation if the voltage drop still persists. Display CAN A/B: Check if oil pressure has risen within 10 seconds after engine start and monitor oil pressure.
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check
11	Check state Caution lamps 915 i Type C24	"Procedure" AC-DC converter: 24 V drop to 0 Terminal X2.C. Caution Lamp: 14 V Output (EMS): <b>OFF</b> Caution Lamp. 28 V Output (AC): <b>ON</b> Caution Lamp: Start/Backup Power: <b>OFF</b>
	Example (Symbolic)	Start Power Switch: <b>OFF</b> Backup Battery Switch: <b>OFF</b> Engine running: >1700 rpm<2400 rpm
12	Generator Switching	Increase engine speed above 2400 rpm and hold for 8 seconds.
	Example (Symbolic)	Increase Throttle Position

Step	Step Description	Procedure
13	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. Display CAN A/B: Check and ensure compliance with opera- tional limits.
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check
14	Check state Caution lamps 915 i Type C24	"Procedure" AC-DC converter: 24 V drop to 0 Terminal X2.C. Caution Lamp: 14 V Output (EMS): <b>OFF</b> Caution Lamp: 28 V Output (AC): <b>ON</b> <sup>1)</sup> Caution Lamp: Start/Backup Power: <b>OFF</b>
	Example (Symbolic)	Start Power Switch: <b>OFF</b> Backup Battery Switch: <b>OFF</b> Engine running: Step 11 successful

<sup>1)</sup>In case of higher rpm >= 3000 rpm the Caution Lamp: 28 V Output (AC) is **OFF**.



Figure 3: Throttle position

# 3.4) After engine start

#### 

Non-compliance can result in serious injuries or death! Do not start the engine if any person is near the engine.

Warming up period

Step	Step Description	Procedure
1	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits while step 2 to 4.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. Display CAN A/B: Check and ensure compliance with opera- tional limits.
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check
2	Set Throttle Valve as required.	Set linearized throttle position in a way that the engine runs at approx. 2000 rpm for approx. 2 minutes.
	Example (Symbolic)	Set Throttle
3	Set Throttle Valve as required.	Set linearized throttle position in a way that the engine runs at approx. 2500 rpm until oil tem- perature reaches 50 °C (120 ° F).
	Example (Symbolic)	Set Throttle
4	Reduce Throttle Valve as required.	Set linearized throttle position so that the engine runs at idle.
	Example (Symbolic)	Reduce Throttle

# 3.5) Engine run-up

#### Ground test

ATT		$\sim$	
ALL	EN	UN	

After a full-load ground test allow a cooling run at idle speed to prevent vapour formation in the cylinder head.

Step	Step Description	Procedure
1	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits while step 2 to 3.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting Display CAN A/B: Check and ensure compliance with opera- tional limits.
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check
2	Set Full Throttle	Set linearized throttle position to WOT and check if maximum performance can be reached.
	Example (Symbolic)	Set Throttle.
3	Set Throttle Valve as required	Set linearized throttle position to reach an engine speed of 2500 rpm and continue with Lane check 2500 rpm and Igni- tion check.
	Example (Symbolic)	Set Throttle.

# Lane and Ignition check

During the Lane and Ignition check Engine Speed must always show plausible values no matter if one or both lanes are active. Otherwise maintenance is required.

Step	Step Description	Procedure
1	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits while step 2 to 11.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting Display CAN A/B: Check and ensure compliance with opera- tional limits.
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check
2	Set Throttle Valve as required.	Set linearized throttle position so that engine speed is approx 2500 rpm.
	Example (Symbolic)	Set Throttle
3	Deactivate ECU Lane A	HIC A: Disconnect Terminal 1 and Terminal 7 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane A.
	Example (Symbolic)	Lane select Switch A: OFF
4	Observe engine speed	Display CAN A/B; Check engine speed.
	Example (Symbolic)	Pilot Display: Check

### ATTENTION

Engine speed should not drop/increase more than 250 rpm. If the fuel pressure is not within the limits, the cause must be determined. The engine must not be put into service until the problem is rectified.

Step	Step Description	Procedure
5	Activate ECU Lane A	HIC A: Connect Terminal 1 and Terminal 7 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to power ECU Lane A.
	Example (Symbolic)	Lane select Switch A: <b>ON</b>
6	Await Warning Indica- tor A to extinguish and note how long this takes.	HIC A: 12 V voltage drop be- tween Terminal 2 and Terminal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D for 3 seconds.
	<b>NOTE</b> After the voltage drop between Terminal 2 and Terminal 8 changes back to 0 V wait approx. 3 seconds until continuing with the next step.	
	Example (Symbolic)	Warning Lamp A: Check
7	Deactivate ECU Lane B	HIC B: Disconnect Terminal 1 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane B.
	Example (Symbolic)	Lane select Switch B: OFF
8	Observe engine speed	Display CAN A/B: Check engine speed.
	Example (Symbolic)	Pilot Display: Check

### ATTENTION

Engine speed should not drop/increase more than 250 rpm. If the fuel pressure is not within the limits, the cause must be determined. The engine must not be put into service until the problem is rectified.

Step	Step Description	Procedure
9	Activate ECU Lane B	HIC B: Connect Terminal 1 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to power ECU Lane B.
	Example (Symbolic)	Lane select Switch B: <b>ON</b>

Step	Step Description	Procedure		
10	Await Warning Indicator B to extinguish and note how long this takes.	HIC A: 12 V voltage drop between Terminal 2 and Terminal 10 at 915 i Type A, or at 915 i C24 Terminal A and D for 3 seconds.		
	NOTE			
	After the voltage drop between Terminal Terminal 10 changes back to 0 V wait ap seconds until continuing with the next ste			
	Example (Symbolic)	Set Throttle		
11	Reduce Throttle Valve as required.	Set linearized throttle posi- tion to reach an engine speed of 2000 rpm and con- tinue with wastegate and PCV check.		
	Example (Symbolic)	Set Throttle		

#### NOTE

Lane A and Lane B have different sensor inputs. During Lane and Ignition check, some sensor values are not displayed, depending on the activation of the Lanes

Following sensor values are not available if Lane A is turned OFF and Lane B is activated:

- Coolant temperature
- Exhaust gas temperatures from cyl. 1-4
- Ambient temperature
- Throttle lever position

Following sensor values are not available if Lane B is turned OFF and Lane A is activated:

- · Oil temperature
- · Oil pressure

Manifold Air Temperature (MAT) must be <65 °C during the check procedure. Otherwise the ECU internal check of the Pressure Control Valve and Wastegate will not be executed.

#### NOTE

Step	Step Description	Procedure
1	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits while step 2 –13.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. Display CAN A/B: Check and ensure compliance with opera- tional limits.
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check
2	Set Throttle valve to WOT	Set linearized throttle position to 100%. Governor must be set in a way that engine speed >4700 rpm.
	Example (Symbolic)	Set Throttle
3	Deactivate ECU Lane A	HIC A: Disconnect Terminal 1 and Terminal 7 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane A
	Example (Symbolic)	Lane Select Switch A: OFF
4	Wait > 15 seconds	-
	Example (Symbolic)	Wait

If possible the PCV Check and the Lane and Ignition Check might be combined in one check.

Step	Step Description	Procedure	
5	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. Display CAN A/B: Check and ensure compliance with opera- tional limits.	
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check	
6	Activate ECU Lane A	HIC A: Connect Terminal 1 and Terminal 7 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to power ECU Lane A	
	Example (Symbolic)	Lane Select Switch A: ON	
7	Await Warning Indi- cator A to extinguish and note how long this takes.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D for 3 second.	
	NOTE		
	After the voltage drop between Terminal 2 and Terminal 8 changes back to 0 V wait approx 3 sec- onds until continuing with the next step.		
	Example (Symbolic)	Warning Lamp A: Check	
8	Deactivate ECU Lane B	HIC B: Disconnect Terminal 1 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane B.	
	Example (Symbolic)	Lane Select Switch B: OFF	
9	Wait > 15 seconds	-	
	Example (Symbolic)	Wait	

Step	Step Description	Procedure		
10	Check engine instru- ments (Warning Indi- cators and Operational Limits) and ensure compli- ance with the operat- ing limits.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut off engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut off engine and perform troubleshooting. Dis- play CAN A/B: Check and en- sure compliance with operational limits.		
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check		
11	Activate ECU Lane B	HIC B: Connect Terminal 1 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to power ECU Lane B.		
	Example (Symbolic)	Lane select Switch B: ON		
12	Await Warning Indi- cator B to extinguish and note how long this takes.	HIC A: 12 V voltage drop be- tween Terminal 2 and Terminal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D for 3 seconds.		
	NOTE			
	After the voltage drop between Terminal 2 and ter- minal 10 changes back to 0 V wait approx 3 sec- onds until continuing with the next step.			
	Example (Symbolic)	Warning Lamp B: Check		
13	Reduce Throttle Valve as required	Set linearized throttle position to reach an engine speed of 2000 rpm and continue with Fuel pump check		
	Example (Symbolic)	Set Throttle		

#### Fuel pump check

Verify that both fuel pumps are working and that no loss of power or irregular running occurs during deactivation of one fuel pump. The limits for fuel pressure must not be exceeded.

Step	Step Description	Procedure
Step     Step Description       1     Check engine instruments (Warning Indicators and Operational Limits) and ensure compliance with the operating limits while step 2 – 8.       Example (Symbolic)	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. Display CAN A/B: Check and ensure compliance with opera- tional limits.	
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check

Step	Step Description	Procedure
2	Set Throttle valve as required	Set linearized throttle position so that the engine speed is ap- prox 2000 rpm.
	Example (Symbolic)	Set Throttle
3	Deactivate Fuel pump 1	HIC A: Disconnect Terminal 3 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal E and F, to deactivate Fuel pump 1
	Example (Symbolic)	Fuel pump 1: OFF
4	Observe Fuel pressure	
	Example (Symbolic)	Pilot Display: Check

#### ATTENTION

If the fuel pressure is not within the limits, the cause must be determined. The engine must not be put into service until the problem is rectified.

Step	Step Description	Procedure
5	Activate Fuel pump 1	HIC A: Connect Terminal 3 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal E and F, to activate Fuel pump 1
	Example (Symbolic)	Fuel pump 1: <b>ON</b>
6	Deactivate Fuel pump 2	HIC A: Disconnect Terminal 3 and Terminal 11 at 915 i Type A, or at 915 i Type C24 AC-DC Con- verter Terminal X4.C and X4.D, to deactivate Fuel pump 2.
	Example (Symbolic)	Fuel pump 2: <b>OFF</b>
7	Observe Fuel pressure	
	Example (Symbolic)	Pilot Display: Check

### ATTENTION

If the fuel pressure is not within the limits, the cause must be determined. The engine must not be put into service until the problem is rectified.

Step	Step Description	Procedure
8	Activate Fuel pump 2	HIC A: Connect Terminal 3 and Terminal 11 at 915 i Type A, or at 915 i Type C24 AC-DC Con- verter Terminal X4.C and X4.D, to activate Fuel pump 2.
	Example (Symbolic)	Fuel pump 2: <b>ON</b>

# NOTE

Cycling the propeller governor puts a relatively high load on the engine. Unnecessary cycling should be avoided.

# 3.6) Engine shut-off

Step	Step Description	Procedure
1	Check the engine in- struments (Warning Indicators and Opera- tional Limits) and en- sure compliance with the operating limits while step 2 to 5.	HIC A: If a 12 V voltage drop between Terminal 2 and Termi- nal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. HIC B: If a 12 V voltage drop between Terminal 2 and Termi- nal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (permanent or oscillating) is detected, shut OFF engine and perform troubleshooting. Display CAN A/B: Check and ensure compliance with opera- tional limits
	Example (Symbolic)	Warning Lamp A: Check Warning Lamp B: Check Pilot Display: Check
2	Reduce Throttle valve as required.	Set linearized throttle position so that the engine runs on idle.
	Example (Symbolic)	Reduce Throttle.
3	Await cooling down phase.	Wait > 2 minutes.
4	Deactivate ECU	HIC A: Disconnect Terminal 1 and Terminal 7 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane A. HIC B: Disconnect Terminal 1 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane B.
	Example (Symbolic)	Lane select Switch A: <b>OFF</b> Lane select Switch B: <b>OFF</b>

### NOTE

The ECU needs to be deactivated before the fuel pumps. Shutting off the engine by deactivating the fuel supply may result in fault and failure entries in the ECU. Shutting down the engine by shutting off the fuel pumps is only allowed in emergency situations.

Step	Step Description	Procedure
5	Deactivate Fuel pumps	HIC A: Disconnect Terminal 3 and terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal E and F, to turn OFF Fuel pump 1 HIC B: Disconnect Terminal 3 and terminal 11 at 915 i Type A, or at 915 i Type C24 AC-DC Convert- er Terminal X4.C and X4.D, turn OFF Fuel pump 2
	Example (Symbolic)	Fuel pump 1: <b>OFF</b> Fuel pump 2: <b>OFF</b>

#### INTENTIONALLY LEFT BLANK

# 4) Abnormal operation

### Topics in this chapter

4.1 EMS	3
4.1.1 Failure of internal generators	6
4.1.2 Failure of AC-DC Converter	7
4.1.3 Engine not responding to throttle position	
commands	8
4.1.4 Engine on fire or fire in the engine	
compartment	8
4.2 Failures during engine start	9
4.2.1 Engine does not start	9
4.3 Re-Start during flight	9
4.4 The sprag clutch fails to decouple from the	
starter 1	0
4.5 Exceedance of operational limits1	0
4.6 Fuel pressure outside range1	0

#### 

**Non-compliance can result in serious injuries or death!** Unless stated otherwise in this chapter, operating an engine with limited airworthiness is not permitted. At unusual engine behavior conduct checks as per maintenance Manual Line Chapter 05-50-00 before the next flight. Only qualified staff (authorized by the Aviation Authorities) trained on this particular engine, is allowed to carry out maintenance and repair work.

The following description of procedures depends on the respective type of installation in the aircraft and shall therefore only be seen functionally.

# 4.1) EMS

### Warning Lamps

HIC A**)	HIC B**)	Effect on engine	Proposed action on ground if warning lamp is persistent *)	Proposed ac- tion in flight *)
0 V	Oscillat- ing 0-12 V	No effect on engine power, 2 systems available	Mainte- nance ac- tion required	Flight is possi- ble to your destination at your own discretion.
Oscillat- ing 0-12 V	0 V	No effect on engine power, 2 systems available	Mainte- nance ac- tion required	Flight is possi- ble to your destination at your own discretion.
0 V	12 V	No effect on engine power, rely on alter- nate system	Mainte- nance ac- tion required	Flight is possi- ble to your destination at your own discretion.
Oscillat- ing 0-12 V	Oscillat- ing 0-12 V	No effect on engine power, rely on alter- nate power supply system	Mainte- nance ac- tion required	Flight is possi- ble to your destination at your own discretion.
Oscillat- ing 0-12 V	12 V	No effect on engine power, rely on alter- nate system (oscillating system)	Mainte- nance ac- tion required	Flight is possi- ble to your destination at your own discretion.
12 V	0 V	No effect on engine power, rely on alter- nate system	Mainte- nance ac- tion required	Flight is possi- ble to your destination at your own discretion.

HIC A**)	HIC B**)	Effect on engine	Proposed action on ground if warning lamp is persistent *)	Proposed ac- tion in flight *)
12 V	Oscillat- ing 0-12 V	No effect on engine power, rely on alter- nate system (oscillating system)	Mainte- nance ac- tion required	Flight is possi- ble to your destination at your own discretion.
12 V	12 V	Loss of engine power possi- ble (LOPC up to IFSD), sys- tem relies on default values and tries to maintain operation	Mainte- nance ac- tion re- quired Flight not permissi- ble	Flight is possi- ble to your destination at your own discretion.

\*) Pilot action depends on installation relevant situation (SEP vs. MEP, operational conditions, additional installation provisions, etc.) and can not be determined at the engine manufacturing level and therefore must be established at the aircraft manufacturer's level.

\*\*) HIC A: Voltage between Terminal 2 and Terminal 8 at 915 i Type A, or at 915 i Type C24 Terminal A and D (Warning Indicator A)

\*\*) HIC B: Voltage between Terminal 2 and Terminal 10 at 915 i Type A, or at 915 i Type C24 Terminal A and D (Warning Indicator B)

#### ATTENTION

Reduce engine power setting to the minimum necessary and carry out precautionary landing.

### NOTE

An oscillating system indicates limited capability from the system (e.g. set value determination, diagnostics, etc.) however it still continues to be able to provide full engine power.

### NOTE

If a warning indicator remains on permanently, it indicates that an error with higher severity (Failure) has been detected by the internal testing procedures of the ECU.

In this case, the ECU will continue to operate in an alternative control mode, which will transfer the control of ignition and injection to the error- free Lane. Regular operation as well as alternative control modes of the ECU are able to represent the full engine power. Differences arise only in the efficiency of the engine.

*If limitations were exceeded, warning lamps may be reset by restart or lane check.* 

# 915 i TYPE C24

On the engine Type C24 AC-DC Converter Version, three caution lamps are implemented in the system:

### • Caution lamp Output 14 V (EMS)

The Caution lamp indicates the status of the Output 14 V (EMS) on the AC-DC converter which get supplied by Generator 2. The Output 14 V (EMS) lamp may be **ON** during engine start, until the voltage is bigger then >11.9 V. As long as Voltage stay within 11.9 V and 14.46 V the lamp remains **OFF**. In the unlikely event that the voltage is not longer within this range the lamp will come **ON**. If voltage will get back into normal operating range the Output 14 V (EMS) will go **OFF** again. No effect on engine power, rely on alternate power supply system. If Output 14 V (EMS) show up on ground a Maintenance action is required, if the lamp show up in flight - Check EMS Warning lamps and the Caution lamp Output 28 V (AC), also the Current and Voltage of the Battery. Flight is possible to your destination at your own discretion.

• Caution Lamp Output 28 V (AC)

If engine is not running or rpm is below generator switching rpm the Output 28 V (AC) lamp indicates that the power supply of 28 V side is not active. In this state the charging of the battery is not given. If voltage will get back into normal operating range the Output 28 V (AC) will go **OFF** again. If Output 28 V (AC) show up on ground a Maintenance action is required, if the lamp show up in flight - Check EMS Warning lamps and the Caution lamp Output 14 V (EMS), also the

Caution Lamps Current and Voltage of the Battery. Flight is possible to your destination at your own discretion.

• Caution Lamp Start / Backup Battery Switch If Start Power Switch or Backup Battery Switch or both are activated the this Caution lamp will be **ON**. So please check with Aircraft manufacturer on witch condition the switches need to be activated during flight. If lamp show up without having activated Start power or Backup Battery Switch a Maintenance action is required.

# 4.1.1) Failure of internal generators



Failure of Generator 1 If during normal operation (Generator 1 is supplying the EMS) Generator 1 fails, the ECU automatically switches over to supply the EMS by using Generator 2.

If the engine is supplied by Generator 2 the engine is able to deliver full performance. No performance drop can be recognized while the engine switches the supply from Generator 1 to Generator 2.

#### ATTENTION

If Generator 2 is used for supplying the EMS, the airframe will not be supplied with electrical power by an internal generator.

This failure condition will be detected by the EMS. Therefore see section "Failures detected by the EMS" for appropriate action.

Failure of Generator 2 If during normal operation (Generator 1 is supplying the EMS) Generator 2 fails, the ECU is not able to detect this condition.

#### 915 i TYPE C24

Caution lamp 14 V and 28 V Output ON

#### ATTENTION

If Generator 2 fails the Airframe will not be supplied with electrical power by an internal generator

Aircraft Manufacturer is responsible for defining a procedure for this failure condition.

Failure of both Generators A failure of both Generators (Generator 1/Generator 2) will result in engine stoppage unless the EMS is powered by an external power source (12 V voltage drop between X3 Terminal 1 and Aircraft ground).

### 915 i TYPE C24

Battery Backup Switch is activated engine is running – then Warning lamp flashing, Caution lamp 28 V **ON**, 14 V **OFF** and Caution Lamp Start/Backup Battery Switch **ON**.

Aircraft Manufacturer is responsible for defining a procedure for this failure condition.

# 4.1.2) Failure of AC-DC Converter

915 Type C24

Failure of the Output 14 V (EMS) side If Caution lamp Output 14 V (EMS) is **ON** during normal operation (Generator 1 is supplying the EMS) – it indicates a problem on the AC-DC converter 14 V (EMS) output side. As long as the Caution lamp Output 28 V (AC) is not **ON**, the problem is related to the AC-DC converter output, not to Generator 2.

### NOTE

The aux fuel pump is supplied from the Generator 2/AC-DC converter side.

Failure of the Output 28 V (AC) side If Caution lamp Output 28 V (AC) is **ON** during normal operation >3000 rpm (Generator 1 is supplying the EMS) – it indicates no power to the airframe on the AC-DC converter 28 V (AC) output side. As long as the Caution lamp Output 28 V (AC) is not **ON**, the problem is related to the AC-DC converter output, not to Generator 2.

# ATTENTION

If Caution lamp 28 V (AC) is ON the airframe will not be supplied with electrical power by the AC-DC converter 28 V output side.

As long as the Caution lamp Output 14 V (EMS) is not **ON**, the problem is related to heat transfer (high temperature), over current, over voltage on the 28 V output (AC) side.

# NOTE

The aux fuel pump is supplied from the Generator 2/AC-DC converter side.

# 4.1.3) Engine not responding to throttle position commands

Possible breakage/blockage of throttle valve actuation/linkage. In case of a breakage of the throttle valve actuation the valve will jump to wide open position.



For shutting off the engine proceed according to Engine shut-OFF procedure (see Chapter 3.6). As part of an abnormal operation, it might be required to shut down the engine at higher engine speeds.

# 4.1.4) Engine on fire or fire in the engine compartment

#### ATTENTION

#### Carry out emergency procedures as prescribed in the flight manual of the aircraft manufacturer.

- After landing locate the cause of fire and resolve the error before next flight by qualified staff (authorized by the Aviation Authorities)
- An entry in the logbook must be made
- · A maintenance inspection should be carried out

Aircraft Manufacturer is responsible for defining a procedure for this failure condition. Depending on the installation shutting off the fuel supply first might be required.

#### Emergency Engine shut-off

Step	Step Description	Procedure
1	Deactivate ECU	HIC A: Disconnect Terminal 1 and Terminal 7 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane A HIC B: Disconnect Terminal 1 and Terminal 9 at 915 i Type A, or at 915 i Type C24 Terminal N and P, to turn OFF ECU Lane B Display CAN A/B: Check and ensure compliance with opera- tional limits.
	Example (Symbolic)	Lane select Switch A: OFF Lane select Switch B: OFF

Loss of Display CAN Information If Display CAN Bus A or B fail, all information is still available on the working CAN Bus. In case Display CAN A and B fail and no engine parameters are available, land the aircraft. Aircraft Manufacturer is responsible for defining a procedure for both failure conditions.

Loss of Power Aircraft Manufacturer is responsible for defining a procedure for this failure condition.

# 4.2) Failures during engine start

# 4.2.1) Engine does not start

#### Insufficient supply from electrical power source.

• Ensure that Engine starter and EMS system is supplied by an external power source until engine reaches idle speed

#### Insufficient fuel supply.

· Ensure that Engine is supplied with fuel in appropriate quality

### Starting at low oil temperature.

• Use high quality oil without friction modifier see Chapter 2.4).

# 4.3) Re-Start during flight

If the propeller continues to rotate during flight by windmilling, but the speed is not sufficient to start the engine, the electric starter can be used. It is not required to wait until the propeller stops rotating.

# 4.4) The sprag clutch fails to decouple from the starter

ATTENTION

Shut down engine!

Risk of fire and danger of the electric starter overheating.

Follow engine shut OFF procedure (see Chapter 3.6).

# 4.5) Exceedance of operational limits

#### ATTENTION

When exceeding an operating limit, adapt engine power setting.

Any exceeding of an operating limit has to be entered by the pilot into engine logbook, stating duration of this omit condition. Unscheduled maintenance action may be required (see Maintenance Manual Line).

Aircraft Manufacturer is responsible for defining an abnormal operation procedure for each operating limit.

# 4.6) Fuel pressure outside range

ATTENTION

Reduce engine power setting to the minimum necessary and carry out precautionary landing.

Exceeding fuel pressure

- If the pressure is too high, switch the AUX- pump OFF. If this
  has no effect then limited flight operation with reduced power
  is possible.
- If the pressure is too low, switch the AUX-pump ON. If this has no effect then limited flight operation with reduced power is possible.
- A maintenance inspection should be carried out.
## 5) Performance and Fuel consumption

Topics in this chapter	
5.1 Performance data and fuel consumption	.2
5.2 Explanation of the parameters	.2

## 5.1) Performance data and fuel consumption

	Information on performance and fuel consumption are summar- ized in the ROTAX® Performance and Fuel Consumption Model. The Performance and Fuel consumption model for this engine is only available in the electronic version of this document (see Appendix) which can be downloaded on our website. www.flyrotax.com/service/technical-documentation.html
	Note that all information provided is model based and therefore subject to tolerances. This chapter summarizes the parameters and the constraints that need to be considered when working with this data.
	The actual power and fuel consumption is highly dependant upon the installation, the compliance to predefined mainte- nance events, and the way the engine is operated. Those val- ues need to be determined and provided by the aircraft manufacturer.
Ambient Conditions	Ambient conditions are given by the pressure in the ambient (p_ambient) and the temperature in the ambient (T_ambient).
Engine Conditions	Engine conditions are given by the engine speed (rpm) and throttle position (ECU_throttle_lin).
Critical Altitude	The engine was designed for a critical altitude up to 15000 ft.

## **5.2) Explanation of the parameters**

Parameters	Explanation
Case Number [No Unit]	Sequential number
rpm [RPM]	Engine speed
p_ambient [bar]	Pressure at ambient depending on altitude and weather conditions. The pressure was calculated according to ISA conditions at altitude. Engine deck was calculated with different altitudes from sea level to max operation altitude.
T_ambient [°C]	Temperature at ambient depending on altitude and weather conditions. The temperature was calculated according to ISA conditions and additional temperature variation -15 °C (5 °F), +15 °C (59 °F) and +30 °C (86 °F).
ECU_thottle_lin [%]	Linearized throttle position as given by the ECU.
Altitude [ft]	Altitude correlates to the ambient pressure (p_ambient) according ISA.

Parameters	Explanation
power_observ- ered [kW]	Power observed (certified) at the propeller shaft at given ambient conditions and engine conditions. This value means the LOWER LIMIT of the power tolerance range. Depending on circumstances the delivered power can be up to 6% higher but not lower than the power stated in the engine deck. The power stated in the engine deck accounts for:
	The use of different certified fuels
	Maximum allowed temperatures of oil and coolant
	Losses due to gear and governor
	Tolerances of the engine
	The observed power depends on:
	<ul> <li>MAT (T_Plenum): If the MAT exceeds the given limits power will decrease below stated values of the engine deck (not specified). For given ambient and engine conditions the MAT and the pressure in the plenum (p_Ple- num) can be used to evaluate the air path from the intake to the plenum.</li> </ul>
	<ul> <li>Fuel: With MOGAS the delivered power will be up to 1.4 [kW] higher than the stated power in the engine deck. Therefore power loss due to the use of AVGAS is taken into account.</li> </ul>
Fuel Flow [kg/h]	Fuel flow at given ambient/engine conditions, tolerance range at stationary flight conditions (5500-5800 rpm > 55 [kW, 4000-5000 rpm > 35 [kW]): 10%. Flight range must be evaluated by the manufacturer in real plane application.
p_plenum [bar]	At given ambient/engine conditions the pressure and temperature in the plenum correlates to engine power. Deviation more than +20 mbar (at 5800 rpm/at sea level) indicates failure in the air supply to the engine.
T_plenum [K]	At given ambient/engine conditions the temperature and pressure in the plenum correlates to engine power. Deviation more than +5 °C (41 °F) (at 5800 rpm/at sea level) indicates failure in the air supply to the engine.

#### INTENTIONALLY LEFT BLANK

## 7) System Description

#### Topics in this chapter

7.1 General specification	2
7.1.1 Basic specification	2
7.1.2 Technical data	2
7.1.3 Engine components	3
7.1.4 Cylinder arrangement	5
7.1.5 Direction of rotation	5
7.2 Cooling system	6
7.3 Fuel system	7
7.4 Lubrication system	8
7.5 Electric system	
7.5.1 Engine Management System	
7.5.2 Ignition control.	
7.5.3 Fuel injection control	
7.5.4 Communication interfaces	
7.6 Air intake system and Boost pressure	
control	
7.7 Exhaust system	21
7.8 Propeller gearbox	

Introduction	<ul> <li>This chapter of the Operators Manual contains information about the general engine specification as well as a description of cooling system, fuel system, lubrication system, electric system and the propeller gearbox.</li> <li>The system description refers only to the engine and not to a specific application in a particular aircraft. The aircraft manufacturer's Operators Manual is therefore definitive in terms of the operation of the engine, as it contains all the aircraft specific instructions.</li> </ul>
	The design shown in this chapter does not represent a

The design shown in this chapter does not represent a specified execution but should support the understanding of the system.

## 7.1) General specification

### 7.1.1) Basic specification

- 4-stroke-, 4 cylinder flat engine
- Liquid cooled cylinder heads
- · Ram air cooled cylinders
- Dry sump forced lubrication
- Fully redundant electronic engine management system (EMS) for controlling fuel injection, ignition, etc.
- Propeller drive via gearbox with integrated mechanical shock absorber and overload clutch
- Oil tank
- · Electric starter
- Turbocharged
- · Electronic/pneumatic control of boost pressure
- Preparation for hydraulic governor for constant speed propeller (configuration 3 only)
- Cooling air baffle

### 7.1.2) Technical data

Optional

Description	Value
Bore	84 mm (3.31 in)
Stroke	61 mm (2.40 in)
Displacement	1352 cm <sup>3</sup> (82.5 in <sup>3</sup> )
Compression ratio.	8.2:1

## 7.1.3) Engine components



Figure 1: Engine components

1	Propeller gearbox	2	ECU	3	Fusebox
4	Intercooler	5	Airbox	6	Wiring harness
7	Turbocharger	8	Air baffle	9	Electric starter
10	Oil tank	11	Oil filter	12	Suspen- sion frame
13	Flange for governor				



Figure 2: Engine components

1	Propeller gearbox	2	ECU	3	Fusebox
4	24 V AC/DC converter	5	Inter- cooler	6	Airbox
7	Wiring harness	8	Turbo- charger	9	Air baffle
10	Electric starter	11	Oil tank	12	Oil filter
13	Suspension frame	14	Flange for gov- ernor		

### 7.1.4) Cylinder arrangement



Figure 3: Cylinder arrangement

### 7.1.5) Direction of rotation

Direction of rotation on propeller shaft Direction of rotation on propeller shaft: counter clockwise, viewed from the front.



Figure 4: Normal direction of propeller rotation (engine)

## 7.2) Cooling system

- System Overview The cooling system of the engine is designed for liquid cooling of the cylinder heads and ram-air cooling of the cylinders. The cooling system of the cylinder heads is a closed circuit with an expansion tank.
- **Coolant flow** The coolant flow is forced by a water pump, driven from the camshaft, from the radiator to the cylinder heads. From the top of the cylinder heads the coolant passes on to the expansion tank. Since the standard location of the radiator is below engine level, the expansion tank located on the top of the engine allows for coolant expansion.
- **Expansion tank** From the expansion tank the coolant is sucked back to the water pump. In common installations the coolant passes a radiator in between. Additionally the expansion tank is closed by a pressure cap (with excess pressure valve and return valve). At temperature rise of the coolant the excess pressure valve opens and the coolant will escape via hose at atmospheric pressure. In common installation this hose is connected to an overflow bottle. This overflow bottle allows the coolant to be sucked back into the cooling circuit as the engine is cooling down.





- 1 Expansion tank 2 Radiator
- 3 Pressure cap
- 5 Level glass

4 Overflow bottle

## 7.3) Fuel system

Fuel flow

The fuel is pumped in the fuel rail 1/3 feed line (2). From there it passes the both fuel rails (connected by the fuel line (4)), the fuel regulator and escapes thru fuel rail 2/4 outlet line (1). The supply of the injectors (5) is done by the fuel rails. The fuel pressure regulator (6) ensures that the pressure differential between the fuel injectors and the intake manifold remains constant. This allows injecting same quantity of fuel independent from the operational state.



AE 5iS\_0144a

#### Figure 6: Fuel system

- 1 Fuel rail 2/4 outlet line
- 3 Fuel rail
- 5 Injection valves
- 2 Fuel rail 1/3 feed line
- 4 Fuel line
- 6 Fuel pressure regulator

### 7.4) Lubrication system

The engine is provided with a dry sump forced lubrication system with a main oil pump with integrated pressure regulator.



Figure 7: Lubrication system (symbolic)

Oil flow	The oil pump (driven by the camshaft) (2) sucks the motor oil from the oil tank (4) and forces it through the oil filter (3) and, depending on the engine installation, through the oil cooler, to the points of lubrication in the engine and the turbocharger. The escaping oil emerging from the points of lubrication accu- mulates on the bottom of crankcase and is forced back to the oil tank by the piston blow-by gases. The ventilation of the oil system is done by the vent socket on the oil tank
Turbocharger	The turbocharger is lubricated via a separate oil line (from the main oil pump). The oil emerging from the turbocharger oil sump and is sucked back to the secondary oil pump and then pumped back to the main oil tank via an oil hose



Figure 8: Lubrication system

- Pressure regulator 1
- 3 Oil filter
- Venting hose 5
- Oil pressure sensor 7
- Oil cooler 9

- 2 Oil pump
- 4 Oil tank
- Oil temperature sensor 6
- Turbocharger oil sump (with 8 oil screen)
- Oil temperature sensor
  - Oil pressure sensor

The oil temperature sensor for reading of the oil temperature is located on the crankcase, on the mag side of the engine.

The oil pressure sensor for reading of the oil pressure is located on the ignition housing.

### 7.5) Electric system

This System is responsible for supplying the Engine Management System (EMS) and the Airframe with electrical power. It consists of the Fusebox with Regulators and the Internal Generators.





Figure 9: Internal power supply

1 Stator 2 Fusebox

Generators 1 and 2	The two generators (Generator 1 and Generator 2) are mounted electrically isolated on one stator. Each generator is connected with a regulator mounted on the Fusebox. The Fuse- box takes care of the energy management and allows selecting whether the EMS is supplied by an external power source (e.g. Battery) or one of the generators. The selection of which gener- ator is powering the EMS depends on the engine status and can only be done by the Engine Control Unit (ECU). During the engine start an external power source is needed to power the EMS. After the engine speed is high enough to power the EMS with the Generator 2, for running the engine the exter- nal power source is only required in emergency situations. If a defined engine speed threshold has been reached for a certain time Generator 1 takes over to supply the EMS. After this, Gen- erator 2 can be used to supply the Airframe (e.g. instrumenta- tion). In no operation state can Generator 1 be used to supply the Airframe.
Malfunction	In case of an malfunction of Generator 1 the internal electric supply system changes to fail-safe mode where Generator 2 again is in charge to supply the EMS. In fail-safe mode Genera- tor 2 is not able to charge external power sources or supply the Airframe.
	The EMS is not capable of supervising the power provided to the Airframe. If the EMS is powered by Generator 1 and Gener- ator 2 fails; no indication is provided from engine side.





1 Stator

- 2 Fusebox
- 3 28 V AC-DC Converter assy.

	Generators 1 and 2	The two generators (Generator 1 and Generator 2) are mounted electrically isolated on one stator. Generator A is con- nected with a regulator mounted on the Fusebox, Generator B is connected with the AC-DC converter. The Fusebox takes care of the energy management and allows selecting whether the EMS is supplied by an external power source (e.g. Battery) or one of the generators. The selection of which generator is powering the EMS depends on the engine status and can only be done by the Engine Control Unit (ECU). During the engine start an external power source is needed to power the EMS. After the engine speed is high enough to power the EMS with the Generator 2, for running the engine the exter- nal power source is only required in emergency situations.
		NOTE
		The aux fuel pump is supplied from the Generator 2/AC-DC converter side. If a defined engine speed threshold has been reached for a certain time Generator 1 takes over to supply the EMS. Generator 2 can fully power the Airframe (e.g. instrumentation) when reaching 3000 rpm. Generator 1 does not supply the Airframe in any operation mode.
I	Malfunction	In case of an malfunction of Generator 1 the internal electric supply system changes to fail-safe mode where Generator 2 again is in charge to supply the EMS. In fail-safe mode Genera- tor 2 is still able to cover a certain power on the Airframe side.
		NOTE
		But it is needed to minimize the power on the Airframe side (switch <b>OFF</b> some instruments, air-condition, etc), please check with Pilot Operating Handbook of the relevant Airframe manufacturer.
		The EMS is not capable of supervising the power provided to the airframe. If the EMS is powered by Generator 1 and Gener-

The EMS is not capable of supervising the power provided to the airframe. If the EMS is powered by Generator 1 and Generator 2 fails; the Caution lamp 14 V (EMS) and Caution lamp 28 V (AC) are **ON**.

### 7.5.1) Engine Management System

Parts

The Engine Management System has following main functionality

- Ignition control
- · Fuel injection control
- Fault detection
- (Internal-) Generator management

Parts of the Engine Management System are Sensors, Actuators, the ECU and the wiring harness. The core of the EMS is the engine control unit (ECU), which consists of two modules. These modules will be denoted by Lane A and Lane B, each one capable of taking over control, regulation and monitoring of the engine. In error-free engine operation, both Lanes are turned ON.

> During engine control by Lane A, Lane B ensures that the engine operation can be maintained even after a failure or reduced functionality of Lane A. Depending on the activity and the failure status of the two Lanes, the ECU automatically selects a Lane to take over control of the engine. A huge quantity of sensors (e. g. sensors for measuring the pressure in the airbox) and actuators (e. g. ignition coils) of the engine are designed with redundancy. In this case, each of the sensors or actuators is connected to a Lane, so that the two Lanes have the same measurement values and send the same output signals. Nonredundant sensors (e. g. oil pressure sensors) are connected to one Lane only and serve for the expanded monitoring of the engine functionality. Due to an ECU internal communication, these sensor values will be exchanged between the two Lanes (assuming that both Lanes are active and free of errors).









AE 5iS\_0147\_b

915 i TYPE C24

Figure 12: Management System

### 7.5.2) Ignition control

The 915 iSc/iS is equipped with 4 double ignition coils. The ignition system is almost entirely wear-free, as the ECU generates and processes the ignition signal electronically.

### 7.5.3) Fuel injection control

The engine is equipped with an electronic fuel injection system. This system is controlled by the ECU and enables highly accurate metering of the fuel according to operating and load conditions, whilst at the same time also taking ambient conditions into account.

The key input variables are throttle valve position, engine speed signal, intake air temperature, ambient pressure, manifold pressure and exhaust temperature. Ultimately, the required fuel quantity or injection period is determined on the basis of the calculated air density in the airbox. It is monitored continuously.

## 7.5.4) Communication interfaces

Each Lane has a maintenance and a display interface (CANbus). While the maintenance interface is required to work with the BUDS Aircraft Diagnostic Software to perform various diagnostic and maintenance activities, the display CAN interface enables the connection of a display for visualization of engine parameters.

B.U.D.S Software For engines of the ROTAX® 915 i A Series, the maintenance and BUDS Aircraft Diagnostic Software is available. This provides not only the reading of ECU logs, it also provides a variety of functionality to support troubleshooting of the engine. To start this software and connect the engine with a computer a BUDS Aircraft Diagnostic Software kit is required. This is a hardware interface that provides different software functionality depending on its version.

## 7.6) Air intake system and Boost pressure control



#### Figure 13: Air intake system

- 1 Airfilter connection 2 Air intake hose
- 3 Turbocharger
- 5 Pop OFF valve
- 7 Solenoid valve 8 Waste gate

Intercooler

Throttle

4

6

The compressor side of the turbocharger sucks air thru the airfilter and pushes it thru the Intercooler into the airbox. The pressure in the airbox is controlled by the Throttle. From the airbox the compressed air moves thru the intake manifolds into the four cylinders.



#### Figure 14

Boost pressure control	The compression rate of air is depending on the amount of ex- haust gases passing the compression side of the turbocharger. For controlling this compression rate the waste gate has an im- portant role. If the wastegate is fully closed the complete flow of exhaust gases must pass the turbine. The more the wastegate is opened, the less exhaust gases have to pass the turbine. The waste gate is powered by the boost pressure from the com- pressor. Pneumatic valves actuated by the ECU control the amount of the boost pressure necessary to adjust the waste gate to reach the requested boost pressure. The PCV, as well as Wastegate, are normally closed
Over boost valve	In case of overboost conditions the overboost valve is opened to relieve the excessive pressure.
Ambient Air Pres- sure and Tempera- ture Sensor (AAPTS)	The two Ambient Air Pressure and Temperature Sensors (AAPTS) are all-in-one sensors for engine ambient temperature and engine ambient pressure. In cowled engine installations they have to be mounted in the engine compartment in a ram- air-free area and close to the air inlet. The sensors must

	measure the correct air inlet temperature and the air pressure right before the air filter.
Boost Pressure Sensor (BPS)	The boost pressure sensors for reading of the boost pressure are located right before the throttle near the overboost valve.
Manifold Air Pres- sure Sensor (MAP)	The manifold air pressure sensors are located on the airbox.
Manifold Air Tem- perature Sensor (MAT)	The manifold air temperature sensors are located on the airbox.

## 7.7) Exhaust system



Figure 15: Turbocharger/Exhaust system

1	Exhaust manifold	2	Exhaust pipes
---	------------------	---	---------------

3 Muffler 4 Turbocharger

**Exhaust flow** The Exhaust gases are pushed out of the cylinders thru the exhaust pipes and are brought together in the exhaust manifold. From there the exhaust gases pass the turbine side of the turbocharger (depending on the waste gate position). From there the exhaust gases leave the engine thru the muffler.

#### Exhaust Gas Temperature Sensors The sensors for reading the exhaust gas temperature are located on the exhaust pipes near the cylinder outlet. (EGT)

## 7.8) Propeller gearbox

#### **Reduction ratio**

Reduction ratio	915 iSc/iS
crankshaft: propeller shaft	2.54:1

The propeller shaft is driven by the crankshaft by means of a spur gear unit.

The power transmission from the crankshaft to the propeller consists of:

- Overload clutch
- · Damper clutch
- Torsion shaft

The damper clutch and torsion shaft absorbs vibrations and/or shocks caused by engine running and/or the propeller. The overload clutch protects the crankshaft in case of a propeller strike.

**Governor** Alternatively a hydraulic governor for constant speed propeller can be used. (only for configuration 3). The drive is via the propeller reduction gear.

## 8) Preservation and storage

#### Topics in this chapter

8.1 Engine preservation and storage	2
8.2 Engine back to operation	4

Safety

All checks to be carried out as specified in the current Maintenance Manual Line (last revision).



As well as the maintenance and special checks, see Maintenance Manual Line for the engine type 915 i A Series.

#### 

Non-compliance can result in serious injuries or death! Only qualified staff (authorized by the Aviation Authorities) trained on this particular engine, is allowed to carry out maintenance and repair work.

#### NOTE

Other useful information for service and airworthiness of your engine you'll find on www.rotax-owner.com.

#### ATTENTION

Carry out all directives of Service Bulletins (SB), according to their priority. Observe applicable Service Instructions (SI) and Service Letter (SL).

## 8.1) Engine preservation and storage

#### General

Environmental corrosion (on the external surfaces) is a naturally occurring process which can inevitably affect the continued airworthiness of the engine, engine mounted components and accessories. Susceptibility to corrosion is influenced by a number of factors, including but not limited to, geographical location, season and usage. All general preventive (technical) measures, identification, control and treatment of corrosive attack on aircraft structures and engine materials has to be carried out in accordance with Advisory Circular AC 43-4B from FAA and also in accordance with the information of the aircraft manufacturer's Instruction for Continued Airworthiness. Furthermore the preservation procedures for stored and inactive aircraft (engines) provides an effective means for combating and minimizing the corrosion condition and should be adhered to.

Advisory Circular AC 43-4B: This advisory circular (AC) is a summary of the current available data regarding identification and treatment of corrosive attack on aircraft structures and engine materials. Corrosion inspection frequency, corrosion identification, and especially corrosion treatment continues to be the responsibility of the operator. These inspections should be accomplished per this AC, the manufacturer's recommendations, or the operator's own maintenance program. The procedures in this AC are an acceptable means, but not the only acceptable means, of corrosion treatment. The information in this AC is applicable to aircraft for which the manufacturer has not published corrosion control information.

#### **A WARNING**

Risk of burns and scalds! Hot engine parts! Conduct checks on cold engine only!

Due to the special material of the cylinder wall, there is no need for extra protection against corrosion for ROTAX® aircraft engines. At extreme climatic conditions and for long out of service periods we recommend the following to protect the valve guides against corrosion:

Step	Procedure
1	Operate the engine until the temperatures have stabilized for a period of 5 min (engine oil temperature between 50 to 70 °C (122 to 160 °F).
2	Shut-off engine.
3	Allow the engine to cool down.

Step	Procedure
4	Change oil.
5	Remove the top spark plugs and spray into openings with corrosion inhibiting oil.
6	Turn the propeller several times by hand in direction of the engine rotation, so that the corrosion inhibiting oil reaches all necessary points.
7	Install the spark plugs in accordance to the Maintenance Manual.
8	Close <b>all</b> openings on the cold engine, such as exhaust end pipe, venting tube, air filter etc. against entry of dirt and humidity.
9	Spray all steel external engine parts with corrosion inhibit- ing oil.

### 8.2) Engine back to operation

If preservation (including oil change) took place within a year of storage, oil renewal will not be necessary. For longer storage periods repeat preservation annually.

Step	Procedure
1	Remove all plugs and caps.
2	Clean spark plugs with plastic brush and solvent.
3	Reinstall.

## 9) Supplement

Topics in this chapter 9.1 Form		
	See Form.	
	According to the regulation of EASA part 21.A.3 the manufacturer shall evaluate field information and report to the authority. In case of any relevant occurrences that may involve malfunction of the engine, the form on the next page should be filled out and sent to the responsible ROTAX® authorized aircraft engines distributor or their independent Service Center.	
	NOTE	
	The form is also available from the official ROTAX® AIRCRAFT ENGINES Website in electronic version.	
Authorized Distributor	Overview of ROTAX® authorized aircraft engines distributor or their independent Service Center. Refer to the official ROTAX® AIRCRAFT ENGINES Website www.FLYROTAX.com.	

# ROTAX.

# CUSTOMER SERVICE INFORMATION REPORT

WHEN / WHERE / WHAT		
Accident / Incident Date	State / Country	
Location of Occarence		
Headline		
Namative		
		1
AIRCRAFT IDENTIFICATION		
Aircraft registration	Aircraft cabegory	
Manufacturer	Model / Senes	
Senal Number	Aircratt total time	
FLIGHT DETAILS		
Flight phase	Operator	
Lasi departure pomi	Planned destination	
ENGINE INFORMATION		
Type	Senal Number	
Time since naw (h)	Time since overnaul [h]	
Date overhaut	Ilate impéction / mainténaricé	
PROPELLER INFORMATION		
Manufacturar	Model / Series	
Serial Number	Propeller position	
FLYROTAX.COM		
# and TNI and Transmissive of BRP-Retaix Ornet. & Co (Ø). # 2020 BRP-Retain Grabh & Co (HE ÅΠ night) meanwed.	BARATERIAN	

Figure 1: Form

## 10) Proper disposal

#### ENVIRONMENTAL NOTE

Pleaseobservethedisposal regulationsapplicable in your area.

General	All old/used parts, liquids and chemical agents be disposed of according to local ordinance regulations.
Packaging	The disposal of the packaging is the customer's responsibility and has to take place in accordance with the current regulations of the country in which it has been removed.
Liquids	<ul> <li>Engine oil: Dispose of engine oil at the respective oil collecting point or hand it over to an approved disposal company</li> </ul>
	<ul> <li>Coolant: Dispose of coolant at the respective collecting point or hand it over to an approved disposal company</li> </ul>
	<ul> <li>Fuel: Dispose of fuel at the respective collecting point or hand it over to an approved disposal company</li> </ul>
	<b>▲ WARNING</b>
	Flammable material must be placed at a sufficient distance from all sources of ignition, direct and strong sunlight, spotlights and heating devices, so that it cannot be ignited by such items.
	ENVIRONMENTAL NOTE
	Observe the safety instructions of the manufacturer of hazardous substances (coolant, oil or fuel) and the applicable regional waste disposal regulations.

#### ENVIRONMENTAL NOTE

Work with the utmost care to ensure that no water pollutants can penetrate into the soil, water or the sewerage system.

Old/used parts	Please return old/used parts (not periodic maintenance parts) from ROTAX® aircraft engines F.O.B to ROTAX® Authorized Distributors or their independent Service Centers.
Chemical agents (cleaner, LOCTITE etc.)	Please observe the safety and disposal instructions of the manufacturer.

## Index

# Α

Abbreviations	3
Abnormal operation	1
After engine start	12
Air intake system	18

## В

Basic specification	.2
Boost pressure control	18

## С

Communication interfaces1	7
Cooling system	6
Cylinder arrangement	5

## D

Daily checks	2
Direction of rotation	5
Disposal	1

## Ε

Electric system10
EMS
Engine back to operation4
Engine components3
Engine does not start9
Engine Management System14
Engine not responding to
throttle position commands8
•
Engine preservation and storage2
Engine preservation and storage2 Engine run-up13
Engine preservation and storage2 Engine run-up13 Engine shut-off22
Engine preservation and storage2 Engine run-up13 Engine shut-off22 Engine start
Engine preservation and storage2 Engine run-up13 Engine shut-off22 Engine start6 Exceedance of operational limits10

## F

Failure, AC-DC converter	7
Failure, internal generators	6
Failures during engine start	9
Fire, Engine, compartment	8
Form	2
Fuel injection control	16
Fuel pressure, outside range	10
Fuel system	7

## G

General	2
General specification	2

## I

Ignition control		16
------------------	--	----

## L

List of effective pages	1
Lubrication system	8

## 0

.2
.7
.7
.8

## Ρ

Performance data Pre-flight checks	2
Pre-flight checks	5
Propeller gearbox	22

К	
1	

R	Т
Re-Start during flight9	Table Techn
S	Techn Terms
-	. 511110

Table of amendments	1
Technical data	2
Technical documentation	13
Terms	3
Turbocharger/Exhaust system .	21
Type description	15


Engine serial no.

Type of aircraft

Aircraft registration no.



Rotax<sup>®</sup> authorized distributor

## FLYROTAX.COM

<sup>®</sup> and TM are trademarks of BRP-Rotax GmbH & Co KG.
<sup>©</sup> 2021 BRP-Rotax GmbH & Co KG. All rights reserved.

